

Network Video Recorder

User Manual

User Manual

COPYRIGHT ©2017 Hangzhou Hikvision Digital Technology Co., Ltd.

ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou Hikvision Digital Technology Co., Ltd. or its subsidiaries (hereinafter referred to be "Hikvision"). This user manual (hereinafter referred to be "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of Hikvision. Unless otherwise stipulated, Hikvision does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

About this Manual

This Manual is applicable to Network Video Recorder (NVR).

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the company website (http://overseas.hikvision.com/en/).

Please use this user manual under the guidance of professionals.

Trademarks Acknowledgement

HIKVISION and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED "AS IS", WITH ALL FAULTS AND ERRORS, AND HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL HIKVISION, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. HIKVISION SHALL NOT TAKE ANY RESPONSIBILITES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

SURVEILLANCE LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS THE APPLICABLE LAW. HIKVISION SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATER PREVAILS.

Regulatory Information

FCC Information

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC compliance: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Conditions

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.

EU Conformity Statement

This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the EMC Directive 2014/30/EU, the LVD Directive 2014/35/EU, the RoHS Directive 2011/65/EU.



2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or

dispose of it at designated collection points. For more information see: www.recyclethis.info



2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include

lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: www.recyclethis.info

Industry Canada ICES-003 Compliance

This device meets the CAN ICES-3 (A)/NMB-3(A) standards requirements.

Applicable Models

This manual is applicable to the models listed in the following table.

| Series | Model |
|----------------|------------------|
| | DS-9608NI-I8 |
| DS-9600NI-18 | DS-9616NI-I8 |
| D2-9000INI-18 | DS-9632NI-I8 |
| | DS-9664NI-I8 |
| | DS-9616NI-I16 |
| DS-9600NI-I16 | DS-9632NI-I16 |
| | DS-9664NI-I16 |
| | DS-8608NI-I8 |
| DS-8600NI-18 | DS-8616NI-I8 |
| D3-9000INI-19 | DS-8632NI-I8 |
| | DS-8664NI-I8 |
| | DS-7608NI-I2 |
| DS-7600NI-I2 | DS-7616NI-I2 |
| | DS-7632NI-I2 |
| | DS-7608NI-I2/8P |
| DS-7600NI-I2/P | DS-7616NI-I2/16P |
| | DS-7632NI-I2/16P |
| | DS-7708NI-I4 |
| DS-7700NI-I4 | DS-7716NI-I4 |
| | DS-7732NI-I4 |
| | DS-7708NI-I4/8P |
| DS-7700NI-I4/P | DS-7716NI-I4/16P |
| | DS-7732NI-I4/16P |
| | DS-8608NI-K8 |
| DS-8600NI-K8 | DS-8616NI-K8 |
| | DS-8632NI-K8 |
| | DS-7708NI-K4 |
| DS-7700NI-K4 | DS-7716NI-K4 |
| | DS-7732NI-K4 |
| DC 7700NI K4/D | DS-7708NI-K4/8P |
| DS-7700NI-K4/P | DS-7716NI-K4/16P |

| | DS-7732NI-K4/16P |
|-----------------|------------------|
| | DS-7608NI-K2 |
| DS-7600NI-K2 | DS-7616NI-K2 |
| | DS-7632NI-K2 |
| | DS-7608NI-K2/8P |
| DS-7600NI-K2/P | DS-7616NI-K2/16P |
| | DS-7632NI-K2/16P |
| | DS-7604NI-K1 |
| DS-7600NI-K1 | DS-7608NI-K1 |
| | DS-7616NI-K1 |
| DS-7600NI-K1/4P | DS-7604NI-K1/4P |

Symbol Conventions

The symbols that may be found in this document are defined as follows.

| Symbol | Description | | |
|------------------|---|--|--|
| NOTE | Provides additional information to emphasize or supplement important points of the main text. | | |
| A WARNING | Indicates a potentially hazardous situation, which if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results. | | |
| DANGER | Indicates a hazard with a high level of risk, which if not avoided, will result in death or serious injury. | | |

Safety Instructions

- Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.
- In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region. Please refer to technical specifications for detailed information.
- Input voltage should meet both the SELV (Safety Extra Low Voltage) and the Limited Power Source with 100~240 VAC or 12 VDC according to the IEC60950-1 standard. Please refer to technical specifications for detailed information.
- Do not connect several devices to one power adapter as adapter overload may cause over-heating or a fire hazard.
- Please make sure that the plug is firmly connected to the power socket.
- If smoke, odor or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.

Preventive and Cautionary Tips

Before connecting and operating your device, please be advised of the following tips:

- Ensure unit is installed in a well-ventilated, dust-free environment.
- Unit is designed for indoor use only.
- Keep all liquids away from the device.
- Ensure environmental conditions meet factory specifications.
- Ensure unit is properly secured to a rack or shelf. Major shocks or jolts to the unit as a result of dropping it may cause damage to the sensitive electronics within the unit.
- Use the device in conjunction with an UPS if possible.
- Power down the unit before connecting and disconnecting accessories and peripherals.
- A factory recommended HDD should be used for this device.
- Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufacturer.

Product Key Features

General

- Connectable to network cameras, network dome and encoders.
- Connectable to the third-party network cameras like ACTI, Arecont, AXIS, Bosch, Brickcom, Canon, PANASONIC, Pelco, SAMSUNG, SANYO, SONY, Vivotek and ZAVIO, and cameras that adopt ONVIF or PSIA protocol.
- Connectable to the smart IP cameras.
- H.265+/H.265/ H.264+/H.264/MPEG4 video formats
- PAL/NTSC adaptive video inputs.
- Each channel supports dual-stream.
- Up to 8/16/32/64 network cameras can be added according to different models.
- Independent configuration for each channel, including resolution, frame rate, bit rate, image quality, etc.
- The quality of the input and output record is configurable.

Local Monitoring

- HDMI/VGA1 and HDMI2/VGA2 outputs provided for DS-9600NI and DS-8600NI series NVR.
- HDMI and VGA outputs provided for DS-7600NI and DS-7700NI series NVR.
- HDMI Video output at up to 4K resolution and VGA video output at up to 2K resolution.
- Multiple screen display in live view is supported, and the display sequence of channels is adjustable.
- Live view screen can be switched in group. Manual switch and auto-switch are provided and the auto-switch interval is configurable.
- 3D positioning supported by I series NVR in live view.
- Configurable main stream and sub-stream for the live view.
- Quick setting menu is provided for live view.
- POS information overlay on live view by I series NVR.
- Motion detection, video tampering, video exception alert and video loss alert functions.
- Privacy mask.
- Multiple PTZ protocols supported; PTZ preset, patrol and pattern.
- Zooming in by clicking the mouse and PTZ tracing by dragging mouse.

HDD Management

Up to 16 SATA hard disks and 1 eSATA disk can be connected for DS-9600NI-I16, up to 8 SATA hard disks and 1 eSATA disk can be connected for DS-9600NI-I8, DS-8600NI-I8 and DS-8600NI-K8, 4 SATA hard disks for DS-7700NI, 2 SATA hard disks for DS-7600NI-I2/K2 (/P), and 1 SATA hard disk for DS-7600NI-K1 (/P) series NVR.

- Up to 6TB storage capacity for each disk supported.
- Supports 8 network disks (NAS/IP SAN disk).
- Supports S.M.A.R.T. and bad sector detection.
- HDD group management.
- Supports HDD standby function.
- HDD property: redundancy, read-only, read/write (R/W).
- HDD quota management; different capacity can be assigned to different channel.
- For DS-9600NI-I8 and DS-9600NI-I16 series, RAID0, RAID1, RAID5, RAID6 and RAID 10 are supported.
- Hot-swappable RAID storage scheme, and can be enabled and disabled on your demand. And 16 arrays can be configured.
- DS-9600NI-I8, DS-8600NI-I8 and DS-9600NI-I16 series NVR support disk clone to the eSATA disk.

Recording, Capture and Playback



The capture is supported by I series NVR only.

- Holiday recording schedule configuration.
- Continuous and event video recording parameters.
- Multiple recording types: manual, continuous, alarm, motion, motion | alarm, motion & alarm
 VCA, and POS (for I series NVR only).
- 8 recording time periods with separated recording types.
- POS information overlay on image by I series NVR.
- Pre-record and post-record for alarm, motion detection for recording, and pre-record time for schedule and manual recording.
- Searching record files and captured pictures by events (alarm input/motion detection).
- Tag adding for record files, searching and playing back by tags.
- Locking and unlocking record files.
- Local redundant recording and capture.
- Provide new playback interface with easy and flexible operation.
- Searching and playing back record files by channel number, recording type, start time, end time, etc.
- Supports the playback by main stream or sub stream. (I series NVR)
- Smart search for the selected area in the video.
- Zooming in when playback.
- Reverse playback of multi-channel.

- Supports pause, play reverse, speed up, speed down, skip forward, and skip backward when playback, and locating by dragging the mouse.
- Supports thumbnails view and fast view during playback.
- Up to 16-ch synchronous playback at 1080p real time.
- Supports playback by transcoded stream.
- Manual capture, continuous capture of video images and playback of captured pictures.
- Supports enabling H.264+ to ensure high video quality with lowered bitrate.

Backup

- Export video data by USB, SATA or eSATA device (for DS-9600NI-I8, DS-8600NI-I8 and DS-9600NI-I16 only).
- Export video clips when playback.
- Management and maintenance of backup devices.
- Either Normal or Hot Spare working mode is configurable to constitute an N+1 hot spare system.

Alarm and Exception

- Configurable arming time of alarm input/output.
- Alarm for video loss, motion detection, tampering, abnormal signal, video input/output standard mismatch, illegal login, network disconnected, IP confliction, abnormal record/capture, HDD error, and HDD full, etc.
- POS triggered alarm supported by I series NVR.
- VCA detection alarm is supported.
- VCA search for face detection, vehicle plate, behavior analysis, people counting and heat map.
- Connectable to the thermal network camera. (I series NVR)
- Supports the advanced search for fire/ship/temperature/temperature difference detection triggered alarm and the recorded video files and pictures (I series NVR)
- Alarm triggers full screen monitoring, audio alarm, notifying surveillance center, sending email and alarm output.
- Automatic restore when system is abnormal.

Other Local Functions

- Operable by front panel, mouse, remote control, or control keyboard.
- Three-level user management; admin user is allowed to create many operating accounts and define their operating permission, which includes the limit to access any channel.
- Admin password resetting by exporting/importing the GUID file.
- Operation, alarm, exceptions and log recording and searching.
- Manually triggering and clearing alarms.
- Import and export of device configuration information.

Network Functions

- Two self-adaptive 10M/100M/1000Mbps network interfaces for DS-9600NI, DS-8600NI, DS-7700NI-I4 and DS-7700NI-K4, and the multi-address and network fault tolerance working modes are configurable.
- One self-adaptive 10M/100M/1000Mbps network interface for DS-7600NI-K2/I2 (/P), DS-7700NI-I4/P and DS-7700NI-K4/P.
- One self-adaptive 10M/100Mbps network interface for DS-7600NI-K1 (/P).
- Four independent PoE network interfaces are provided for /4P models, eight independent PoE network interfaces for the /8P models, and sixteen independent PoE network interfaces for the /16P models.
- Long distance (100-300 m) network transmission via PoE (for /P models).
- IPv6 is supported.
- TCP/IP protocol, DHCP, DNS, DDNS, NTP, SADP, SMTP, SNMP, NFS, and iSCSI are supported.
- TCP, UDP and RTP for unicast.
- Auto/Manual port mapping by UPnPTM.
- Support access by Hik-Connect.
- Remote web browser access by HTTPS ensures high security.
- The ANR (Automatic Network Replenishment) function is supported, it enables the IP camera save the recording files in the local storage when the network is disconnected, and synchronizes the files to the NVR when the network is resumed.
- Remote reverse playback via RTSP.
- Supports accessing by the platform via ONVIF.
- Remote search, playback, download, locking and unlocking of the record files, and support downloading files broken transfer resume.
- Remote parameters setup; remote import/export of device parameters.
- Remote viewing of the device status, system logs and alarm status.
- Remote keyboard operation.
- Remote HDD formatting and program upgrading.
- Remote system restart and shutdown.
- RS-232, RS-485 transparent channel transmission.
- Alarm and exception information can be sent to the remote host
- Remotely start/stop recording.
- Remotely start/stop alarm output.
- Remote PTZ control.
- Remote JPEG capture.
- Virtual host function is provided to get access and manage the IP camera directly.
- Two-way audio and voice broadcasting.

Embedded WEB server.

Development Scalability:

- SDK for Windows system.
- Source code of application software for demo.
- Development support and training for application system.

TABLE OF CONTENTS

| Chapter 1 Introduction | 18 |
|---|----|
| 1.1 Front Panel | 18 |
| 1.1.1 DS-9600NI Series | 18 |
| 1.1.2 DS-8600NI-I8 Series | 22 |
| 1.1.3 DS-8600NI-K8 and DS-7700NI Series | 26 |
| 1.1.4 DS-7600NI Series | 28 |
| 1.2 IR Remote Control Operations | 28 |
| 1.3 USB Mouse Operation | 34 |
| 1.4 Input Method Description | 35 |
| 1.5 Rear Panel | 36 |
| 1.5.1 DS-9600NI and DS-8600NI Series | 36 |
| 1.5.2 DS-7600NI Series | 37 |
| 1.5.3 DS-7700NI Series | 40 |
| Chapter 2 Getting Started | 42 |
| 2.1 Device Startup and Activation | 42 |
| 2.1.1 Starting Up and Shutting Down the NVR | 42 |
| 2.1.2 Activating Your Device | 43 |
| 2.1.3 Using the Unlock Pattern for Login | 45 |
| 2.1.4 Login and Logout | 48 |
| 2.1.5 Resetting Your Password | 49 |
| 2.2 Using Wizard for Basic Configuration | 50 |
| 2.3 Adding and Connecting the IP Cameras | 56 |
| 2.3.1 Activating the IP Camera | 56 |
| 2.3.2 Adding the Online IP Cameras | 57 |
| 2.3.3 Editing the Connected IP Cameras and Configuring Customized Protocols | 62 |
| 2.3.4 Editing IP Cameras Connected to the PoE Interfaces | 66 |
| 2.3.5 Configuring PoE Interface | 68 |
| Chapter 3 Live View | 70 |
| 3.1 Introduction of Live View | 70 |
| 3.2 Operations in Live View Mode | 71 |
| 3.2.1 Front Panel Operation on Live View | 72 |
| 3.2.2 Using the Mouse in Live View | 72 |

| 3.2.3 Using an Auxiliary Monitor | 73 |
|--|-----|
| 3.2.4 Quick Setting Toolbar in Live View Mode | 74 |
| 3.2.5 Fisheye Expansion View | 76 |
| 3.3 Adjusting Live View Settings | 78 |
| 3.4 Channel-zero Encoding | 80 |
| Chapter 4 PTZ Controls | 81 |
| 4.1 Configuring PTZ Settings | 81 |
| 4.2 Setting PTZ Presets, Patrols & Patterns | 83 |
| 4.2.1 Customizing Presets | 83 |
| 4.2.2 Calling Presets | 83 |
| 4.2.3 Customizing Patrols | 84 |
| 4.2.4 Calling Patrols | 85 |
| 4.2.5 Customizing Patterns | 86 |
| 4.2.6 Calling Patterns | 87 |
| 4.2.7 Customizing Linear Scan Limit | 87 |
| 4.2.8 Calling Linear Scan | 88 |
| 4.2.9 One-touch Park | 89 |
| 4.3 PTZ Control Panel | 91 |
| Chapter 5 Recording and Capture Settings | 93 |
| 5.1 Configuring Parameters | 93 |
| 5.2 Configuring Recording and Capture Schedule | 97 |
| 5.3 Configuring Motion Detection Recording and Capture | 101 |
| 5.4 Configuring Alarm Triggered Recording and Capture | 103 |
| 5.5 Configuring VCA Event Recording | 105 |
| 5.6 Manual Recording and Continuous Capture | 107 |
| 5.7 Configuring Holiday Recording and Capture | 109 |
| 5.8 Configuring Redundant Recording and Capture | 111 |
| 5.9 Configuring HDD Group for Recording and Capture | 113 |
| 5.10 Files Protection | 114 |
| 5.10.1 Locking the Recording Files | 114 |
| 5.10.2 Setting HDD Property to Read-only | 116 |
| Chapter 6 Playback | 118 |
| 6.1 Playing Back Record Files | 118 |
| 6.1.1 Instant Playback | 118 |
| 6.1.2 Playing Back by Normal Search | 118 |

| 6.1.3 Playing back by Smart Search | 122 |
|--|-----|
| 6.1.4 Playing Back by Event Search | 125 |
| 6.1.5 Playing Back by Tag | 127 |
| 6.1.6 Playing Back by Sub-periods | 129 |
| 6.1.7 Playing Back by System Logs | 130 |
| 6.1.8 Playing Back External File | 132 |
| 6.1.9 Playing Back Pictures | 133 |
| 6.2 Auxiliary Functions of Playback | 134 |
| 6.2.1 Playing Back Frame by Frame | 134 |
| 6.2.2 Thumbnails View | 134 |
| 6.2.3 Fast View | 135 |
| 6.2.4 Digital Zoom | 135 |
| 6.2.5 File Management | 136 |
| Chapter 7 Backup | 137 |
| 7.1 Backing up Record Files | 137 |
| 7.1.1 Quick Export | 137 |
| 7.1.2 Backing up by Normal Video/Picture Search | 139 |
| 7.1.3 Backing up by Event Search | 142 |
| 7.1.4 Backing up Video Clips or Captured Playback Pictures | 143 |
| 7.2 Managing Backup Devices | 144 |
| 7.3 Hot Spare Device Backup | 145 |
| 7.3.2 Setting Hot Spare Device | 145 |
| 7.3.3 Setting Working Device | 146 |
| 7.3.4 Managing Hot Spare System | 146 |
| Chapter 8 Alarm Settings | 149 |
| 8.1 Setting Motion Detection Alarm | |
| 8.2 Setting Sensor Alarms | |
| 8.3 Detecting Video Loss Alarm | |
| 8.4 Detecting Video Tampering Alarm | |
| 8.5 Handling Exceptions Alarm | |
| 8.6 Setting Alarm Response Actions | |
| 8.7 Triggering or Clearing Alarm Output Manually | |
| Chapter 9 POS Configuration | |
| 9.1 Configuring POS Settings | |
| 9.2 Configuring Overlay Channel | |
| | |

| 9.3 Configuring POS Privacy Information Filtering | 170 |
|---|-----|
| 9.4 Configuring POS Alarm | 170 |
| Chapter 10 VCA Alarm | 173 |
| 10.1 Face Detection | 173 |
| 10.2 Vehicle Detection | 175 |
| 10.3 Line Crossing Detection | 176 |
| 10.4 Intrusion Detection | 179 |
| 10.5 Region Entrance Detection | 181 |
| 10.6 Region Exiting Detection | 182 |
| 10.7 Unattended Baggage Detection | 182 |
| 10.8 Object Removal Detection | 183 |
| 10.9 Audio Exception Detection | 183 |
| 10.10 Sudden Scene Change Detection | 184 |
| 10.11 Defocus Detection | 185 |
| 10.12 PIR Alarm | 185 |
| Chapter 11 VCA Search | 186 |
| 11.1 Face Search | 186 |
| 11.2 Behavior Search | 187 |
| 11.3 Plate Search | 189 |
| 11.4 People Counting | 190 |
| 11.5 Heat Map | 191 |
| 11.6 Advanced Search | 193 |
| Chapter 12 Network Settings | 195 |
| 12.1 Configuring General Settings | 195 |
| 12.2 Configuring Advanced Settings | 197 |
| 12.2.1 Configuring Hik-Connect | 197 |
| 12.2.2 Configuring DDNS | 199 |
| 12.2.3 Configuring NTP Server | 200 |
| 12.2.4 Configuring SNMP | 201 |
| 12.2.5 Configuring More Settings | 202 |
| 12.2.6 Configuring HTTPS Port | 203 |
| 12.2.7 Configuring Email | 205 |
| 12.2.8 Configuring NAT | 207 |
| 12.2.9 Configuring Virtual Host | |
| 12.3 Checking Network Traffic | 210 |

| 12.4 Configuring Network Detection | 212 |
|--|-----|
| 12.4.1 Testing Network Delay and Packet Loss | 212 |
| 12.4.2 Exporting Network Packet | 212 |
| 12.4.3 Checking the Network Status | 213 |
| 12.4.4 Checking Network Statistics | 214 |
| Chapter 13 RAID | 216 |
| 13.1 Configuring Array | 216 |
| 13.1.2 Enable RAID | 217 |
| 13.1.3 One-touch Configuration | 218 |
| 13.1.4 Manually Creating Array | 219 |
| 13.2 Rebuilding Array | 222 |
| 13.2.2 Automatically Rebuilding Array | 222 |
| 13.2.3 Manually Rebuilding Array | 223 |
| 13.3 Deleting Array | 225 |
| 13.4 Checking and Editing Firmware | 226 |
| Chapter 14 HDD Management | 227 |
| 14.1 Initializing HDDs | 227 |
| 14.2 Managing Network HDD | 229 |
| 14.3 Managing eSATA | 231 |
| 14.4 Managing HDD Group | 232 |
| 14.4.1 Setting HDD Groups | 232 |
| 14.4.2 Setting HDD Property | 233 |
| 14.5 Configuring Quota Mode | 235 |
| 14.6 Configuring Disk Clone | 237 |
| 14.7 Checking HDD Status | 239 |
| 14.8 HDD Detection | 241 |
| 14.9 Configuring HDD Error Alarms | 243 |
| Chapter 15 Camera Settings | 244 |
| 15.1 Configuring OSD Settings | 244 |
| 15.2 Configuring Privacy Mask | 245 |
| 15.3 Configuring Video Parameters | 247 |
| Chapter 16 NVR Management and Maintenance | 248 |
| 16.1 Viewing System Information | 248 |
| 16.2 Searching & Exporting Log Files | 249 |
| 16.3 Importing/Exporting IP Camera Info | 251 |

| 16.4 Importing/Exporting Configuration Files | 252 |
|--|-----|
| 16.5 Upgrading System | 253 |
| 16.5.1 Upgrading by Local Backup Device | 253 |
| 16.5.2 Upgrading by FTP | 253 |
| 16.6 Restoring Default Settings | 255 |
| Chapter 17 Others | 256 |
| 17.1 Configuring RS-232 Serial Port | 256 |
| 17.2 Configuring General Settings | 257 |
| 17.3 Configuring DST Settings | 259 |
| 17.4 Configuring More Settings | 260 |
| 17.5 Managing User Accounts | 261 |
| 17.5.1 Adding a User | 261 |
| 17.5.2 Deleting a User | 264 |
| 17.5.3 Editing a User | 264 |
| Chapter 18 Appendix | 267 |
| 18.1 Specifications | 267 |
| 18.1.1 DS-9600NI-I8 | 267 |
| 18.1.2 DS-9600NI-I16 | 269 |
| 18.1.3 DS-8600NI-I8 | 271 |
| 18.1.4 DS-7600NI-I2 | 273 |
| 18.1.5 DS-7600NI-I2/P | 275 |
| 18.1.6 DS-7700NI-I4 | 277 |
| 18.1.7 DS-7700NI-I4/P | 279 |
| 18.1.8 DS-8600NI-K8 | 280 |
| 18.1.9 DS-7700NI-K4 | 283 |
| 18.1.10 DS-7700NI-K4/P | 285 |
| 18.1.11 DS-7600NI-K2 | 287 |
| 18.1.12 DS-7600NI-K2/P | 289 |
| 18.1.13 DS-7600NI-K1 | 291 |
| 18.1.14 DS-7604NI-K1/4P | 293 |
| 18.2 Glossary | 295 |
| 18.3 Troubleshooting | 296 |
| 18.4 Summary of Changes | 304 |
| Version 3.4.92 | 304 |
| Version 3.4.91 | 304 |

| | Version 3.4.90 | .304 |
|----|--|------|
| | Version 3.4.80 | .304 |
| | Version 3.4.70 | .305 |
| | Version 3.4.6 | .305 |
| | Version 3.4.2 | .305 |
| | Version 3.3.9 | .306 |
| | Version 3.3.7 | .306 |
| | Version 3.3.6 | .306 |
| | Version 3.3.4 | .307 |
| 18 | .5 List of Compatible IP Cameras | .308 |
| | 18.5.1 List of Hikvision IP Cameras | .308 |
| | 18.5.2 List of Third-party IP Cameras | .318 |
| | 18.5.3 List of IP Cameras Connected to PoE by Long Network Cable (100 - 300 m) | .322 |

Chapter 1 Introduction

1.1 Front Panel

1.1.1 DS-9600NI Series




Figure 1-1 DS-9600NI-I8 Series




Figure 1-2 DS-9600NI-I16 Series

Table 1-1 Panel Description

| No. | Name | | Function Description |
|-----|----------------------|--------|--|
| | | ALARM | Turns red when a sensor alarm is detected. |
| | | READY | Turns blue when the device is functioning properly. |
| | | STATUS | Turns blue when device is controlled by an IR remote. |
| | | | Turns red when controlled by a keyboard and purple when IR remote and keyboard is used at the same time. |
| 1 | Status | HDD | Flickers red when data is being read from or written to HDD. |
| | Indicators | MODEM | Reserved for future usage. |
| | | Tx/Rx | Flickers blue when network connection is functioning properly. |
| | | GUARD | Turns blue when the device is in armed status; at this time, an alarm is enabled when an event is detected. |
| | | | Turns off when the device is unarmed. The arm/disarm status can be changed by pressing and holding on the ESC button for more than 3 seconds in live view mode. |
| 2 | IR Receiver | | Receiver for IR remote control. |
| 3 | Front Panel | Lock | Locks or unlocks the panel by the key. |
| 4 | DVD-R/W | | Slot for DVD-R/W disk. |
| | Alphanumeric Buttons | | Switches to the corresponding channel in live view or PTZ control mode. |
| | | | Inputs numbers and characters in edit mode. |
| 5 | | | Switches between different channels in playback mode. |
| | | | Turns blue when the corresponding channel is recording; turns red when the channel is in network transmission status; turns pink when the channel is recording and transmitting. |

| No. | Name | | Function Description |
|-----|-------------------|---------------------|--|
| 6 | USB Interfaces | | Universal Serial Bus (USB) ports for additional devices such as USB mouse and USB Hard Disk Drive (HDD). |
| | | ESC | Returns to the previous menu. |
| | | | Presses for arming/disarming the device in live view mode. |
| | | REC/SHOT | Enters the Manual Record settings menu. |
| | | | Presses this button followed by a numeric button to call a PTZ preset in PTZ control settings. |
| | | | Turns audio on/off in the playback mode. |
| | | PLAY/AUTO | Enters the playback mode. |
| | | | Automatically scans in the PTZ control menu. |
| | Composite Keys | ZOOM+ | Zooms in the PTZ camera in the PTZ control setting. |
| | | A/FOCUS+ | Adjusts focus in the PTZ Control menu. |
| 7 | | | Switches between input methods (upper and lower case alphabet, symbols and numeric input). |
| | | | Edits text fields. When editing text fields, it also deletes the character in front of the cursor. |
| | | | Checks the checkbox in the checkbox fields. |
| | | EDIT/IRIS+ | Adjusts the iris of the camera in PTZ control mode. |
| | | | Generates video clips for backup in playback mode. |
| | | | Enters/exits the folder of USB device and eSATA HDD. |
| | | MAIN/SPOT/Z OOM- | Switches between main and spot output. |
| | | | Zooms out the image in PTZ control mode. |
| | | F1/ LIGHT | Selects all items on the list when used in a list field. |

| No. | Name | | Function Description |
|-----|--------------------|-------------|---|
| | | | Turns on/off PTZ light (if applicable) in PTZ control mode. |
| | | | Switches between play and reverse play in playback mode. |
| | | | Cycles through tab pages. |
| | | F2/ AUX | Switches between channels in synchronous playback mode. |
| | | | Returns to the Main menu (after successful login). |
| | | MENU/WIPER | Presses and holds the button for five seconds to turn off audible key beep. |
| | | • | Starts wiper (if applicable) in PTZ control mode. |
| | PREV/FOCU | | Shows/hides the control interface in playback mode. |
| | | DDEN/EOCHS | Switches between single screen and multi-screen mode. |
| | | PREV/POCOS- | Adjusts the focus in conjunction with the A/FOCUS+ button in PTZ control mode. |
| | | | Enters the PTZ Control mode. |
| | | PTZ/IRIS- | Adjusts the iris of the PTZ camera in PTZ control mode. |
| | | | Navigates between different fields and items in menus. |
| | Control Buttons | | In the playback mode, use the Up and Down buttons to speed up and slow down recorded video. Use the Left and Right buttons to select the next and previous video files. |
| 8 | | | Cycles through channels in live view mode. |
| | | | Controls the movement of the PTZ camera in PTZ control mode. |
| | | | Confirms selection in any of the menu modes. |
| | | | Checks the checkbox fields. |
| | | | Plays or pauses the video playing in playback |

| No. | Name | | Function Description |
|-----|---------------------|-----|---|
| | | | mode. |
| | | | Advances the video by a single frame in single-frame playback mode. |
| | | | Stops/starts auto switch in auto-switch mode. |
| | JOG SHUTTLE Control | | Moves the active selection up and down in a menu. |
| 0 | | | Cycles through different channels in live view mode. |
| 9 | | | Jumps 30s forward/backward in video files in the playback mode. |
| | | | Controls the movement of the PTZ camera in PTZ control mode. |
| 10 | POWER ON/ | OFF | Long press the button for more than 3 seconds to turn on/off the NVR. |

1.1.2 DS-8600NI-I8 Series




Table 1-2 Description of Control Panel Buttons

| No. | Name | 14516 1 2 5 6 5 6 1 | Function Description |
|-----|----------------------|---------------------|--|
| | | ALARM | Turns red when a sensor alarm is detected. |
| | | READY | Turs blue when the device is functioning properly. |
| | | | Turns blue when device is controlled by an IR remote. |
| | | STATUS | Turns red when controlled by a keyboard and purple when IR remote and keyboard is used at the same time. |
| 1 | Status | HDD | Flickers red when data is being read from or written to HDD. |
| | Indicators | MODEM | Reserved for future usage. |
| | | Tx/Rx | Flickers blue when network connection is functioning properly. |
| | | | Turns blue when the device is in armed status; at this time, an alarm is enabled when an event is detected. |
| | | GUARD | Turns off when the device is unarmed. The arm/disarm status can be changed by pressing and holding on the ESC button for more than 3 seconds in live view mode. |
| 2 | IR Receiver | | Receiver for IR remote |
| 3 | DVD-R/W | | Slot for DVD-R/W. |
| | | | Switches to the corresponding channel in live view or PTZ control mode. |
| | | | Inputs numbers and characters in edit mode. |
| 4 | Alphanumeric Buttons | | Switches between different channels in playback mode. |
| | | | Turns blue when the corresponding channel is recording; turns red when the channel is in network transmission status; turns pink when the channel is recording and transmitting. |
| 5 | USB Interfaces | | Universal Serial Bus (USB) ports for additional devices such as USB mouse and USB Hard Disk |

| No. | Name | | Function Description |
|-----|-------------------|-------------|--|
| | | | Drive (HDD). |
| | | ESC | Returns to the previous menu. |
| | | | Presses for arming/disarming the device in live view mode. |
| | | | Enters the Manual Record settings menu. |
| | | REC/SHOT | Presses this button followed by a numeric button to call a PTZ preset in PTZ control settings. |
| | | | Turns audio on/off in the playback mode. |
| | | DI AV/ALITO | Enters the playback mode. |
| | | PLAY/AUTO | Automatically scans in the PTZ control menu. |
| | | ZOOM+ | Zooms in the PTZ camera in the PTZ control setting. |
| | | | Adjusts focus in the PTZ Control menu. |
| | Composite Keys | A/FOCUS+ | Switches between input methods (upper and lower case alphabet, symbols and numeric input). |
| 6 | | • | Edits text fields. When editing text fields, it also deletes the character in front of the cursor. |
| | | | Checks the checkbox in the checkbox fields. |
| | | | Adjusts the iris of the camera in PTZ control mode. |
| | | | Generates video clips for backup in playback mode. |
| | | | Enters/exits the folder of USB device and eSATA HDD. |
| | | | Switches between main and spot output. |
| | | | Zooms out the image in PTZ control mode. |
| | | | Selects all items on the list when used in a list field. |
| | | | Turns on/off PTZ light (if applicable) in PTZ control mode. |
| | | | Switches between play and reverse play in |

| No. | Name | | Function Description |
|-----|--------------------|-------------|---|
| | | | playback mode. |
| | | | Cycles through tab pages. |
| | | F2/ AUX | Switches between channels in synchronous playback mode. |
| | | | Returns to the Main menu (after successful login). |
| | | MENU/WIPER | Presses and holds the button for five seconds to turn off audible key beep. |
| | | | Starts wiper (if applicable) in PTZ control mode. |
| | | | Shows/hides the control interface in playback mode. |
| | | DDEV/EOCUS | Switches between single screen and multi-screen mode. |
| | | PREV/FOCUS- | Adjusts the focus in conjunction with the A/FOCUS+ button in PTZ control mode. |
| | | | Enters the PTZ Control mode. |
| | | PTZ/IRIS- | Adjusts the iris of the PTZ camera in PTZ control mode. |
| | | | Navigates between different fields and items in menus. |
| | | DIRECTION | In the playback mode, use the Up and Down buttons to speed up and slow down recorded video. Use the Left and Right buttons to select the next and previous video files. |
| | | | Cycles through channels in live view mode. |
| 7 | Control Buttons | | Controls the movement of the PTZ camera in PTZ control mode. |
| | | | Confirms selection in any of the menu modes. |
| | | ENTER | Checks the checkbox fields. |
| | | | Plays or pauses the video playing in playback mode. |
| | | | Advances the video by a single frame in single-frame playback mode. |

| No. | Name | | Function Description |
|-----|---------------------|--|---|
| | | | Stops/starts auto switch in auto-switch mode. |
| | JOG SHUTTLE Control | | Moves the active selection up and down in a menu. |
| 0 | | | Cycles through different channels in live view mode. |
| 8 | | | Jumps 30s forward/backward in video files in the playback mode. |
| | | | Controls the movement of the PTZ camera in PTZ control mode. |
| 9 | POWER ON/OFF | | Power on/off switch. |

1.1.3 DS-8600NI-K8 and DS-7700NI Series




Figure 1-4 DS-8600NI-K8 Series




Figure 1-5 DS-7700NI Series

Table 1-3 Panel Description

| No. | Name | | Function Description |
|-----|---------------|-------|---|
| | | POWER | Turns green when NVR is powered up. |
| 1 | Status | HDD | Blinks red when HDD is reading/writing. |
| _ | Indicators | Tx/Rx | Blinks green when network connection is functioning normally. |
| | | | The Enter button is used to confirm selection in menu mode; or used to check checkbox fields and ON/OFF switch. |
| | | | In playback mode, it can be used to play or pause the video. |
| 2 | ENTER | | In single-frame play mode, pressing the Enter button will play the video by a single frame. |
| | | | In auto sequence view mode, the buttons can be used to pause or resume auto sequence. |
| | | | The Enter button is used to confirm selection in menu mode; or used to check checkbox fields and ON/OFF switch. |
| | 3 DIRECTION | | In menu mode, the direction buttons are used to navigate between different fields and items and select setting parameters. |
| 3 | | | In playback mode, the Up and Down buttons are used to speed up and slow down record playing, and the Left and Right buttons are used to move the recording 30s forwards or backwards. |
| | | | In the image setting interface, the up and down button can adjust the level bar of the image parameters. |
| | | | In live view mode, these buttons can be used to switch channels. |
| 4 | Back | | Back to the previous menu. |
| 5 | POWER ON/OFF | | Power on/off switch. |
| 6 | MENU | | Access the main menu interface. |
| 7 | USB Interface | | Universal Serial Bus (USB) ports for additional devices such as USB mouse and USB Hard Disk Drive (HDD). |

1.1.4 DS-7600NI Series




Figure 1-6 DS-7600NI Series

Table 1-4 Panel Description

| No. | Name | Connections | |
|-----|---------------|---|--|
| 1 | POWER | Turns green when NVR is powered up. | |
| 2 | HDD | Flickers red when data is being read from or written to HDD. | |
| 3 | Tx/Rx | Flickers blue when network connection is functioning properly. | |
| 4 | USB Interface | Universal Serial Bus (USB) port for additional devices such as USB mouse and USB Hard Disk Drive (HDD). | |

1.2 IR Remote Control Operations

The NVR may also be controlled with the included IR remote control, shown in Figure 1-7.



Batteries (2×AAA) must be installed before operation.

The IR Remote is set at the factory to control the NVR (using default Device ID# 255) without any additional steps. Device ID# 255 is the default universal device identification number shared by the NVRs. You may also pair an IR Remote to a specific NVR by changing the Device ID#, as follows:

Pairing (Enabling) the IR Remote to a Specific NVR (optional)

You can pair an IR Remote to a specific Hikvision NVR by creating a user-defined Device ID#. This feature is useful when using multiple IR Remotes and NVRs.

On the NVR:

Step 1 Go to General > More Settings.

Step 2 Type a number (255 digits maximum) into the Device No. field.

Step 3 On the IR Remote:

Step 4 Press the DEV button.

Step 5 Use the Number buttons to enter the Device ID# that was entered into the NVR.

Step 6 Press Enter button to accept the new Device ID#.




Figure 1-7 Remote Control

Unpairing (Disabling) an IR Remote from a NVR

To unpair an IR Remote from a NVR so that the unit cannot control any NVR functions, proceed as follows:

Press the DEV key on the IR Remote. Any existing Device ID# will be erased from the unit's memory and it will no longer function with the NVR.



(Re)-enabling the IR Remote requires pairing to a NVR. See "Pairing the IR Remote to a Specific NVR (optional)," above.

The keys on the remote control closely resemble the ones on the front panel. See the table 1.4.

Table 1-5 IR Remote Functions

| No. | Name | Function Description | | |
|-------|--------|--|--|--|
| _ ,,, | | To Turn Power On: | | |
| | | | | |
| | | - If User Has Not Changed the Default NVR Device ID# (255): | | |
| | | 1. Press Power On/Off button (1). | | |
| | | - If User Has Changed the NVR Device ID#: | | |
| | | 1. Press DEV button. | | |
| | | 2. Press Number buttons to enter user-defined Device ID#. | | |
| | | 3. Press Enter button. | | |
| | | 4. Press Power button to start device. | | |
| | | 4. Press rower button to start device. | | |
| | | To Turn NVR Off: | | |
| | | - If User Is Logged On: | | |
| | | 1. Hold Power On/Off button (1) down for five seconds to display the "Yes/No" verification prompt. | | |
| | | 2. Use Up/Down Arrow buttons (12) to highlight desired selection. | | |
| 1 | POWER | 3. Press Enter button (12) to accept selection. | | |
| 1 | ON/OFF | - If User Is <i>Not</i> Logged On: | | |
| | | 1. Hold Power On/Off button (1) down for five seconds to display the user name/password prompt. | | |
| | | 2. Press the Enter button (12) to display the on-screen keyboard. | | |
| | | 3. Input the user name. | | |
| | | 4. Press the Enter button (12) to accept input and dismiss the on-screen keyboard. | | |
| | | 5. Use the Down Arrow button (12) to move to the "Password" field. | | |
| | | 6. Input password (use on-screen keyboard or numeric buttons (3) for numbers). | | |
| | | 7. Press the Enter button (12) to accept input and dismiss the on-screen keyboard. | | |
| | | 8. Press the OK button on the screen to accept input and display the Yes/No" verification prompt (use Up/Down Arrow buttons (12) to move between fields) | | |
| | | 9. Press Enter button (12) to accept selection. | | |
| L | | | | |

| | | User name/password prompt depends on NVR is configuration. See "System Configuration" section. |
|----|-----------|---|
| 2 | DEV | Enable IR Remote: Press DEV button, enter NVR Device ID# with number keys, press Enter to pair unit with the NVR |
| 2 | DEV | Disable IR Remote: Press DEV button to clear Device ID#; unit will no longer be paired with the NVR |
| 3 | Numerals | Switch to the corresponding channel in Live View or PTZ Control mode |
| | | Input numbers in Edit mode |
| 4 | FDIT | Delete characters before cursor |
| 4 | EDIT | Check the checkbox and select the ON/OFF switch |
| | | Adjust focus in the PTZ Control menu |
| 5 | A | Switch on-screen keyboards (upper and lower case alphabet, symbols, and numerals) |
| | REC | Enter Manual Record setting menu |
| 6 | | Call a PTZ preset by using the numeric buttons in PTZ control settings |
| | | Turn audio on/off in Playback mode |
| 7 | PLAY | Go to Playback mode |
| , | PLAT | Auto scan in the PTZ Control menu |
| 8 | INFO | Reserved |
| 9 | VOIP | Switches between main and spot output |
| | | Zooms out the image in PTZ control mode |
| | | Return to Main menu (after successful login) |
| 10 | MENU | N/A |
| | | Show/hide full screen in Playback mode |
| 12 | | Navigate between fields and menu items |
| | DIRECTION | Use Up/Down buttons to speed up/slow down recorded video, and Left/Right buttons to advance/rewind 30 secs in Playback mode |
| | | Cycle through channels in Live View mode |
| | | |

| | Control PTZ camera movement in PTZ control mode | |
|-------------|--|--|
| | Confirm selection in any menu mode | |
| | Checks checkbox | |
| ENTER | Play or pause video in Playback mode | |
| | Advance video a single frame in single-frame Playback mode | |
| | Stop/start auto switch in auto-switch mode | |
| PTZ | Enter PTZ Control mode | |
| | Go back to previous screen | |
| ESC | N/A | |
| RESERVED | Reserved | |
| | Select all items on a list | |
| F1 | N/A | |
| | Switch between play and reverse play in Playback mode | |
| PTZ Control | Adjust PTZ camera iris, focus, and zoom | |
| F2 | Cycle through tab pages | |
| FZ | Switch between channels in Synchronous Playback mode | |
| | PTZ ESC RESERVED | |

Troubleshooting Remote Control:



Make sure you have installed batteries properly in the remote control. And you have to aim the remote control at the IR receiver in the front panel.

If there is no response after you press any button on the remote, follow the procedure below to troubleshoot.

- Step 1 Go to Menu > Settings > General > More Settings by operating the front control panel or the mouse.
- Step 2 Check and remember NVR ID#. The default ID# is 255. This ID# is valid for all the IR remote controls.
- Step 3 Press the DEV button on the remote control.
- Step 4 Enter the NVR ID# you set in step 2.
- Step 5 Press the ENTER button on the remote.

If the Status indicator on the front panel turns blue, the remote control is operating properly. If the Status indicator does not turn blue and there is still no response from the remote, please check the following:

- Batteries are installed correctly and the polarities of the batteries are not reversed.
- Batteries are fresh and not out of charge.
- IR receiver is not obstructed.
- No fluorescent lamp is used nearby

If the remote still can't function properly, please change a remote and try again, or contact the device provider.

1.3 USB Mouse Operation

A regular 3-button (Left/Right/Scroll-wheel) USB mouse can also be used with this NVR. To use a USB mouse:

- Step 1 Plug USB mouse into one of the USB interfaces on the front panel of the NVR.
- Step 2 The mouse should automatically be detected. If in a rare case that the mouse is not detected, the possible reason may be that the two devices are not compatible, please refer to the recommended the device list from your provider.

The operation of the mouse:

Table 1-6 Description of the Mouse Control

| Name | Action | Description |
|--------------|-------------------|---|
| | Single-Click | Live view: Select channel and show the quick set menu. Menu: Select and enter. |
| Left-Click | Double-Click | Live view: Switch between single-screen and multi-screen. |
| Lett-Click | Click and Drag | PTZ control: pan, tilt and zoom. Video tampering, privacy mask and motion detection: Select target area. Digital zoom-in: Drag and select target area. Live view: Drag channel/time bar. |
| Right-Click | Single-Click | Live view: Show menu. Menu: Exit current menu to upper level menu. |
| Scroll-Wheel | Scrolling up | Live view: Previous screen. Menu: Previous item. |
| | Scrolling down | Live view: Next screen. Menu: Next item. |

1.4 Input Method Description




Figure 1-8 Soft Keyboard (1)



Figure 1-9 Soft Keyboard (2)

Description of the buttons on the soft keyboard:

Table 1-7 Description of the Soft Keyboard Icons



1.5 Rear Panel

1.5.1 DS-9600NI and DS-8600NI Series




Figure 1-10 DS-9600NI-I8 and DS-8600NI Series




Figure 1-11 DS-9600NI-I16 Series

Table 1-8 Panel Description

| No. | Name | Description | | |
|-----|------------------------|---|--|--|
| 1 | LAN1/LAN2 Interface | 2 RJ-45 10/100/1000 Mbps self-adaptive Ethernet interfaces provided. | | |
| 2 | LINE IN | RCA connector for audio input. | | |
| 3 | AUDIO OUT | 2 RCA connectors for audio output. | | |
| 4 | HDMI1/HDMI2 | HDMI video output connector. | | |
| 5 | VGA1/VGA2 | DB9 connector for VGA output. Display local video output and menu. | | |
| 6 | USB 3.0 interface | Universal Serial Bus (USB) ports for additional devices such as USB mouse and USB Hard Disk Drive (HDD). | | |
| 7 | RS-232 Interface | Connector for RS-232 devices. | | |
| 8 | eSATA | Connects external SATA HDD, CD/DVD-RM. | | |
| 9 | Controller Port | D+, D- pin connects to Ta, Tb pin of controller. For cascading devices, the first NVR's D+, D- pin should be connected with the D+, D- pin of the next NVR. | | |
| J | ALARM IN | Connector for alarm input. | | |
| | ALARM OUT | Connector for alarm output. | | |
| 10 | 100 to 240 VAC | 100 to 240 VAC power supply. | | |
| 11 | Power Switch | Switch for turning on/off the device. | | |
| 12 | GROUND | Ground (needs to be connected when NVR starts up). | | |

1.5.2 DS-7600NI Series

DS-7600NI-I2 (/P) and DS-7600NI-K2 (/P)




Figure 1-12 DS-7600NI-I2 and DS-7600NI-K2 Series




Figure 1-13 DS-7600NI-I2/8P and DS-7600NI-K2/8P Series



The DS-7616NI-I2/16P and DS-7632NI-I2/16P provide 16 network Interfaces with PoE function.

Table 1-9 Panel Description

| No. | Name | Description | |
|-----|--------------------------------------|--|--|
| 1 | Audio In | RCA connector for audio input. | |
| 2 | Audio Out | RCA connector for audio output. | |
| 3 | VGA Interface | DB9 connector for VGA output. Display local video output and menu. | |
| 4 | HDMI Interface | HDMI video output connector. | |
| 5 | ALARM IN | Connector for alarm input. | |
| | ALARM OUT | Connector for alarm output. | |
| 6 | LAN Network Interface | 1 10/100/1000 Mbps self-adaptive Ethernet interface | |
| 7 | USB Interface | Universal Serial Bus (USB 3.0) ports for additional devices such as USB mouse and USB Hard Disk Drive (HDD). | |
| 8 | Ground | Ground (needs to be connected when NVR starts up). | |
| 9 | Power Supply | 12 VDC power supply for DS-7600NI-I4 and DS-7600NI-K4, and 100 to 240 VAC for DS-7600NI-I4/P and DS-7600NI-K4/P. | |
| 10 | Power Switch | Switch for turning on/off the device. | |
| 11 | Network Interfaces with PoE function | Network interfaces for the cameras and to provide power over Ethernet. | |

DS-7600NI-K1 and DS-7600NI-K1/4P




Figure 1-14 DS-7600NI-K1 Series




Figure 1-15 DS-7604NI-K1/4P Series

Table 1-10 Panel Description

| No. | Name | Description | |
|-----|--------------------------------------|--|--|
| 1 | Network Interfaces with PoE function | Network interfaces for the cameras and to provide power over Ethernet. | |
| 2 | Audio In | RCA connector for audio input. | |
| 3 | Audio Out | RCA connector for audio output. | |
| 4 | VGA Interface | DB9 connector for VGA output. Display local video output and menu. | |
| 5 | HDMI Interface | HDMI video output connector. | |
| 6 | LAN Network Interface | 1 10/100/1000 Mbps self-adaptive Ethernet interface for DS-7600NI-K1; 1 100 Mbps full-duplex Ethernet interface for DS-7600NI-K1/4P. | |
| 7 | USB Interface | Universal Serial Bus (USB) ports for additional devices such as USB mouse and USB Hard Disk Drive (HDD). | |
| 9 | Power Supply | 12VDC power supply for DS-7600NI-K1 and 48 VDC power supply for DS-7600NI-K1/4P | |

| 10 | Ground | Ground (needs to be connected when NVR starts |
|----|--------|---|
| | | up). |

1.5.3 DS-7700NI Series




Figure 1-16 DS-7700NI-I4 and DS-7700NI-K4 Series




Figure 1-17 DS-7700NI-I4/16P and DS-7700NI-K4/16P Series



The DS-7708NI-I4/8P and DS-7708NI-K4/8P provides 8 network Interfaces with PoE function.

Table 1-11 Panel Description

| No. | Name | Description | |
|-----|-------------------|---|--|
| 1 | LAN Interface | 1 network interface provided for DS-7700NI-I4/P and DS-7700NI-K4/P, and 2 network interfaces for DS-7700NI-I4 and DS-7700NI-K4. | |
| 2 | AUDIO OUT | RCA connector for audio output. | |
| 3 | LINE IN | RCA connector for audio input. | |
| 4 | HDMI | HDMI video output connector. | |
| 5 | USB 3.0 interface | Universal Serial Bus (USB) ports for additional devices such as USB mouse and USB Hard Disk Drive (HDD). | |
| 6 | RS-232 Interface | Connector for RS-232 devices. | |

| 7 | VGA | DB9 connector for VGA output. Display local video output and menu. | |
|----|---|--|--|
| 8 | RS-485 Interface | Half-duplex connector for RS-485 devices. | |
| 9 | ALARM IN | Connector for alarm input. | |
| | ALARM OUT | Connector for alarm output. | |
| 10 | GROUND | Ground (needs to be connected when NVR starts up). | |
| 11 | AC 100V ~ 240V | 100V to 240VAC power supply. | |
| 12 | Power Switch | Switch for turning on/off the device. | |
| 13 | Network Interfaces with PoE function (supported by DS-7700NI-I4/P and DS-7700NI-K4/P) | Network interfaces for the cameras and to provide power over Ethernet. | |

Chapter 2 Getting Started

2.1 Device Startup and Activation

2.1.1 Starting Up and Shutting Down the NVR

Purpose:

Proper startup and shutdown procedures are crucial to expanding the life of the NVR.

Before you start:

Check that the voltage of the extra power supply is the same with the NVR's requirement, and the ground connection is working properly.

Starting up the NVR:

- Step 1 Check the power supply is plugged into an electrical outlet. It is HIGHLY recommended that an Uninterruptible Power Supply (UPS) be used in conjunction with the device. The Power indicator LED on the front panel should be red, indicating the device gets the power supply.
- Step 2 Press the POWER button on the front panel. The Power indicator LED should turn blue indicating that the unit begins to start up.
- Step 3 After startup, the Power indicator LED remains blue. A splash screen with the status of the HDD appears on the monitor. The row of icons at the bottom of the screen shows the HDD status. 'X' means that the HDD is not installed or cannot be detected.

Shutting down the NVR

Steps:

There are two proper ways to shut down the NVR.

OPTION 1: Standard shutdown

Step 1 Enter the Shutdown menu.

Menu > Shutdown



Figure 2-1 Shutdown Menu

Step 2 Click the **Shutdown** button.

Step 3 Click the Yes button.

OPTION 2: By operating the front panel

Step 1 Press and hold the POWER button on the front panel for 3 seconds.

Step 2 Enter the administrator's username and password in the dialog box for authentication.

Step 3 Click the Yes button.



Do not press the POWER button again when the system is shutting down.

Rebooting the NVR

In the Shutdown menu, you can also reboot the NVR.

Step 1 Enter the Shutdown menu by clicking Menu > Shutdown.

Step 2 Click the Logout button to lock the NVR or the Reboot button to reboot the NVR.

2.1.2 Activating Your Device

Purpose:

For the first-time access, you need to activate the device by setting an admin password. No operation is allowed before activation. You can also activate the device via Web Browser, SADP or Client Software.

Step 1 Input the same password in the text field of **Create New Password** and **Confirm New Password**.



Figure 2-2 Settings Admin Password



WARNING

We highly recommend you create a strong password of your own choosing (Using a minimum of 8 characters, including at least three of the following categories: upper case letters, lower case letters, numbers, and special characters.) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

- Step 2 Click **OK** to save the password and activate the device.
- Step 3 When the device is activated, the system pops up the message box to remind you to remember the password. And you can click **Yes** to continue to export the GUID file for the future password resetting.



Figure 2-3 Export GUID File Remind

Step 4 Insert the U flash disk to your device, and export the GUID file to the U flash disk in the Reset Password interface. Please refer to Chapter 2.1.5 Resetting Your Password for the instructions of password resetting.



Figure 2-4 Export GUID File



Please keep your GUID file properly for future password resetting.



If Admin's password is modified, the following menu pops up. Optionally, click the Yes button to duplicate the password to IP cameras that are connected with default protocol.



Figure 2-5 Attention Interface

2.1.3 Using the Unlock Pattern for Login

For the Admin user, you can configure the unlock pattern for device login.

Configuring the Unlock Pattern

Step 1 After the device is activated, you can enter the following interface to configure the device unlock pattern.




Figure 2-6 Set Unlock Pattern

Step 2 Use the mouse to draw a pattern among the 9 dots on the screen. Release the mouse when the pattern is done.



Figure 2-7 Draw the Pattern



Connect at least 4 dots to draw the pattern.

Each dot can be connected for once only.

Step 3 Draw the same pattern again to confirm it. When the two patterns match, the pattern is configured successfully.




Figure 2-8 Confirm the Pattern



If the two patterns are different, you must set the pattern again.




Figure 2-9 Re-set the Pattern

Logging in via Unlock Pattern



- Only the *admin* user has the permission to unlock the device.
- Please configure the pattern first before unlocking. Please refer to Configuring the Unlock Pattern

Step 1 Right click the mouse on the screen and select the menu to enter the interface as shown in Figure 2.8.




Figure 2-10 Draw the Unlock Pattern

Step 2 Draw the pre-defined pattern to unlock to enter the menu operation.

NOTE

- If you have forgotten your pattern, you can select the Forget My Pattern or Switch User option to enter the normal login dialog box.
- When the pattern you draw is different from the pattern you have configured, you should try again.
- If you have drawn the wrong pattern for more than 5 times, the system will switch to the normal login mode automatically.



Figure 2-11 Normal Login Dialog Box

2.1.4 Login and Logout

User Login

Purpose:

If NVR has logged out, you must login the device before operating the menu and other functions.

Step 1 Select the User Name in the dropdown list.



Figure 2-12 Login Interface

Step 2 Input password.

Step 3 Click OK to log in.



When you forget the password of the admin, you can click **Forget Password** to reset the password. Please refer to Chapter 2.1.5 Resetting Your Password for details.



In the Login dialog box, if you enter the wrong password 7 times, the current user account will be locked for 60 seconds.

User Logout

Purpose:

After logging out, the monitor turns to the live view mode and if you want to perform any operations, you need to enter user name and password log in again.

Step 1 Enter the Shutdown menu.

Menu > Shutdown



Figure 2-13 Logout

Step 2 Click Logout.



After you have logged out the system, menu operation on the screen is invalid. It is required to input a user name and password to unlock the system.

2.1.5 Resetting Your Password

When you forget the password of the admin, you can reset the password by importing the GUID file. The GUID file must be exported and saved in the local U flash disk after you have activated the device (refer to Chapter 2.1.2 Activating Your Device).

Step 1 On the user login interface, click **Forget Password** to enter the Reset Password interface.



Please insert the U flash disk stored with the GUID file to the NVR before resetting password.



Figure 2-14 Reset Password

Step 2 Select the GUID file from the U flash disk and click Import to import the file to the device.



If you have imported the wrong GUIE file for 7 times, you will be not allowed to reset the password for 30 minutes.

Step 3 After the GUID file is successfully imported, enter the reset password interface to set the new admin password. Refer to Chapter 2.1.2 Activating Your Device for details.

Step 4 Click OK to set the new password. You can export the new GUID file to the U flash disk for future password resetting.



When the new password is set, the original GUID file will be invalid. The new GUID file should be exported for future password resetting. You can also enter the User>User Management interface to edit the admin user and export the GUID file.

2.2 Using Wizard for Basic Configuration

By default, the Setup Wizard starts once the NVR has loaded, as shown in Figure 2-15.



Figure 2-15 Start Wizard Interface

Operating the Setup Wizard:

Step 1 The Setup Wizard can walk you through some important settings of the NVR. If you don't want to use the Setup Wizard at that moment, click the **Cancel** button. You can also choose to use the Setup Wizard next time by leaving the "Start wizard when the device starts?" checkbox checked.

Step 2 Click **Next** button to enter the date and time settings window, as shown in Figure 2-16.



Figure 2-16 Date and Time Settings

Step 3 After the time settings, click **Next** button which takes you back to the Network Setup Wizard window, as shown in the following figure.




Figure 2-17 Network Settings



Two self-adaptive 10M/100M/1000M network interfaces provided for DS-9600NI, DS-8600NI, DS-7700NI-I4 and DS-7700NI-K4, and two working modes are configurable: multi-address and network fault tolerance. And one self-adaptive 10M/100M/1000M network interface for DS-7600NI, DS-7700NI-I4/P and DS-7700NI-K4/P.

Step 4 Click **Next** button after you configured the basic network parameters. Enter the **Hik-Connect** interface to configure the parameters. Please refer to Chapter 12.2.1 Configuring Hik-Connect12.2.1 for detailed instructions.




Figure 2-18 Hik-Connect Settings

Step 5 Click **Next** button after you configured the basic network parameters. Then you will enter the **Advanced Network Parameter** interface. You can enable UPnP, DDNS and set other ports according to your need.



Figure 2-19 Advanced Network Parameters

Step 6 Click **Next** button after you configured the network parameters, which takes you to the RAID configuration window.



The RAID is supported by DS-9600NI-I8 and DS-9600NI-I16 series NVR only.



Figure 2-20 Array Management

Step 7 Click Next button to enter the Array Management window.




Figure 2-21 Array Management

Step 8 Click **Next** button after you configured the network parameters, which takes you to the **HDD Management** window, shown in Figure 2-22.



Figure 2-22 HDD Management

- Step 9 To initialize the HDD, click the **Init** button. Initialization removes all the data saved in the HDD.
- Step 10 Click Next button. You enter the Adding IP Camera interface.
- Step 11 Click **Search** to search the online IP Camera and the **Security** status shows whether it is active or inactive. Before adding the camera, make sure the IP camera to be added is in active status.

If the camera is in inactive status, you can click the inactive icon of the camera to set the password to activate it. You can also select multiple cameras from the list and click the **One-touch Activate** to activate the cameras in batch.

Click the Add to add the camera.



Figure 2-23 Search for IP Cameras



When you check the checkbox of **Enable H.265**, the NVR can automatically switch to the H.265 stream of IP camera (which supports H.265 video format) for the initial access.

Step 12 Click Next button. Configure the recording for the added IP Cameras.




Figure 2-24 Record Settings

Step 13 Click **OK** to complete the startup Setup Wizard.

2.3 Adding and Connecting the IP Cameras

2.3.1 Activating the IP Camera

Purpose:

Before adding the camera, make sure the IP camera to be added is in active status.

Step 1 Select the **Add IP Camera** option from the right-click menu in live view mode or click Menu> Camera> Camera to enter the IP camera management interface.

For the IP camera detected online in the same network segment, the **Password** status shows whether it is active or inactive.




Figure 2-25 IP Camera Management Interface

Step 2 Click the inactive icon of the camera to enter the following interface to activate it. You can also select multiple cameras from the list and click the **One-touch Activate** to activate the cameras in batch.




Figure 2-26 Activate the Camera

Step 3 Set the password of the camera to activate it.

Use Admin Password: when you check the checkbox, the camera (s) will be configured with the same admin password of the operating NVR.



Figure 2-27 Set New Password

Create New Password: If the admin password is not used, you must create the new password for the camera and confirm it.



<u>Strong Password recommended</u>—We highly recommend you create a strong password of your own choosing (Using a minimum of 8 characters, including at least three of the following categories: upper case letters, lower case letters, numbers, and special characters.) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Step 4 Click **OK** to finish the acitavting of the IP camera. And the security status of camera will be changed to **Active**.

2.3.2 Adding the Online IP Cameras

Purpose:

The main function of the NVR is to connect the network cameras and record the video got from it. So before you can get a live view or record of the video, you should add the network cameras to the connection list of the device.

Before you start:

Ensure the network connection is valid and correct. For detailed checking and configuring of the network, please see *Chapter Checking Network Traffic* and *Chapter Configuring Network Detection*.

Adding the IP Cameras

• OPTION 1:

Step 1 Click to select an idle window in the live view mode.

Step 2 Click the icon in the center of the windw to pop up the adding IP camera interface.



Figure 2-28 Icon of Adding IP Camera

Step 3 Select the detected IP camera and click the **Add** button to add it directly, and you can click the **Search** button to refresh the online IP camera manually.



Figure 2-29 Quick Adding IP Camera Interface

Or you can choose to custom add the IP camera by editing the parameters in the corresponding textfiled and then click the **Add** button to add it.

• OPTION 2:

Step 1 Select the **Add IP Camera** option from the right-click menu in live view mode or click Menu> Camera > Camera to enter the IP camera management interface.



Figure 2-30 Adding IP Camera Interface

- Step 2 The online cameras with same network segment will be detected and displayed in the camera list.
- Step 3 Select the IP camera from the list and click the button to add the camera. Or you can click the **One-touch Adding** button to add all cameras (with the same login password) from the list.



Make sure the camera to add has already been activated.

Step 4 (For the encoders with multiple channels only) check the **Channel Port** checkbox in the pop-up window, as shown in the following figure, and click **OK** to add multiple channels.



Figure 2-31 Selecting Multiple Channels

OPTION 3:

Step 1 On the IP Camera Management interface, click the **Custom Adding** button to pop up the Add IP Camera (Custom) interface.




Figure 2-32 Custom Adding IP Camera Interface

Step 2 You can edit the IP address, protocol, management port, and other information of the IP camera to be added.



If the IP camera to add has not been actiavated, you can activate it from the IP camera list on the camera management interface.

Step 3 (Optional) Check the checkbox of **Continue to Add** to add other IP cameras.

Step 4 Click **Add** to add the camera. The successfully added cameras are listed in the interface.

Refer to the following table for the description of the icons

Table 2-1 Description of Icons

| Icon | Explanation | Icon | Explanation |
|-----------|--|----------|---|
| | Edit basic parameters of the camera | • | Add the detected IP camera. |
| ^ | The camera is disconnected; you can click the icon to get the exception information of camera. | î | Delete the IP camera |
| | Play the live video of the connected camera. | | Advanced settings of the camera. |
| \$ | Upgrade the connected IP camera. | Security | Show the security status of the camera to be active/inactive or the password strength (strong/medium/weak/risk) |



For the added IP cameras, the Security status shows the security level of the password of camera: strong password, weak password and risk password.




Figure 2-33 Security Level of IP Camera's Password

Enabling the Password of IP Camera Visible

For the admin login user account, you can check the checkbox of **Show Password of IP Camera** to enable the show the passwords of the successfully added IP cameras in the list.

You must enter the admin password to confirm permission.



Figure 2-34 List of Added IP Cameras

Enabling the H.265 Stream Access

You can check the checkbox of **Enable H.265**, the NVR can automatically switch to the H.265 stream of IP camera (which supports H.265 video format) for the initial access.

2.3.3 Editing the Connected IP Cameras and Configuring Customized Protocols

After the adding of the IP cameras, the basic information of the camera lists in the page, you can configure the basic setting of the IP cameras.

Step 1 Click the icon to edit the parameters; you can edit the IP address, protocol and other parameters.



Figure 2-35 Edit the Parameters

Channel Port: If the connected device is an encoding device with multiple channels, you can choose the channel to connect by selecting the channel port No. in the dropdown list.

Step 2 Click **OK** to save the settings and exit the editing interface.

To edit advanced parameters:

Step 1 Drag the horizontal scroll bar to the right side and click the icon.



Figure 2-36 Network Configuration of the Camera

Step 2 You can edit the network information and the password of the camera.




Figure 2-37 Password Configuration of the Camera

Step 3 Click **OK** to save the settings and exit the interface.

Configuring the customized protocols

Purpose:

To connect the network cameras which are not configured with the standard protocols, you can configure the customized protocols for them.

Step 1 Click the **Protocol** button in the custom adding IP camera interface to enter the protocol management interface.




Figure 2-38 Protocol Management Interface

There are 16 customized protocols provided in the system, you can edit the protocol name; and choose whether to enable the sub-stream.

Step 2 Choose the protocol type of transmission and choose the transfer protocols.

NOTE

Before customizing the protocol for the network camera, you have to contact the manufacturer of the network camera to consult the URL (uniform resource locator) for getting main stream and sub-stream.

The format of the URL is: [Type]://[IP Address of the network camera]:[Port]/[Path].

Example: rtsp://192.168.1.55:554/ch1/main/av stream.

- Protocol Name: Edit the name for the custom protocol.
- Enable Substream: If the network camera does not support sub-stream or the sub-stream is not needed leave the checkbox empty.
- Type: The network camera adopting custom protocol must support getting stream through standard RTSP.
- **Transfer Protocol:** Select the transfer protocol for the custom protocol.
- **Port:** Set the port No. for the custom protocol.
- Path: Set the resource path for the custom protocol. E.g., ch1/main/av stream.

NOTE

The protocol type and the transfer protocols must be supported by the connected network camera.

After adding the customized protocols, you can see the protocol name is listed in the dropdown list, please refer to Figure 2-39.



Figure 2-39 Protocol Setting

Step 3 Choose the protocols you just added to validate the connection of the network camera.

2.3.4 Editing IP Cameras Connected to the PoE Interfaces



This chapter is only applicable for the following models: DS-7600NI-I2/P, DS-7700NI-I4/P, DS-7600NI-K2/P, DS-7700NI-K4/P and DS-7600NI-K1/4P series NVR.

The PoE interfaces enables the NVR system to pass electrical power safely, along with data, on Ethernet cabling to the connected network cameras.

Up to 4 network cameras can be connected to /4P models, 8 network cameras to /8P models, and 16 network cameras to /16P models. If you disable the PoE interface, you can also connect to the online network cameras. And the PoE interface supports the Plug-and-Play function.

Example:

For DS-7608NI-I2/8P, if you want to connect 6 network cameras via PoE interfaces and 2 online cameras, you must disable 2 PoE interfaces in the Edit IP Camera menu.

To add Cameras for NVR supporting PoE function:

Before you start:

Connect the network cameras via the PoE interfaces.

Step 1 Enter the Camera Management interface.

Menu> Camera> IP Camera



Figure 2-40 List of Connected Cameras



The cameras connecting to the PoE interface cannot be deleted in this menu.

Step 2 Click the 📝 button, and select the Adding Method in the drop-down list.

• **Plug-and-Play:** It means that the camera is connected to the PoE interface, so in this case, the parameters of the camera can't be edited. The IP address of the camera can only be

edited in the Network Configuration interface, see *Chapter 11.1 Configuring General* Settings for detailed information.



Figure 2-41 Edit IP Camera Interface - Plug-and-Play

• **Manual:** You can disable the PoE interface by selecting the manual while the current channel can be used as a normal channel and the parameters can also be edited.

Input the IP address, the user name and password of administrator manually, and click **OK** to add the IP camera.




Figure 2-42 Edit IP Camera Interface - Manual

2.3.5 Configuring PoE Interface

When it requires long-distance PoE transmission (100 to 300 m), you can configure the PoE channel to the long network cable mode.

Step 1 Enter the PoE Configuration interface.

Menu> Camera> Camera> PoE Configuration

Step 2 Click the radio button of each POE channel to switch and . You can click the radio button of **PoE Channel** to enable or disable the long network cable mode.

ON: Long-distance (100 - 300 meters) network transmissions via POE interface.

OFF: Short-distance (< 100 meters) network transmission via POE interface.



Figure 2-43 Configure PoE Interface

INOTE

- The PoE is enabled with the short network cable mode (OFF) by default.
- The bandwidth of IP camera connected to the PoE via long network cable (100 300 meters) cannot exceed 6 MP.
- The allowed max. long network cable may be less than 300 meters depending on different IP camera models and cable materials.
- When the transmission distance reaches 100 to 250 meters, you must use the CAT5E or CAT6 network cable to connect with the PoE interface.
- When the transmission distance reaches 250 to 300 meters, you must use the CAT6 network cable to connect with the PoE interface.
- Refer to the Appendix 18.5.3 List of IP Cameras Connected to PoE by Long Network Cable (100 - 300 m) for the list of IP cameras.

NOTE

You can check the connecting status and power information of POE channel on the interface.

Step 3 Click **Back** to finish the settings.

Chapter 3 Live View

3.1 Introduction of Live View

Live view shows you the video image getting from each camera in real time. The NVR automatically enters Live View mode when powered on. It is also at the very top of the menu hierarchy, thus pressing the ESC many times (depending on which menu you're on) brings you to the Live View mode.

Live View Icons

In the live view mode, there are icons at the upper-right of the screen for each channel, showing the status of the record and alarm in the channel, so that you can know whether the channel is recorded, or whether there are alarms occur as soon as possible.

Table 3-1 Description of Live View Icons

| Icons | Description | |
|---------------|--|--|
| <u>></u> | Alarm (video loss, video tampering, motion detection, VCA and sensor alarm) | |
| 88 | Record (manual record, schedule record, motion detection, VCA and alarm triggered record) | |
| <u>></u> 😸 | Alarm and Record | |
| <u> </u> | Event/Exception (motion detection, VCA, sensor alarm or exception information, appears at the lower-left corner of the screen. Please refer to <i>Chapter 8.6 Setting Alarm Response Actions</i> for details.) | |

3.2 Operations in Live View Mode

In live view mode, there are many functions provided. The functions are listed below.

- **Single Screen**: showing only one screen on the monitor.
- **Multi-screen:** showing multiple screens on the monitor simultaneously.
- **Auto-switch:** the screen is auto switched to the next one. And you must set the dwell time for each screen on the configuration menu before enabling the auto-switch.

Menu>Configuration>Live View>Dwell Time.

- Start Recording: continuous record and motion detection record are supported.
- Output Mode: select the output mode to Standard, Bright, Gentle or Vivid.
- Add IP Camera: the shortcut to the IP camera management interface.
- Playback: playback the recorded videos for current day.
- Aux Monitor: the NVR checks the connection of the output interfaces to define the main and auxiliary output interfaces. The priority level for the main and aux output is HDMI1/VGA1> HDMI2/VGA2 (for DS-9600NI-I8, DS-8600NI-I8 and DS-9600NI-I16) and HDMI > VGA (for DS-7600NI and DS-7700NI).

DS-9600NI-I8, DS-8600NI-I8 and DS-9600NI-I16: When the HDMI1, HDMI2, VGA1 and VGA2 are all connected, the HDMI1/VGA1 is used as main output and the HDMI2/VGA2 is used as the aux output.

DS-7600NI and DS-7700NI: When both the HDMI and VGA are connected, the HDMI is used as main output and the VGA is used as the aux output.

When the aux output is enabled, the main output cannot perform any operation, and you can do some basic operation on the live view mode for the Aux output.

3.2.1 Front Panel Operation on Live View

Table 3-2 Front Panel Operation in Live View

| Functions | Front Panel Operation | | | |
|------------------------------------|---|--|--|--|
| Show single screen | Press the corresponding Alphanumeric button. E.g. Press 2 to display only the screen for channel 2. | | | |
| Show multi-screen | Press the PREV/FOCUS- button. | | | |
| Manually switch screens | Next screen: right/down direction button. Previous screen: left/up direction button. | | | |
| Auto-switch | Press Enter button. | | | |
| Playback | Press Play button. | | | |
| Switch between main and aux output | Press Main/Aux button. | | | |

3.2.2 Using the Mouse in Live View

Table 3-3 Mouse Operation in Live View

| Name | Description | | | |
|---------------------------|--|--|--|--|
| Common Menu | Quick access to the sub-menus which you frequently visit. | | | |
| Menu | Enter the main menu of the system by right clicking the mouse. | | | |
| Single Screen | Switch to the single full screen by choosing channel number from the dropdown list. | | | |
| Multi-screen | Adjust the screen layout by choosing from the dropdown list. | | | |
| Previous Screen | Switch to the previous screen. | | | |
| Next Screen | Switch to the next screen. | | | |
| Start/Stop Auto-switch | Enable/disable the auto-switch of the screens. | | | |
| Start Recording | Start continuous recording or motion detection recording of all channels. | | | |
| Add IP Camera | Enter the IP Camera Management interface, and manage the cameras. | | | |
| Playback | Enter the playback interface and start playing back the video of the selected channel immediately. | | | |

| PTZ | Enter the PTZ control interface. | | | |
|-------------|--|--|--|--|
| Output Mode | Four modes of output supported, including Standard, Bright, Gentle and Vivid. | | | |
| Aux Monitor | Switch to the auxiliary output mode and the operation for the main output is disabled. | | | |

NOTE

- The *dwell time* of the live view configuration must be set before using **Start Auto-switch**.
- If you enter Aux monitor mode and the Aux monitor is not connected, the mouse operation
 is disabled; you need to switch back to the Main output with the MAIN/AUX button on the
 front panel or remote.
- If the corresponding camera supports intelligent function, the Reboot Intelligence option is included when right-clicking mouse on this camera.




Figure 3-1 Right-click Menu

3.2.3 Using an Auxiliary Monitor

Certain features of the Live View are also available while in an Aux monitor. These features include:

- Single Screen: Switch to a full screen display of the selected camera. Camera can be selected from a dropdown list.
- Multi-screen: Switch between different display layout options. Layout options can be selected from a dropdown list.
- Next Screen: When displaying less than the maximum number of cameras in Live View, clicking this feature will switch to the next set of displays.
- Playback: Enter into Playback mode.
- PTZ Control: Enter PTZ Control mode.

Main Monitor: Enter Main operation mode.



In the live view mode of the main output monitor, the menu operation is not available while Aux output mode is enabled.

3.2.4 Quick Setting Toolbar in Live View Mode

On the screen of each channel, there is a quick setting toolbar which shows when you single click the mouse in the corresponding screen.



Figure 3-2 Quick Setting Toolbar



The fisheye expansion view feature is supported by the DS-7600/7700/8600/9600-I (/P) series NVR only.

Icon Description Icon Description **Icon** Description Enable/Disable Mute/Audio Instant Manual Record Playback on **PTZ Control** Capture Digital Zoom Face Live View **Image Settings** Detection Strategy 3D **Fisheye** 便 Information Expansion **Positioning** Main/Sub-Stre Close am

Table 3-4 Description of Quick Setting Toolbar Icons

Instant Playback only shows the record in last five minutes. If no record is found, it means there is no record during the last five minutes.

3D Positioning (for I series NVR) is for zooming in/out the specific area of live image.

Use the left key of mouse to click on the desired position in the video image and drag a rectangle area in the lower right direction, the camera will move the position to the center and enable the rectangle area to zoom in. Use the left key of mouse to drag a rectangle area in the upper left direction to move the position to the center and enable the rectangle area to zoom out.

Digital Zoom is for zooming in the live image. You can zoom in the image to different proportions (1 to16X) by moving the sliding bar from to . You can also scroll the mouse wheel to control the zoom in/out.



Figure 3-3 Digital Zoom

Image Settings icon can be selected to enter the Image Settings menu.

You can set the image parameters like brightness, contrast, saturation and hue according to the actual demand.



Figure 3-4 Image Settings- Customize

Live View Strategy can be selected to set strategy, including Real-time, Balanced, Fluency.




Figure 3-5 Live View Strategy

Face detection function can be used to detect the human faces in live view mode and save in HDD. When there are human faces with the specified size detected in the front of the camera, the device will capture the human face and save in HDD.

Move the mouse onto the icon to show the real-time stream information, including the frame rate, bitrate, resolution and stream type.



Figure 3-6 Information

3.2.5 Fisheye Expansion View

The device supports the fisheye expansion for the connected fisheye camera in live view or playback mode.

Click the to enter the fisheye expansion mode.



The fisheye expansion view feature is supported by the DS-7600/7700/8600/9600-I (/P) series NVR only.

Table 3-5 Fisheye Display Mode

| Fisheye expansion | Button | Operation |
|----------------------|--------|---------------|
| | \sim | 180° panorama |
| | 0 | 360° panorama |
| | G | PTZ expansion |
| | | Fisheye |

Four different display modes are available. You can select a display mode as demand.

- **180° Panorama**: Switch the live view image to the 180° panorama view.
- **360° Panorama**: Switch the live view image to the 360° panorama view.
- **PTZ Expansion**: The PTZ Expansion is the close-up view of some defined area in the fisheye view or panorama expansion, and it supports the electronic PTZ function, which is also called e-PTZ.
- **Fisheye**: In the Fisheye mode, the whole wide-angle view of the fisheye camera is displayed. This view mode is called Fisheye View because it approximates the vision of a fish's convex eye. The lens produces curvilinear images of a large area, while distorting the perspective and angles of objects in the image.

3.3 Adjusting Live View Settings

Purpose:

Live View settings can be customized according to different needs. You can configure the output interface, dwell time for screen to be shown, mute or turning on the audio, the screen number for each channel, etc.

Step 1 Enter the Live View Settings interface.

Menu> Configuration> Live View



Figure 3-7 Live View-General

The settings available in this menu include:

- Video Output Interface: Designates the output to configure the settings for. The DS-9600NI and DS-8600NI provide VGA/HDMI and VGA2/HDMI2, and DS-7600NI and DS-7700NI provide the HDMI and VGA video outputs.
- Live View Mode: Designates the display mode to be used for Live View.
- **Dwell Time:** The time in seconds to *dwell* between switching of channels when enabling auto-switch in Live View.
- Enable Audio Output: Enables/disables audio output for the selected video output.
- **Volume:** Adjust the volume of live view, playback and two-way audio for the selected output interface.
- Event Output: Designates the output to show event video.
- Full Screen Monitoring Dwell Time: The time in seconds to show alarm event screen.

Step 2 Set cameras order.



Figure 3-8 Live View- Camera Order

- 1) Select a **View** mode in millim millim millim millim millim modes are supported depending on different models.
- 2) Select the small window, and double-click on the channel number to display the channel on the window.
- 3) You can click **button to start live view for all the channels and click to stop all the live view.**
- 4) Click the **Apply** button to save the setting.

You can also click-and-drag the camera to the desired window on the live view interface to set the camera order.

Step 3 Set the stream type for live view of camera.

- 1) Click the More Settings to enter the more settings interface.
- 2) Select the camera to configure from the list.
- 3) Select the stream type to main stream, sub-stream or Auto.



Figure 3-9 Stream Type Settings

- 4) Click Apply to save the settings.
- 5) (Optional) You can click the **Copy** button to copy the stream type settings of the current camera to other camera (s).

3.4 Channel-zero Encoding

Purpose:

Sometimes you need to get a remote view of many channels in real time from web browser or CMS (Client Management System) software, in order to decrease the bandwidth requirement without affecting the image quality, channel-zero encoding is supported as an option for you.

Step 1 Enter the Live View Settings interface.

Menu > Configuration > Live View

Step 2 Select the Channel-Zero Encoding tab.



Figure 3-10 Live View- Channel-Zero Encoding

Step 3 Check the checkbox after Enable Channel Zero Encoding.

Step 4 Configure the Frame Rate, Max. Bitrate Mode and Max. Bitrate.

After you set the Channel-Zero encoding, you can get a view in the remote client or web browser of 16 channels in one screen.

Chapter 4 PTZ Controls

4.1 Configuring PTZ Settings

Purpose:

Follow the procedure to set the parameters for PTZ. The configuring of the PTZ parameters should be done before you control the PTZ camera.

Step 1 Enter the PTZ Settings interface.

Menu >Camera> PTZ



Figure 4-1 PTZ Settings

Step 2 Click the **PTZ Parameters** button to set the PTZ parameters.



Figure 4-2 PTZ- General

Step 3 Choose the camera for PTZ setting in the **Camera** dropdown list.

Step 4 Enter the parameters of the PTZ camera.



All the parameters should be exactly the same as the PTZ camera parameters.

Step 5 Click **Apply** button to save the settings.

4.2 Setting PTZ Presets, Patrols & Patterns

Before you start:

Please make sure that the presets, patrols and patterns should be supported by PTZ protocols.

4.2.1 Customizing Presets

Purpose:

Follow the steps to set the Preset location which you want the PTZ camera to point to when an event takes place.

Step 1 Enter the PTZ Control interface.

Menu>Camera>PTZ



Figure 4-3 PTZ Settings

- Step 2 Use the directional button to wheel the camera to the location where you want to set preset; and the zoom and focus operations can be recorded in the preset as well.
- Step 3 Enter the preset No. (1~255) in the preset text field, and click the **Set** button to link the location to the preset.

Repeat the steps2-3 to save more presets.

You can click the **Clear** button to clear the location information of the preset, or click the **Clear All** button to clear the location information of all the presets.

4.2.2 Calling Presets

Purpose:

This feature enables the camera to point to a specified position such as a window when an event takes place.

Step 1 Click the button PTZ in the lower-right corner of the PTZ setting interface;

Or press the PTZ button on the front panel or click the PTZ Control icon in the quick setting bar, or select the PTZ option in the right-click menu to show the PTZ control panel.

Step 2 Choose Camera in the dropdown list.

Step 3 Click the button to show the general settings of the PTZ control.



Figure 4-4 PTZ Panel - General

Step 4 Click to enter the preset No. in the corresponding text field.

Step 5 Click the Call Preset button to call it.

4.2.3 Customizing Patrols

Purpose:

Patrols can be set to move the PTZ to different key points and have it stay there for a set duration before moving on to the next key point. The key points are corresponding to the presets. The presets can be set following the steps above in Customizing Presets.

Step 1 Enter the PTZ Control interface.

Menu>Camera>PTZ



Figure 4-5 PTZ Settings

- Step 2 Select patrol No. in the drop-down list of patrol.
- Step 3 Click the **Set** button to add key points for the patrol.



Figure 4-6 Key point Configuration

- Step 4 Configure key point parameters, such as the key point No., duration of staying for one key point and speed of patrol. The key point is corresponding to the preset. The **Key Point No.** determines the order at which the PTZ will follow while cycling through the patrol. The **Duration** refers to the time span to stay at the corresponding key point. The **Speed** defines the speed at which the PTZ will move from one key point to the next.
- Step 5 Click the **Add** button to add the next key point to the patrol, or you can click the **OK** button to save the key point to the patrol.

You can delete all the key points by clicking the **Clear** button for the selected patrol, or click the **Clear All** button to delete all the key pints for all patrols.

4.2.4 Calling Patrols

Purpose:

Calling a patrol makes the PTZ to move according the predefined patrol path.

Step 1 Click the button PTZ in the lower-right corner of the PTZ setting interface;

Or press the PTZ button on the front panel or click the PTZ Control icon in the quick setting bar, or select the PTZ option in the right-click menu to show the PTZ control panel.

Step 2 Click the **D** button to show the general settings of the PTZ control.



Figure 4-7 PTZ Panel - General

Step 3 Select a patrol in the dropdown list and click the Call Patrol button to call it.

Step 4 You can click the **Stop Patrol** button to stop calling it.

4.2.5 Customizing Patterns

Purpose:

Patterns can be set by recording the movement of the PTZ. You can call the pattern to make the PTZ movement according to the predefined path.

Step 1 Enter the PTZ Control interface.

Menu > Camera > PTZ



Figure 4-8 PTZ Settings

Step 2 Choose pattern number in the dropdown list.

Step 3 Click the **Start** button and click corresponding buttons in the control panel to move the PTZ camera, and click the **Stop** button to stop it.

The movement of the PTZ is recorded as the pattern.

4.2.6 Calling Patterns

Purpose:

Follow the procedure to move the PTZ camera according to the predefined patterns.

Step 1 Click the button PTZ in the lower-right corner of the PTZ setting interface;

Or press the PTZ button on the front panel or click the PTZ Control icon in the quick setting bar, or select the PTZ option in the right-click menu to show the PTZ control panel.

Step 2 Click the **D** button to show the general settings of the PTZ control.



Figure 4-9 PTZ Panel - General

Step 3 Click the **Call Pattern** button to call it.

Step 4 Click the Stop Pattern button to stop calling it.

4.2.7 Customizing Linear Scan Limit

Purpose:

The Linear Scan can be enabled to trigger the scan in the horizantal direction in the predefined range.



This function is supported by some certain models.

Step 1 Enter the PTZ Control interface.

Menu > Camera > PTZ



Figure 4-10 PTZ Settings

Step 2 Use the directional button to wheel the camera to the location where you want to set the limit, and click the **Left Limit** or **Right Limit** button to link the location to the corresponding limit.



The speed dome starts linear scan from the left limit to the right limit, and you must set the left limit on the left side of the right limit, as well the angle from the left limit to the right limit should be no more than 180°.

4.2.8 Calling Linear Scan



Before operating this function, make sure the connected camera supports the linear scan and is in HIKVISION protocol.

Purpose:

Follow the procedure to call the linear scan in the predefined scan range.

Step 1 Click the button **PTZ** in the lower-right corner of the PTZ setting interface;

Or press the PTZ button on the front panel or click the PTZ Control icon in the quick setting bar to enter the PTZ setting menu in live view mode.

Step 2 Click the **D** button to show the one-touch function of the PTZ control.



Figure 4-11 PTZ Panel - One-touch

Step 3 Click **Linear Scan** button to start the linear scan and click the Linear Scan button again to stop it.

You can click the **Restore** button to clear the defined left limit and right limit data and the dome needs to reboot to make settings take effect.

4.2.9 One-touch Park



Before operating this function, make sure the connected camera supports the linear scan and is in HIKVISION protocol.

Purpose:

For some certain model of the speed dome, it can be configured to start a predefined park action (scan, preset, patrol and etc.) automatically after a period of inactivity (park time).

Step 1 Click the button PTZ in the lower-right corner of the PTZ setting interface;

Or press the PTZ button on the front panel or click the PTZ Control icon in the quick setting bar to enter the PTZ setting menu in live view mode.

Step 2 Click the **D** button to show the one-touch function of the PTZ control.



Figure 4-12 PTZ Panel - One-touch

Step 3 There are 3 one-touch park types selectable, click the corresponding button to activate the park action.

Park (Quick Patrol): The dome starts patrol from the predefined preset 1 to preset 32 in order after the park time. The undefined preset will be skipped.

Park (Patrol 1): The dome starts move according to the predefined patrol 1 path after the park time.

Park (Preset 1): The dome moves to the predefined preset 1 location after the park time.



The park time can only be set through the speed dome configuration interface, by default the value is 5s.

Step 4 Click the button again to inactivate it.

4.3 PTZ Control Panel

To enter the PTZ control panel, there are two ways supported.

OPTION 1:

In the PTZ settings interface, click the **PTZ** button on the lower-right corner which is next to the Back button.

OPTION 2:

In the Live View mode, you can press the PTZ Control button on the front panel or on the remote control, or choose the PTZ Control icon , or select the PTZ option in the right-click menu.

Click the **Configuration** button on the control panel, and you can enter the PTZ Settings interface.



In PTZ control mode, the PTZ panel will be displayed when a mouse is connected with the device. If no mouse is connected, the PTZ icon appears in the lower-left corner of the window, indicating that this camera is in PTZ control mode.







Figure 4-13 PTZ Panel

Table 4-1 Description of the PTZ panel icons

| Icon | Description | Icon | Description | Icon | Description |
|-------------------------|---|-----------|---|---------|--|
| , , , , O , , , , | Direction button and the auto-cycle button | + | Zoom+, Focus+, Iris+ | - | Zoom-, Focus-, Iris- |
| | The speed of the PTZ movement | * | Light on/off | 4/ | Wiper on/off |
| 30 | 3D Positioning | ¤ | Image Centralization | | Menu |
| PTZ Control | Switch to the PTZ control interface | One-touch | Switch to the one-touch control interface | General | Switch to the general settings interface |
| 1 | Previous item | | Next item | 0 | Start pattern / patrol |
| | Stop the patrol / pattern movement | × | Exit | В | Minimize windows |

Chapter 5 Recording and Capture Settings



The picture capture is supported by the DS-7600/7700/8600/9600-I (/P) series NVR only.

5.1 Configuring Parameters

Purpose:

By configuring the parameters you can define the parameters which affect the image quality, such as the transmission stream type, the resolution and so on.

Before you start:

1) Make sure that the HDD has already been installed. If not, please install a HDD and initialize it. (Menu>HDD>General)



Figure 5-1 HDD- General

2) Check the storage mode of the HDD

Click **Advanced** to check the storage mode of the HDD.

If the HDD mode is *Quota*, please set the maximum record capacity and maximum picture capacity. For detailed information, see *Chapter Configuring Quota Mode*.

If the HDD mode is **Group**, you should set the HDD group. For detailed information, see *Chapter Configuring HDD Group for Recording and Capture*.




Figure 5-2 HDD- Advanced

Step 1 Enter the Record settings interface to configure the recording parameters:

Menu > Record > Parameters



Figure 5-3 Recording Parameters

Step 2 Parameters Setting for Recording

1) Select **Record** tab page to configure. You can configure the stream type, the resolution, and other parameters on your demand.

Video Encode: select the video encoding to H.265 or H.264.

Enable H.264+ Mode: check the checkbox to enable. Once enabled, the Max. Bitrate Mode, Max. Bitrate(Kbps) and Max. Bitrate Range Recommend are not configurable. Enabling it helps to ensure the high video quality with a lowered bitrate.



The H.265 and H.264+ should be supported by the connected IP camera.

2) Click the **More Settings** button to set the advanced parameters for recording and then click **OK** button to finish editing.



Figure 5-4 More Settings

Pre-record: The time you set to record before the scheduled time or event. For example, when an alarm triggers the recording at 10:00, and if you set the pre-record time as 5 seconds, the camera records at 9:59:55.

Post-record: The time you set to record after the event or the scheduled time. For example, when an alarm triggered recording ends at 11:00, and if you set the post-record time as 5 seconds, it records till 11:00:05.

Expired Time: The expired time is period for a recorded file to be kept in the HDD. When the deadline is reached, the file will be deleted. If you set the expired time to 0, the file will not be deleted. The actual keeping time for the file should be determined by the capacity of the HDD.

Redundant Record/Capture: By enabling redundant record or capture you save the record and captured picture in the redundant HDD. See *Chapter Configuring Redundant Recording and Capture*.

Record Audio: Check the checkbox to enable or disable audio recording.

Video Stream: Main stream and sub-stream are selectable for recording. When you select sub-stream, you can record for a longer time with the same storage space.

3) Click **Apply** to save the settings.



You can enable the ANR (Automatic Network Replenishment) function via the web browser (Configuration > Storage > Schedule Settings > Advanced) to save the video files in the IP camera when the network is disconnected, and synchronize the files to the NVR when the network is resumed.

NOTE

- The redundant record/capture is used when you want to save the record files or captured
 pictures in the redundant HDD. You must configure the redundant HDD in HDD settings. For
 detailed information, see Chapter 14.4.2.
- The parameters of Main Stream (Event) are read-only.

Step 3 Parameters Settings for Sub-stream

1) Enter the Sub-stream tab page.



Figure 5-5 Sub-stream Parameters

- 2) Configure the parameters of the camera.
- 3) Click **Apply** to save the settings.

Step 4 Parameters Settings for Capture

1) Select the Capture tab.



Figure 5-6 Capture Parameters

- 2) Configure the parameters.
- 3) Click **Apply** to save the settings.



The interval is the time period between two capturing actions. You can configure all the parameters on this menu on your demand.

5.2 Configuring Recording and Capture Schedule

Purpose:

Set the record schedule, and then the camera automatically starts/stops recording according to the configured schedule.



In this chapter, we take the record schedule procedure as an example, and the same procedure can be applied to configure schedule for both recording and capture. To schedule the automatic capture, you need to choose the Capture tab in the **Schedule** interface.

Step 1 Enter the Record Schedule interface.

Menu>Record/Capture>Schedule

Step 2 Configure Record Schedule

1) Select Record/Capture Schedule.



Figure 5-7 Record Schedule

Different recording types are marked in different color icons.

Continuous: scheduled recording.

Event: recording triggered by all event triggered alarm.

Motion: recording triggered by motion detection.

Alarm: recording triggered by alarm.

M/A: recording triggered by either motion detection or alarm.

M&A: recording triggered by motion detection and alarm.

POS: recording triggered by POS and alarm. (Supported by I series NVR only)



You can delete the set schedule by clicking the **None** icon.

- 2) Choose the camera you want to configure.
- 3) Select the check box after the Enable Schedule item.
- 4) Click **Edit** button or click on the color icon under the edit button and draw the schedule line on the panel.

Edit the schedule:



The all-day continuous recording is configured for the device by factory default.

I. In the message box, you can choose the day to which you want to set schedule.




Figure 5-8 Recording Schedule Interface

You can click the Dutton to set the accurate time of the schedule.

II. To schedule an all-day recording, check the checkbox after the **All Day** item.




Figure 5-9 Edit Schedule

III. To arrange other schedule, set the Start/End time for each period.



Up to 8 periods can be configured for each day. And the time periods can't be overlapped each other.

IV. Select the record type in the dropdown list.

NOTE

- To enable Motion, Alarm, M | A (motion or alarm), M & A (motion and alarm) and VCA (Video Content Analysis) triggered recording and capture, you must configure the motion detection settings, alarm input settings or VCA settings as well. For detailed information, refer to Chapter 8.1 and Chapter 9.
- The VCA settings are only available to the smart IP cameras.

Repeat the above edit schedule steps to schedule recording or capture for other days in the week. If the schedule can also be applied to other days, click **Copy**.



Figure 1. 1 Copy Schedule to Other Days

- V. Click **OK** to save setting and back to upper level menu.
- VI. Click **Apply** in the Record Schedule interface to save the settings.

Draw the schedule:

I. Click on the color icons, you can choose the schedule type as continuous or event.




Figure 5-10 Draw the Schedule

- II. Click the **Apply** button to validate the settings.
- Step 3 (Optional) If the settings can also be used to other channels, click **Copy**, and then choose the channel to which you want to copy.
- Step 4 Click **Apply** to save the settings.



Figure 5-11 Copy Schedule to Other Channels

5.3 Configuring Motion Detection Recording and Capture

Purpose:

Follow the steps to set the motion detection parameters. In the live view mode, once a motion detection event takes place, the NVR can analyze it and do many actions to handle it. Enabling motion detection function can trigger certain channels to start recording, or trigger full screen monitoring, audio warning, notify the surveillance center and so on. In this chapter, you can follow the steps to schedule a record which triggered by the detected motion.

Step 1 Enter the Motion Detection interface.

Menu>Camera>Motion



Figure 5-12 Motion Detection

Step 2 Configure Motion Detection:

- 1) Choose camera you want to configure.
- 2) Check the checkbox after Enable Motion Detection.
- 3) Drag and draw the area for motion detection by mouse. If you want to set the motion detection for all the area shot by the camera, click **Full Screen**. To clear the motion detection area, click **Clear**.
- 4) Click **Settings**, and the message box for channel information pops up.



Figure 5-13 Motion Detection Handling

- 1) Select the channels which you want the motion detection event to trigger recording.
- 2) Click **Apply** to save the settings.
- 3) Click **OK** to back to the upper level menu.
- 4) Exit the Motion Detection menu.

Step 3 Edit the Motion Detection Record Schedule. For the detailed information of schedule configuration, see *Chapter Configuring Recording and Capture* Schedule.

5.4 Configuring Alarm Triggered Recording and Capture

Purpose:

Follow the procedure to configure alarm triggered recording or capture.

Step 1 Enter the Alarm settings interface.

Menu> Configuration> Alarm



Figure 5-14 Alarm Settings

Step 2 Click Alarm Input.




Figure 5-15 Alarm Settings- Alarm Input

- 1) Select Alarm Input number and configure alarm parameters.
- 2) Choose N.O (normally open) or N.C (normally closed) for alarm type.
- 3) Check the checkbox for Setting .
- 4) Click Settings.



Figure 5-16 Alarm Settings

- 5) Choose the alarm triggered recording channel.
- 6) Check the checkbox

 ✓ to select channel.
- 7) Click Apply to save settings.
- 8) Click **OK** to back to the upper level menu.

Repeat the above steps to configure other alarm input parameters.

If the settings can also be applied to other alarm inputs, click **Copy** and choose the alarm input number.



Figure 5-17 Copy Alarm Input

Step 3 Edit the Alarm triggered record in the Record/Capture Schedule setting interface. For the detailed information of schedule configuration, see *Chapter Configuring Recording and Capture* Schedule.

5.5 Configuring VCA Event Recording

Purpose:

The event triggered recording can be configured through the menu. Then events include the motion detection, alarm and VCA events (face detection/face capture, line crossing detection, intrusion detection, region entrance detection, region exiting detection, loitering detection, people gathering detection, fast moving detection, parking detection, unattended baggage detection, object removal detection, audio loss exception detection, sudden change of sound intensity detection, and defocus detection).

Step 1 Enter the VCA settings interface and select a camera for the VCA settings.

Menu > Camera > VCA



Figure 5-18 VCA Settings

- Step 2 Configure the detection rules for VCA events. For details, please refer to Chapter 10 VCA Alarm.
- Step 3 Click the icon to configure the alarm linkage actions for the VCA events.
- Step 4 Select **Trigger Channel** tab and select one or more channels which will start to record when VCA alarm is triggered.
- Step 5 Click Apply to save the settings




Figure 5-19 Set Trigger Camera of VCA Alarm



The PTZ Linking function is only available for the VCA settings of IP cameras.

Step 6 Enter Record Schedule settings interface (Menu > Record > Schedule > Record Schedule), and then set VCA as the record type. For details, see step 2 in *Chapter 5.2 Configuring Recording and* Capture Schedule.

5.6 Manual Recording and Continuous Capture

Purpose:

Follow the steps to set parameters for the manual recording and continuous capture. Using manual recording and continuous capture, you need to manually cancel the record and capture. The manual recording and manual continuous capture is prior to the scheduled recording and capture.

Step 1 Enter the Manual settings interface.

Menu> Manual

Or press the **REC/SHOT** button on the front panel.



Figure 5-20 Manual Record

Step 2 Enable the Manual Recording.

- 1) Select **Record** on the left bar.
- 2) Click the status button before camera number to change **III** to **III**.

Step 3 Disable manual record.

Click the status button to change

to

to



Green icon means that the channel is configured the record schedule. After rebooting, all the manual records enabled will be canceled.

Step 4 Enabling and disabling the continuous capture

1) Select Continuous Capture on the left bar.



Figure 5-21 Continuous Capture

- 2) Click the status button before camera number to change **u** to **u**.
- 3) Disable continuous capture.
- 4) Click the status button to change

 to

 to



Green icon means that the channel is configured the capture schedule. After rebooting, all the continuous capture will be canceled.

5.7 Configuring Holiday Recording and Capture

Purpose:

Follow the steps to configure the record or capture schedule on holiday for that year. You may want to have different plan for recording and capture on holiday.

Step 1 Enter the Record setting interface.

Menu > Record > Holiday




Figure 5-22 Holiday Settings

Step 2 Enable Edit Holiday schedule.

1) Click I to enter the Edit interface.



Figure 5-23 Edit Holiday Settings

- 2) Check the checkbox after Enable Holiday.
- 3) Select Mode from the dropdown list.
- 4) There are three different modes for the date format to configure holiday schedule.
- 5) Set the start and end date.
- 6) Click **Apply** to save settings.
- 7) Click **OK** to exit the Edit interface.

Step 3 Enter Record/Capture Schedule settings interface to edit the holiday recording schedule. See Chapter 6.2 Configuring Recording and Capture Schedule.

5.8 Configuring Redundant Recording and Capture

Purpose:

Enabling redundant recording and capture, which means saving the record files and captured pictures not only in the R/W HDD but also in the redundant HDD, will effectively enhance the data safety and reliability.

Step 1 Enter HDD Information interface.

Menu> HDD



Figure 5-24 HDD General

Step 2 Select the **HDD** and click does not enter the Local HDD Settings interface.

1) Set the HDD property to Redundancy.




Figure 5-25 HDD General-Editing

- 2) Click **Apply** to save the settings.
- 3) Click **OK** to back to the upper level menu.



You must set the Storage mode in the HDD advanced settings to Group before you set the HDD property to Redundant. For detailed information, please refer to *Chapter 11.4.1 Setting HDD Property*. There should be at least another HDD which is in Read/Write status.

Step 3 Enter the Record setting interface.

Menu> Record> Parameters

1) Select Record tab.

2) Click More Settings to enter the following interface.



Figure 5-26 Record Parameters

- 3) Select Camera you want to configure in the drop-down list.
- 4) Check the checkbox of Redundant Record/Capture.
- 5) Click **OK** to save settings and back to the upper level menu.

Repeat the above steps for configuring other channels.

5.9 Configuring HDD Group for Recording and Capture

Purpose:

You can group the HDDs and save the record files and captured pictures in certain HDD group.

Step 1 Enter HDD setting interface.

Menu>HDD



Figure 5-27 HDD General

Step 2 Select Advanced on the left side menu.



Figure 5-28 Storage Mode

Check whether the storage mode of the HDD is Group. If not, set it to Group. For detailed information, please refer to *Chapter 14.4 Managing HDD Group*.

Step 3 Select General in the left side menu

Step 4 Click do enter editing interface.

Step 5 Configuring HDD group.

- 1) Choose a group number for the HDD group.
- 2) Click Apply and then in the pop-up message box, click Yes to save your settings.
- 3) Click **OK** to back to the upper level menu.
- 4) Repeat the above steps to configure more HDD groups.

Step 6 Choose the Channels which you want to save the record files and captured pictures in the HDD group.

- 1) Select **Advanced** on the left bar.
- 2) Choose Group number in the dropdown list of Record on HDD Group
- 3) Check the channels you want to save in this group.
- 4) Click **Apply** to save settings.



After having configured the HDD groups, you can configure the Recording and Capture settings following the procedure provided in *Chapter 5.2-5.7*.

5.10 Files Protection

Purpose:

You can lock the recording files or set the HDD property to Read-only to protect the record files from being overwritten.

5.10.1 Locking the Recording Files

Lock File when Playback

Step 1 Enter Playback interface.

Menu> Playback

Step 2 Check the checkbox of channel(s) in the channel list and then double-click to select a date on the calendar.



Figure 5-29 Normal/Smart Playback

Step 3 During playback, click the button to lock the current recording file.



In the multi-channel playback mde, clicking the button will lock all the record files related to the playback channels.

Step 4 You can click the button to pop up the file management interface. Click the **Locked File** tab to check and export the locked files.



Figure 5-30 Locked File Management

In the File Management interface, you can also click \bigsim to change it to \bigsim to unlock the file and the file is not protected.

Lock File when Export

Step 1 Enter Export setting interface.

Menu> Export



Figure 5-31 Export

- Step 2 Select the channels you want to search by checking the checkbox to .
- Step 3 Configure the record type, file type start/end time.
- Step 4 Click Search to show the results.



Figure 5-32 Export- Search Result

Step 5 Protect the record files.

1) Find the record files you want to protect, and then click the icon which will turn to indicating that the file is locked.



The record files of which the recording is still not completed cannot be locked.

2) Click 1 to change it to 1 to unlock the file and the file is not protected.



Figure 5-33 Unlocking Attention

5.10.2 Setting HDD Property to Read-only

Step 1 Enter HDD setting interface.

Menu> HDD



Figure 5-34 HDD General

Step 2 Click do to edit the HDD you want to protect.




Figure 5-35 HDD General- Editing



To edit HDD property, you need to set the storage mode of the HDD to Group. See *Chapter Managing HDD Group*.

Step 3 Set the HDD property to Read-only.

Step 4 Click **OK** to save settings and back to the upper level menu.

NOTE

- You cannot save any files in a Read-only HDD. If you want to save files in the HDD, change the property to R/W.
- If there is only one HDD and is set to Read-only, the NVR can't record any files. Only live view mode is available.
- If you set the HDD to Read-only when the NVR is saving files in it, then the file will be saved in next R/W HDD. If there is only one HDD, the recording will be stopped.

Chapter 6 Playback

6.1 Playing Back Record Files

6.1.1 Instant Playback

Purpose

Play back the recorded video files of a specific channel in the live view mode. Channel switch is supported.

Instant playback by channel

Choose a channel in live view mode and click the button in the quick setting toolbar.



In the instant playback mode, only record files recorded during the last five minutes on this channel will be played back.



Figure 6-1 Instant Playback Interface

6.1.2 Playing Back by Normal Search

Playback by Channel

Enter the Playback interface.

Right click a channel in live view mode and select Playback from the menu, as shown in Figure 6-2.



Figure 6-2 Right-click Menu under Live View



Pressing numerical buttons will switch playback to the corresponding channels during playback process.

Playback by Time

Purpose

Play back video files recorded in specified time duration. Multi-channel simultaneous playback and channel switch are supported.

Step 1 Enter playback interface.

Menu>Playback

- Step 2 Select the Normal/Smart in the drop-down list on the top-left side.
- Step 3 Select the stream to Main Stream or Sub Stream. (for I series NVR only)
- Step 4 Select a camera in the camera list.



The main stream or sub stream for recording is configurable in Menu>Record>Parameters.

Step 5 Select a date in the calendar and click the button on the left toolbar to play the video file.



Figure 6-3 Playback Calendar

If there are record files for that camera in that day, in the calendar, the icon for that day is displayed in different colors for different recording types: blue for continuous recording and red for event recording.

Step 6 Click the Normal radio button to start playing the continuous recorded files.

Playback Interface

You can use the toolbar in the bottom part of Playback interface to control playing progress, as shown in Figure 6-4.



Figure 6-4 Playback Interface



Figure 6-5 Toolbar of Playback

You can click the channel(s) to execute simultaneous playback of multiple channels.

NOTE

- The O5-06-2016 16:33:42 -- 06-07-2016 10:53:24 indicates the start/end time of the recorded video files.
- Playback progress bar: use the mouse to click any point of the progress bar or drag the progress bar to locate specific frames.

Table 6-1 Detailed Explanation of Playback Toolbar

| Item | Button | Operation | Button | Operation | | |
|---------------------|---------------------|--|---|---|--|--|
| | ፟ | Draw quadrilateral for the motion detection | the motion Q Search | | | |
| Smart Search | | Set full screen for motion detection | Draw line for the line crossing detection | | | |
| | ♦ | Draw quadrilateral for the intrusion detection | Y | Filter video files by setting the target characters | | |
| Operations | ₫ / Š | Audio on/Mute | ŏ / ŏ≥ | Start/Stop clipping | | |
| | 0 | Capture Picture | 電腦 | Lock File | | |
| | 15 | Add default tag | 1 | Add customized tag | | |
| | 蓉 | File management for video clips, captured pictures, locked files and tags | a | Digital Zoom | | |
| Playing Control | Ⅲ/ ▶ | Pause/Play | ■ / □ | Reverse play/ Pause | | |
| | * | Slow forward | | Stop | | |
| | 305 | 30s forward | 305 | 30s reverse | | |
| | > | Next day | >> | Fast forward | | |
| | (| Previous day | | | | |
| | 1 | Previous/Next period | • 30mins | Play the time bar in 30 minutes (default) | | |
| Time Bar Scaling | ● 1h | Play the time bar in 1 hour | 2 h | Play the time bar in 2 hours | | |
| | O 6h | Play the time bar in 6 hours | ● 24h | Play the time bar in 24 hours | | |
| Fisheye | $ \wedge $ | 180° panorama | 0 | 360° panorama | | |

| Item | Button | Operation | Button | Operation |
|-----------|--------|---|--------|-----------|
| Expansion | G | PTZ expansion | • | Fisheye |
| POS | T | Enable/Disable POS information overlay (Supported by I series NVR only) | | |



- The fisheye expansion view feature is supported by the DS-7600/7700/8600/9600-I (/P) series NVR only.
- Please refer to the *Chapter 3.2.5 Fisheye Expansion* for the description and operation of the fisheye expansion.

NOTE

- The playing speed of 256X is supported.
- When the playing speed is higher than 2X, the POS information cannot be overlain on the video.

6.1.3 Playing back by Smart Search

Purpose

The smart playback function provides an easy way to get through the less effective information. When you select the smart playback mode, the system will analyze the video containing the motion, line or intrusion detection information, mark it with green color and play it in the normal speed while the video without motion will be played in the 16-time speed. The smart playback rules and areas are configurable.

Step 1 Enter Playback interface.

Menu>Playback

Step 2 Select the **Normal/Smart** in the drop-down list on the top-left side.

Step 3 Select the stream to Main Stream or Sub Stream. (for I series NVR only)



The main stream or sub stream for recording is configurable in Menu>Record>Parameters.

Step 4 Select a camera in the camera list.

Step 5 Select a date in the calendar and click the button on the left toolbar to play the video file.



Figure 6-6 Playback by Smart Search

Step 6 Click the Smart radio button to switch to the playback by smart search.

Step 7 Set the rules and areas for smart search of line crossing detection, intrusion detection or motion detection event triggered recording.

• Line Crossing Detection

Select the button, and click on the image to specify the start point and end point of the line.

• Intrusion Detection

Click the button, and specify 4 points to set a quadrilateral region for intrusion detection. Only one region can be set.

• Motion Detection

Click the button, and then hold the mouse on the image to draw the detection area manually. You can also click the button to set the full screen as the detection area.

Step 8 (Optional) You can click to filter the searched video files by setting the target characters, including the gender and age of the human and whether he/she wears glasses.



Figure 6-7 Set Result Filter

Step 9 (Optional) Click to enter the Smart Settings to configure the related parameters.

Skip the Non-Related Video: check the checkbox to enable the device to skip non-related video files.

Play Non-Related Video: set the playing speed to 8X/4X/2X/1X when playing the non-related video files.

Play Related Video: set the playing speed to 4X/2X/1X when playing the non-related video files.



Figure 6-8 Smart Settings

6.1.4 Playing Back by Event Search

Purpose

Play back record files on one or several channels searched out by event type (e.g., alarm input, motion detection and VCA).

Step 1 Enter the Playback interface.

Menu>Playback

Step 2 Select the **Event** in the drop-down list on the top-left side.

Step 3 Select the stream to Main Stream or Sub Stream. (for I series NVR only)

Step 4 Select the major type to Alarm Input, Motion, POS or VCA as the event type.



We take playback by VCA as the example in the following instructions.



Figure 6-9 Event Search Interface

Step 5 Select the minor type of VCA from the drop-down list. (Please refer to *Chapter 9 VCA Alarm* for the details of VCA detection types).



For configuring the VCA recording, please refer to Chapter 5.4 Configuring VCA Event Recording and Capture; and for details of VCA detection types, please refer to Chapter 9 VCA Alarm.

Step 6 Select the camera (s) for searching, and set the Start time and End time.

Step 7 Click **Search** button to get the search result information. You may refer to the right-side bar for the result.



For the POS event type (supported by I series NVR), you can enter the Keyword and enable the Case Sensitivity (upper case and lower case) to search the video files with the keyword contained POS information.

Step 8 Select a result item and click button to play back the file.



Pre-play and post-play can be configured.

Step 9 (Optional) Enter the Synch Playback interface to select the camera (s) for synchronous playback.



Figure 6-10 Synch Playback Interface

Step 10 Enter the playback interface.

The toolbar in the bottom part of playback interface can be used to control playing process.



Figure 6-11 Interface of Playback by Event

You can click or button to select the previous or next event. Please refer to Table 6.1 for the description of buttons on the toolbar.

6.1.5 Playing Back by Tag

Purpose:

Video tag allows you to record related information like people and location of a certain time point during playback. You can use video tag(s) to search for record files and position time point.

Before playing back by tag:

Step 1 Enter Playback interface.

Menu>Playback

Step 2 Search and play back the record file(s). Refer to *Chapter 6.1.1* for the detailed information about searching and playback of the record files.



Figure 6-12 Interface of Playback by Time

- Click button to add default tag.
- Click button to add customized tag and input tag name.



Max. 64 tags can be added to a single video file.

Step 3 Tag management.

Click button to enter the File Management interface and click **Tag** to manage the tags. You can check, edit, and delete tag(s).



Figure 6-13 Tag Management Interface

Playing back by Tag

- Step 1 Select the Tag from the drop-down list in the Playback interface.
- Step 2 Select the stream to Main Stream or Sub Stream.
- Step 3 Choose channels, edit start time and end time, and then click **Search** to enter Search Result interface.



You can enter keyword in the textbox Keyword to search the tag on your command.

Step 4 Click button to play back the selected tag file.



Figure 6-14 Interface of Playback by Tag



Pre-play and post-play can be configured.

You can click or button to select the previous or next tag. Please refer to Table 6.1 for the description of buttons on the toolbar.

6.1.6 Playing Back by Sub-periods

Purpose:

The video files can be played in multiple sub-periods simultaneously on the screens.

Step 1 Enter Playback interface.

Step 2 Menu>Playback

Step 3 Select **Sub-periods** from the drop-down list in the upper-left corner of the page to enter the Sub-periods Playback interface.

Step 4 Select the stream to Main Stream or Sub Stream.

Step 5 Select a date and start playing the video file.

Step 6 Select the Split-screen Number from the dropdown list. Up to 16 screens are configurable.



Figure 6-15 Interface of Sub-periods Playback



According to the defined number of split-screens, the video files on the selected date can be divided into average segments for playback. E.g., if there are video files existing between 16:00 and 22:00, and the 6-screen display mode is selected, then it can play the video files for 1 hour on each screen simultaneously.

6.1.7 Playing Back by System Logs

Purpose:

Play back record file(s) associated with channels after searching system logs.

Step 1 Enter Log Information interface.

Menu>Maintenance>Log Information

Step 2 Click Log Search tab to enter Playback by System Logs.

Step 3 Set search time and type and click **Search** button.




Figure 6-16 System Log Search Interface

Step 4 Choose a log with record file and click button to enter Playback interface.



If there is no record file at the time point of the log, the message box "No result found" will pop up.




Figure 6-17 Result of System Log Search

Step 5 Playback interface.

The toolbar in the bottom part of Playback interface can be used to control playing process.



Figure 6-18 Interface of Playback by Log

6.1.8 Playing Back External File

Purpose:

Perform the following steps to look up and play back files in the external devices.

Step 1 Enter Tag Search interface.

Menu>Playback

Step 2 Select the External File in the drop-down list on the top-left side.

The files are listed in the right-side list.

You can click the Refresh button to refresh the file list.

Step 3 Select and click the button to play back it. And you can adjust the playback speed by clicking and ...



Figure 6-19 Interface of External File Playback

6.1.9 Playing Back Pictures



The playback by picture is supported by the DS-9600/8600/7700/7600NI-I (/P) series NVR only.

Purpose:

The captured pictures stored in the HDDs of the device can be searched and viewed.

Step 1 Enter Playback interface.

Menu>Playback

- Step 2 Select **Picture** from the drop-down list in the upper-left corner of the page to enter the Picture Playback interface.
- Step 3 Check checkbox to select the channel(s) and specify the start time and end time for search.
- Step 4 Click **Search** to enter Search Result interface.



Up to 4000 pictures can be displayed each time.

Step 5 Choose a picture you want to view and click button.

You can click **Back** to return to the search interface.



Figure 6-20 Result of Picture Playback

Step 6 The toolbar in the bottom part of Playback interface can be used to control playing process.



Figure 6-21 Picture Playback Toolbar

Table 6-2 Detailed Explanation of Picture-playback Toolbar

| Button | Function | Button | Function | Button | Function | Button | Function |
|--------|--------------|--------|----------|--------|------------------|--------|--------------|
| 4 | Play reverse | > | Play | < | Previous picture | > | Next picture |

6.2 Auxiliary Functions of Playback

6.2.1 Playing Back Frame by Frame

Purpose:

Play video files frame by frame, in case of checking image details of the video when abnormal events happen.

Using a Mouse:

Go to Playback interface.

If you choose playback of the record file: click button until the speed changes to Single frame and one click on the playback screen represents playback of one frame.

If you choose reverse playback of the record file: click button until the speed changes to Single frame and one click on the playback screen represents reverse playback of one frame. It is also feasible to use button in toolbar.

· Using the Front Panel:

Click the button to set the speed to Single frame. One click on button, one click on the playback screen or Enter button on the front panel represents playback or reverse playback of one frame.

6.2.2 Thumbnails View

With the thumbnails view on the playback interface, you can conveniently locate the required video files on the time bar.

Step 1 Enter the playback interface and start to play the video files.

Step 2 Move the mouse to the time bar to get the preview thumbnails of the video files. Select and double click on a required thumbnail to enter the full-screen playback.



Figure 6-22 Thumbnails View



The thumbnail view is supported only in the 1X single-camera playback mode.

6.2.3 Fast View

You can hold the mouse to drag on the time bar to get the fast view of the video files.

- Step 1 Enter the playback interface and start to play the video files.
- Step 2 Use the mouse to hold and drag through the playing time bar to fast view the video files.
- Step 3 Release the mouse to the required time point to enter the full-screen playback.



The fast view is supported only in the 1X single-camera playback mode.

6.2.4 Digital Zoom

Step 1 Click the Dutton on the playback control bar to enter Digital Zoom interface.

Step 2 You can zoom in the image to different proportions (1 to16X) by moving the sliding bar from to ... You can also scroll the mouse wheel to control the zoom in/out.



Figure 6-23 Draw Area for Digital Zoom

Step 3 Right-click the image to exit the digital zoom interface.

6.2.5 File Management

You can manage the video clips, captured pictures in playback, locked files and tags you have added in the playback mode.

Step 1 Enter the playback interface.

Step 2 Click on the toolbar to enter the file management interface.




Figure 6-24 File Management

Step 3 You can view the saved video clips, captured playback pictures, lock/unlock the files and edit the tags which you added in the playback mode.

Step 4 If required, select the items and click **Export All** or **Export** to export the clips/pictures/files/tags to local storage device.

Chapter 7 Backup

7.1 Backing up Record Files

7.1.1 Quick Export

Purpose:

Export record files to backup device(s) quickly.

Step 1 Enter Video Export interface.

Menu>Export>Normal

Choose the channel(s) you want to back up and click **Quick Export** button.



The time duration of record files on a specified channel cannot exceed one day. Otherwise, the message box "Max. 24 hours are allowed for quick export." will pop up.



Figure 7-1 Quick Export Interface

Step 2 Select the format of the log files to be exported. Up to 15 formats are selectable.

Step 3 Click the **Export** to start exporting.

INOTE

Here we use USB Flash Drive and please refer to the next section Normal Backup for more backup devices supported by the NVR.



Figure 7-2 Quick Export using USB1-1

Stay in the Exporting interface until all record files are exported.



Figure 7-3 Export Finished

Step 4 Check backup result.

Choose the record file in Export interface and click button

to check it.



The Player player.exe will be exported automatically during record file export.




Figure 7-4 Checkup of Quick Export Result Using USB1-1

7.1.2 Backing up by Normal Video/Picture Search

Purpose:

The record files can be backup to various devices, such as USB devices (USB flash drives, USB HDDs, USB writer), SATA writer and e-SATA HDD.



The eSATA HDD is supported by DS-9600NI-I8 and DS-9600NI-I16 series NVR only.

Backup using USB flash drives and USB HDDs

Step 1 Enter Export interface.

Menu>Export>Normal/Picture

Step 2 Select the cameras to search.

Step 3 Set search condition and click **Search** button to enter the search result interface. The matched video files or pictures are displayed in Chart or List display mode.



Figure 7-5 Normal Video Search for Backup

Step 4 Select video files or pictures from the Chart or List to export.

Click on to play the record file if you want to check it.

Check the checkbox before the record files you want to back up.



The size of the currently selected files is displayed in the lower-left corner of the window.



Figure 7-6 Result of Normal Video Search for Backup

Step 5 Export the video files or picture files.

Click Export All button to export all the files.

Or you can select recording files you want to back up, and click **Export** button to enter Export interface.



If the inserted USB device is not recognized:

- Click the Refresh button.
- Reconnect device.
- Check for compatibility from vendor.

You can also format USB flash drives or USB HDDs via the device.



Figure 7-7 Export by Normal Video Search using USB Flash Drive

Stay in the Exporting interface until all record files are exported with pop-up message box "Export finished".



Figure 7-8 Export Finished



The backup of video files using USB writer or SATA writer has the same operating instructions. Please refer to steps described above.

7.1.3 Backing up by Event Search

Purpose:

Back up event-related record files using USB devices (USB flash drives, USB HDDs, USB writer), SATA writer or eSATA HDD. Quick Backup and Normal Backup are supported.

Step 1 Enter Export interface.

Menu>Export>Event

Step 2 Select the cameras to search.

Step 3 Select the event type to alarm input, motion, VCA or POS.



Figure 7-9 Event Search for Backup



The POS event type is supported by the DS-7600/7700/8600/9600-I (/P) series NVR only.

Step 4 Set the search conditions and click **Search** button to enter the search result interface. For the POS event type, you can also set the Keyword and enable the Case Sensitivity (upper case and lower case) to search the video files with the key word contained POS information.

Step 5 The matched video files are displayed in Chart or List display mode. Select video files from the Chart or List interface to export.



Figure 7-10 Result of Event Search

Step 6 Export the video files. Please refer to step5 of *Chapter 7.1.2 Backing up by Normal Video Search* for details.

7.1.4 Backing up Video Clips or Captured Playback Pictures

Purpose:

You may also select video clips or captured pictures in playback mode to export directly during Playback, using USB devices (USB flash drives, USB HDDs, USB writer), SATA writer or eSATA HDD.

Step 1 Enter Playback interface.

Please refer to Chapter 6.1 Playing Back Record Files.

Step 2 During playback, use buttons or in the playback toolbar to start or stop clipping record file (s); or use the button to capture pitcures.

Step 3 Click the **to enter the file management interface.**




Figure 7-11 Video Clips or Captured Pictures Export Interface

Step 4 Export the video clips or captured pictures in playback. Please refer to step5 of *Chapter 7.1.2*Backing up by Normal Video Search for details.

7.2 Managing Backup Devices

Management of USB flash drives, USB HDDs and eSATA HDDs

Step 1 Enter the Export interface.




Figure 7-12 Storage Device Management

Step 2 Backup device management.

Click New Folder button if you want to create a new folder in the backup device.

Select a record file or folder in the backup device and click device button if you want to delete it.

Click **Erase** button if you want to erase the files from a re-writable CD/DVD.

Click Format button to format the backup device.



If the inserted storage device is not recognized:

- Click the Refresh button.
- Reconnect device.
- Check for compatibility from vendor.

7.3 Hot Spare Device Backup

Purpose:

The device can form an N+1 hot spare system. The system consists of several working devices and a hot spare device; when the working device fails, the hot spare device switches into operation, thus increasing the reliability of the system.



Please contact dealer for details of models which support the hot spare function.

Before you start:

At least 2 devices are online.

A bidirectional connection shown in the figure below is required to be built between the hot spare device and each working device.



Figure 7-13 Building Hot Spare System

7.3.2 Setting Hot Spare Device



- The camera connection will be disabled when the device works in the hot spare mode.
- It's highly recommended to restore the defaults of the device after switching the working mode of the hot spare device to normal mode to ensure the normal operation afterwards.

Step 1 Enter the Hot Spare settings interface.

Menu > Configuration > Hot Spare

Step 2 Set the Work Mode as Hot Spare Mode and click the Apply button to confirm the settings.

Step 3 Reboot the device to make the change take effect.



Figure 7-14 Reboot Attention

Step 4 Click the **Yes** button in the pop-up attention box.

7.3.3 Setting Working Device

Step 1 Enter the Hot Spare settings interface.

Step 2 Menu > Configuration > Hot Spare

Step 3 Set the Work Mode as Normal Mode (default).

Step 4 Check the checkbox of Enable to enable the hot spare function.

Step 5 Enter the IP address and admin password of hot spare device.




Figure 7-15 Setting Working Mode for Working device

Step 6 Click the **Apply** button to save the settings.

7.3.4 Managing Hot Spare System

Step 1 Enter the Hot Spare Settings interface of the hot spare device.

Menu > Configuration > Hot Spare

The connected working device is displayed on the device list.

Step 2 Check the checkbox to select the working device from the device list, and click the **Add** button to link the working device to the hot spare device.



A hot spare device can connect up to 32 working devices.




Figure 7-16 Add Working Device

Step 3 You can view the working status of the hot spare device on the Working Status list.

When the working device works properly, the working status of the hot spare device is displayed as *No record*.



Figure 7-17 No Recording

When the working device gets offline, the hot spare device will record the video of the IP Camera connected to the working device for backup, and the working status of the hot spare device is displayed as *Backing up*.



The record backing up can be functioned for 1 working device at a time.



Figure 7-18 Backing up

When the working device comes online, the lost video files will be restored by the record synchronization function, and the working status of the hot spare device is displayed as *Synchronizing*.



The record synchronization function can be enabled for 1 working device at a time.



Figure 7-19 Synchronizing

Chapter 8 Alarm Settings

8.1 Setting Motion Detection Alarm

Step 1 Enter Motion Detection interface of Camera Management and choose a camera you want to set up motion detection.

Menu> Camera> Motion




Figure 8-1 Motion Detection Setup Interface

Step 2 Set up detection area and sensitivity.

Tick "Enable Motion Detection", use the mouse to draw detection area(s) and drag the sensitivity bar to set sensitivity.

Click button and set alarm response actions.

Step 3 Click **Trigger Channel** tab and select one or more channels which will start to record/capture or become full-screen monitoring when motion alarm is triggered, and click **Apply** to save the settings.



Figure 8-2 Set Trigger Camera of Motion Detection

Step 4 Set up arming schedule of the channel.

- 1) Select Arming Schedule tab to set the arming schedule of handling actions for the motion detection.
- 2) Choose one day of a week and up to eight time periods can be set within each day.
- 3) Click Apply to save the settings



Time periods shall not be repeated or overlapped.



Figure 8-3 Set Arming Schedule of Motion Detection

Step 5 Click **Handling** tab to set up alarm response actions of motion alarm (please refer to *Chapter Setting Alarm Response Actions*).

Step 6 If you want to set motion detection for another channel, repeat the above steps or just click **Copy** in the Motion Detection interface to copy the above settings to it.

8.2 Setting Sensor Alarms

Purpose:

Set the handling action of an external sensor alarm.

Step 1 Enter Alarm Settings of System Configuration and select an alarm input.

Menu> Configuration> Alarm

Select Alarm Input tab to enter Alarm Input Settings interface.




Figure 8-4 Alarm Status Interface of System Configuration

Step 2 Set up the handling action of the selected alarm input.

Check the **Enable** checkbox and click **Settings** button to set up its alarm response actions.



Figure 8-5 Alarm Input Setup Interface

Step 3 (Optional) Enable the one-key disarming for local alarm input 1 (Local<-1).

- 1) Check the checkbox of Enable One-Key Disarming.
- 2) Click the **Settings** button to enter the linkage action settings interface.
- 3) Select the alarm linkage action (s) you want to disarm for the local alarm input1. The selected linkage actions include the Full Screen Monitoring, Audible Warning, Notify Surveillance Center, Send Email and Trigger Alarm Output.

NOTE

When the alarm input 1 (Local<-1) is enabled with one-key disarming, the other alarm input settings are not configurable.

Step 4 Select Trigger Channel tab and select one or more channels which will start to record/capture or become full-screen monitoring when an external alarm is input, and click **Apply** to save the settings.

Step 5 Select **Arming Schedule** tab to set the arming schedule of handling actions.




Figure 8-6 Set Arming Schedule of Alarm Input

Choose one day of a week and Max. eight time periods can be set within each day, and click **Apply** to save the settings.



Time periods shall not be repeated or overlapped.

Repeat the above steps to set up arming schedule of other days of a week. You can also use **Copy** button to copy an arming schedule to other days.

Step 6 Select **Linkage Action** tab to set up alarm response actions of the alarm input (please refer to *Chapter Setting Alarm Response Actions*).

Step 7 If necessary, select PTZ Linking tab and set PTZ linkage of the alarm input.

Set PTZ linking parameters and click **OK** to complete the settings of the alarm input.



Make sure the PTZ or speed dome connected supports PTZ linkage.




Figure 8-7 Set PTZ Linking of Alarm Input

Step 8 If you want to set handling action of another alarm input, repeat the above steps.

Or you can click the **Copy** button on the Alarm Input Setup interface and check the checkbox of alarm inputs to copy the settings to them.



Figure 8-8 Copy Settings of Alarm Input

8.3 Detecting Video Loss Alarm

Purpose:

Detect video loss of a channel and take alarm response action(s).

Step 1 Enter Video Loss interface of Camera Management and select a channel you want to detect.

Menu> Camera> Video Loss



Figure 8-9 Video Loss Setup Interface

Step 2 Set up handling action of video loss.

Check the checkbox of "Enable Video Loss Alarm", and click button to set up handling action of video loss.

Step 3 Set up arming schedule of the handling actions.

- 1) Select Arming Schedule tab to set the channel's arming schedule.
- 2) Choose one day of a week and up to eight time periods can be set within each day.
- 3) Click Apply button to save the settings.



Time periods shall not be repeated or overlapped.




Figure 8-10 Set Arming Schedule of Video Loss

Step 4 Select **Linkage Action** tab to set up alarm response action of video loss (please refer to *Chapter Setting Alarm Response Actions*).

Step 5 Click the **OK** button to complete the video loss settings of the channel.

8.4 Detecting Video Tampering Alarm

Purpose:

Trigger alarm when the lens is covered and take alarm response action(s).

Step 1 Enter Video Tampering interface of Camera Management and select a channel you want to detect video tampering.

Menu> Camera> Video Tampering




Figure 8-11 Video Tampering Setting Interface

Step 2 Set the video tampering handling action of the channel.

- 1) Check the checkbox of "Enable Video Tampering Detection".
- 2) Drag the sensitivity bar to set a proper sensitivity level. Use the mouse to draw an area you want to detect video tampering.
- 3) Click button to set up handling action of video tampering.

Step 3 Set arming schedule and alarm response actions of the channel.

- 1) Click Arming Schedule tab to set the arming schedule of handling actions.
- 2) Choose one day of a week and Max. eight time periods can be set within each day.
- 3) Click **Apply** button to save the settings.



Time periods shall not be repeated or overlapped.




Figure 8-12 Set Arming Schedule of Video Tampering

Step 4 Select **Linkage Action** tab to set up alarm response actions of video tampering alarm (please refer to *Chapter Setting Alarm Response Actions*).

Step 5 Click the **OK** button to complete the video tampering settings of the channel.

8.5 Handling Exceptions Alarm

Purpose:

Exception settings refer to the handling action of various exceptions, e.g.

- **HDD Full:** The HDD is full.
- **HDD Error:** Writing HDD error or unformatted HDD.
- Network Disconnected: Disconnected network cable.
- IP Conflicted: Duplicated IP address.
- Illegal Login: Incorrect user ID or password.
- Record/Capture Exception: No space for saving recorded files or captured images.
- Hot Spare Exception: Disconnected with the working device.

Steps:

Enter Exception interface of System Configuration and handle various exceptions.

Menu> Configuration> Exceptions

Please refer to Chapter Setting Alarm Response Actions for detailed alarm response actions.



Figure 8-13 Exceptions Setup Interface

8.6 Setting Alarm Response Actions

Purpose:

Alarm response actions will be activated when an alarm or exception occurs, including Event Hint Display, Full Screen Monitoring, Audible Warning (buzzer), Notify Surveillance Center, Trigger Alarm Output and Send Email.

Event Hint Display

When an event or exception happens, a hint can be displayed on the lower-left corner of live view image. And you can click the hint icon to check the details. Besides, the event to be displayed is configurable.

Step 1 Enter the Exception settings interface.

Menu > Configuration > Exceptions

Step 2 Check the checkbox of **Enable Event Hint**.



Figure 8-14 Event Hint Settings Interface

Step 3 Click the to set the type of event to be displayed on the image.



Figure 8-15 Event Hint Settings Interface

Step 4 Click the **OK** button to finish settings.

Full Screen Monitoring

When an alarm is triggered, the local monitor (VGA, HDMI or BNC monitor) display in full screen the video image from the alarming channel configured for full screen monitoring.

If alarms are triggered simultaneously in several channels, their full-screen images will be switched at an interval of 10 seconds (default dwell time). A different dwell time can be set by going to Menu >Configuration>Live View > Full Screen Monitoring Dwell Time.

Auto-switch will terminate once the alarm stops and you will be taken back to the Live View interface.



You must select during "Trigger Channel" settings the channel(s) you want to make full screen monitoring.

Audible Warning

Trigger an audible beep when an alarm is detected.

Notify Surveillance Center

Sends an exception or alarm signal to remote alarm host when an event occurs. The alarm host refers to the PC installed with Remote Client.



The alarm signal will be transmitted automatically at detection mode when remote alarm host is configured. Please refer to *Chapter 11.2.6 Configuring More Settings* for details of alarm host configuration.

Email Linkage

Send an email with alarm information to a user or users when an alarm is detected.

Please refer to Chapter 11.2.8 Configuring Email for details of Email configuration.

Trigger Alarm Output

Trigger an alarm output when an alarm is triggered.

Step 1 Enter Alarm Output interface.

Menu> Configuration> Alarm> Alarm Output

Step 2 Select an alarm output and set alarm name and dwell time. Click **Schedule** button to set the arming schedule of alarm output.



If "Manually Clear" is selected in the dropdown list of Dwell Time, you can clear it only by going to Menu> Manual> Alarm.



Figure 8-16 Alarm Output Setup Interface

Step 3 Set up arming schedule of the alarm output.

Choose one day of a week and up to 8 time periods can be set within each day.



Time periods shall not be repeated or overlapped.




Figure 8-17 Set Arming Schedule of Alarm Output

Step 4 Repeat the above steps to set up arming schedule of other days of a week. You can also use **Copy** button to copy an arming schedule to other days.

Click the **OK** button to complete the video tampering settings of the alarm output No..

Step 5 You can also copy the above settings to another channel.




Figure 8-18 Copy Settings of Alarm Output

8.7 Triggering or Clearing Alarm Output Manually

Purpose:

Sensor alarm can be triggered or cleared manually. If "Manually Clear" is selected in the dropdown list of dwell time of an alarm output, the alarm can be cleared only by clicking **Clear** button in the following interface.

Step 1 Select the alarm output you want to trigger or clear and make related operations.

Menu> Manual> Alarm

Step 2 Click Trigger/Clear button if you want to trigger or clear an alarm output.

Click **Trigger All** button if you want to trigger all alarm outputs.

Click Clear All button if you want to clear all alarm output.



Figure 8-19 Clear or Trigger Alarm Output Manually

Chapter 9 POS Configuration



The POS feature is supported by DS-9600/8600/7700/7600-I (/P) series NVR only.

9.1 Configuring POS Settings

Step 1 Enter the POS settings interface.

Menu > Configuration > POS> POS Settings

Step 2 Select the POS from the drop-down list.



The amount of POS devices supported for each device is the half of its channel amount, e.g., 8 POS devices are supported for the DS-9616NI-I8 model.

Step 3 Check the checkbox to enable the POS feature.




Figure 9-1 POS Settings

Step 4 Select the POS protocol to Universal Protocol, EPSON, AVE or NUCLEUS.



When the new protocol is selected, you should reboot the device to activate the new settings.

Universal Protocol

Click the Advanced button to expand more settings when selecting the universal protocol. You can set the start line tag, line break tag and end line tag for the POS overlay characters, and the case-sensitive property of the characters.




Figure 9-2 Universal Protocol Settings

EPSON

The fixed start and end line tag are used for EPSON protocol.

AVE

The fixed start and end line tag are used for AVE protocol. And the serial port and virtual serial port connection types are supported.

- 1) Click the **Set** to configure the AVE settings.
- 2) Se the rule to VSI-ADD or VNET.
- 3) Set the address bit of the POS message to send.
- 4) Click **OK** to save the settings.



Figure 9-3 AVE Settings

NUCLEUS

- 1) Click the **Set** to configure the NUCLEUS settings.
- 2) Enter the employee No. shift No. and the terminal No. in the field. The matching message sent from the POS device will be used as the valid POS data.



Figure 9-4 NUCLEUS Settings



The NUCLEUS protocol must be used in the RS-232 connection communication.

Step 5 Select the connection mode to TCP, UDP, Multicast, RS-232, USB->RS-232 or Sniff, and click **Set** to configure the parameters for each connection mode.

TCP Connection

- 1) When using TCP connection, the port must be set from 1 to 65535, and the port for each POS machine must be unique.
- 2) Set the Allowed Remote IP Address of the device sending the POS message.




Figure 9-5 TCP Connection Settings

UDP Connection

- 3) When using UDP connection, the port must be set from 1 to 65535, and the port for each POS machine must be unique.
- 4) Set the Allowed Remote IP Address of the device sending the POS message.




Figure 9-6 UDP Connection Settings

● USB->RS-232 Connection

Configure the port parameters of USB-to-RS-232 convertor, including the serial number of port, baud rate, data bit, stop bit, parity and flow ctrl.



Figure 9-7 USB-to-RS-232 Settings

RS-232 Connection

Connect the NVR and the POS machine via RS-232. The RS-232 settings can be configured in Menu>Configuration>RS-232. The Usage must be set to Transparent Channel.



Figure 9-8 RS-232 Settings

Multicast Connection

When connecting the NVR and the POS machine via Multicast protocol, set the multicast address and port.



Figure 9-9 Multicast Settings

Sniff Connection

Connect the NVR and the POS machine via Sniff. Configure the source address and destination address settings.




Figure 9-10 Sniff Settings

Step 6 Set other parameters of characters overly.

- 1) Select the character encoding format from the drop-down list.
- 2) Select the overlay mode of the characters to display in scrolling or page mode.

- 3) Select the font size to small, medium or large.
- 4) Set the overlay time of the characters. The value ranges 5 -3600 sec.
- 5) Set the delay time of POS event. The value ranges 5 -3600 sec. When the device has not received the POS message over the defined delay time, the transaction is finished.
- 6) (optional) Check the checkbox to enable the **POS Overlay in Live View**. When this feature is enabled, the POS information can be overlain on the live view image.
- 7) Select the font color for the characters.



Figure 9-11 Overlay Character Settings



You can adjust the size and position of textbox on the preview screen of POS settings interface by dragging the frame.

Step 7 Click **Apply** to activate the settings.

Step 8 (Optional) You can click the **Copy** button to copy the current settings to other POS (s).



Figure 9-12 Copy POS Settings

9.2 Configuring Overlay Channel

Purpose:

You can assign the POS machine to corresponding channel on which you want to overlay.

Step 1 Enter the POS settings interface.

Menu > Configuration > POS> Overlay Channel

Step 2 Click to select the IP camera from the camera list on the right, and then click a POS item from the POS device list you want to overlay the POS information on the selected camera.

Click or to go to the previous or next page of cameras.



Each POS device can be selected for one camera only.



Figure 9-13 Overlay Channel Settings

Step 3 You can also click to overlay all POS items to the first 8 channels in order. And the used to clear all POS overlay settings.

Step 4 Click the **Apply** button to save the settings.

9.3 Configuring POS Privacy Information Filtering

Purpose:

You can set the POS privacy information to not display on the image.

Step 1 Enter the POS settings interface.

Menu > Configuration > POS> POS Settings

Step 2 Click the button of the **Privacy Settings** to enter the POS privacy information filtering settings interface.



Figure 9-14 POS Privacy information filtering settings

Step 3 Edit three information text (1 to 32 characters) types in the field.

Step 4 Click OK to save the settings. The defined privacy information will be displayed in ***on the image instead.

9.4 Configuring POS Alarm

Purpose:

Set the POS alarm parameters to trigger certain channels to start recording, or trigger full screen monitoring, audio warning, notifying the surveillance center, sending email and so on.

Step 1 Enter the POS settings interface.

Menu > Configuration > POS> POS Settings

Step 2 Follow the steps in Chapter 9.1-9.2 to configure the POS settings.

Step 3 Click at to enter the alarm settings interface.



Figure 9-15 Set Trigger Cameras of POS

Step 4 Click **Trigger Channel** tab and select one or more channels to record or become full-screen monitoring when POS alarm is triggered.

Step 5 Set arming schedule of the channel.

Select **Arming Schedule** tab to set the channel's arming schedule.

Choose one day of a week and up to eight time periods can be set within each day. Or you can click the **Copy** button to copy the time period settings to other day(s).



Time periods shall not be repeated or overlapped.



Figure 9-16 Set Arming Schedule

Step 6 Click the **Handling** tab to set up alarm response actions of POS alarm.

Repeat the above steps to set up arming schedule of other days of a week.

Click the **OK** button to complete the POS settings of the channel.

Step 7 Select PTZ Linking tab and set PTZ linkage of the POS alarm.

Set PTZ linking parameters and click the **OK** button to complete the settings of the alarm input.



Please check whether the PTZ or speed dome supports PTZ linkage.




Figure 9-17 Set PTZ Linking

Step 8 Click **OK** to save the settings.

Chapter 10 VCA Alarm

The NVR supports the VCA detection alarm (face detection, vehicle detection, line crossing detection and intrusion detection, region entrance detection, region exiting detection, unattended baggage detection, object removal detection, audio loss exception detection, sudden change of sound intensity detection, and defocus detection) sent by IP camera. The VCA detection must be enabled and configured on the IP camera settings interface first.



- All VCA detection must be supported by the connected IP camera.
- Please refer to the User Manual of Network Camera for the detailed instructions for the all VCA detection types.

10.1 Face Detection

Purpose:

Face detection function detects the face appears in the surveillance scene, and some certain actions can be taken when the alarm is triggered.

Step 1 Enter the VCA settings interface.

Menu> Camera> VCA

Step 2 Select the camera to configure the VCA.

You can click the checkbox of **Save VCA Picture** to save the captured pictures of VCA detection.




Figure 10-1 Face Detection

- Step 3 Select the VCA detection type to **Face Detection**.
- Step 4 Check the **Enable** checkbox to enable this function.
- Step 5 Click to enter the face detection settings interface. Configure the trigger channel, arming schedule and linkage action for the face detection alarm. Please refer to step3~step5 of Chapter 8.1 Setting Motion Detection Alarm for detailed instructions.
- Step 6 Click the **Rule Settings** button to set the face detection rules. You can click-and-drag the slider to set the detection sensitivity.

Sensitivity: Range [1-5]. The higher the value is, the more easily the face can be detected.



Figure 10-2 Set Face Detection Sensitivity

Step 7 Click **Apply** to activate the settings.

10.2 Vehicle Detection

Purpose:

Vehicle Detection is available for the road traffic monitoring. In Vehicle Detection, the passed vehicle can be detected and the picture of its license plate can be captured. You can send alarm signal to notify the surveillance center and upload the captured picture to FTP server.

Step 1 Enter the VCA settings interface.

Menu> Camera> VCA

- Step 2 Select the camera to configure the VCA.
- Step 3 You can click the checkbox of **Save VCA Picture** to save the captured pictures of VCA detection.
- Step 4 Select the VCA detection type to **Vehicle Detection**.
- Step 5 Check the **Enable** checkbox to enable this function.




Figure 10-3 Set Vehicle Detection

Step 6 Click to configure the trigger channel, arming schedule and linkage actions for the Blacklist, Whitelist and Others.



Up to 2, 048 backlists or whitelists are supported for import and export.

Step 7 Click the **Rule Settings** to enter the rule settings interface. Configure the lane, upload picture and overlay content settings. Up to 4 lanes are selectable.



Figure 10-4 Rule Settings

Step 8 Click Save to save the settings.



Please refer to the User Manual of Network Camera for the detailed instructions for the vehicle detection.

10.3 Line Crossing Detection

Purpose:

This function can be used for detecting people, vehicles and objects cross a set virtual line. The line crossing direction can be set as bidirectional, from left to right or from right to left. And you can set the duration for the alarm response actions, such as full screen monitoring, audible warning, etc.

Step 1 Enter the VCA settings interface.

Menu> Camera> VCA

Step 2 Select the camera to configure the VCA.

You can click the checkbox of **Save VCA Picture** to save the captured pictures of VCA detection.

- Step 3 Select the VCA detection type to **Line Crossing Detection**.
- Step 4 Check the **Enable** checkbox to enable this function.
- Step 5 Click to configure the trigger channel, arming schedule and linkage actions for the line crossing detection alarm.

Step 6 Click the Rule Settings button to set the line crossing detection rules.

1) Select the direction to A<->B, A->B or A<-B.

A<->B: Only the arrow on the B side shows; when an object going across the configured line with both direction can be detected and alarms are triggered.

A->B: Only the object crossing the configured line from the A side to the B side can be detected.

B->A: Only the object crossing the configured line from the B side to the A side can be detected.

- Click-and-drag the slider to set the detection sensitivity.
 Sensitivity: Range [1-100]. The higher the value is, the more easily the detection alarm can be triggered.
- 3) Click-**OK** to save the rule settings and back to the line crossing detection settings interface.



Figure 10-5 Set Line Crossing Detection Rules

Step 7 Click and set two points in the preview window to draw a virtual line.

You can use the to clear the existing virtual line and re-draw it.



Up to 4 rules can be configured.




Figure 10-6 Draw Line for Line Crossing Detection

Step 8 Click **Apply** to activate the settings.

10.4 Intrusion Detection

Purpose:

Intrusion detection function detects people, vehicle or other objects which enter and loiter in a pre-defined virtual region, and some certain actions can be taken when the alarm is triggered.

Step 1 Enter the VCA settings interface.

Menu> Camera> VCA

Step 2 Select the camera to configure the VCA.

You can click the checkbox of **Save VCA Picture** to save the captured pictures of VCA detection.

- Step 3 Select the VCA detection type to Intrusion Detection.
- Step 4 Check the **Enable** checkbox to enable this function.
- Step 5 Click to configure the trigger channel, arming schedule and linkage actions for the line crossing detection alarm.
- Step 6 Click the **Rule Settings** button to set the intrusion detection rules. Set the following parameters.
 - 1) **Threshold:** Range [1s-10s], the threshold for the time of the object loitering in the region. When the duration of the object in the defined detection area is longer than the set time, the alarm will be triggered.
 - 2) Click-and-drag the slider to set the detection sensitivity.
 - 3) **Sensitivity:** Range [1-100]. The value of the sensitivity defines the size of the object which can trigger the alarm. The higher the value is, the more easily the detection alarm can be triggered.
 - 4) **Percentage:** Range [1-100]. Percentage defines the ratio of the in-region part of the object which can trigger the alarm. For example, if the percentage is set as 50%, when the object enters the region and occupies half of the whole region, the alarm is triggered.



Figure 10-7 Set Intrusion Crossing Detection Rules

5) Click-**OK** to save the rule settings and back to the line crossing detection settings interface.

Step 7 Click and draw a quadrilateral in the preview window by specifying four vertexes of the detection region, and right click to complete drawing. Only one region can be configured.

You can use the to clear the existing virtual line and re-draw it.



Up to 4 rules can be configured.




Figure 10-8 Draw Area for Intrusion Detection

Step 8 Click **Apply** to save the settings.

10.5 Region Entrance Detection

Purpose:

Region entrance detection function detects people, vehicle or other objects which enter a pre-defined virtual region from the outside place, and some certain actions can be taken when the alarm is triggered.

Step 1 Enter the VCA settings interface.

Menu> Camera> VCA

Step 2 Select the camera to configure the VCA.

You can click the checkbox of **Save VCA Picture** to save the captured pictures of VCA detection.

- Step 3 Select the VCA detection type to **Region Entrance Detection**.
- Step 4 Check the **Enable** checkbox to enable this function.
- Step 5 Click to configure the trigger channel, arming schedule and linkage actions for the line crossing detection alarm.
- Step 6 Click the **Rule Settings** button to set the sensitivity of the region entrance detection.

Sensitivity: Range [0-100]. The higher the value is, the more easily the detection alarm can be triggered.

Step 7 Click and draw a quadrilateral in the preview window by specifying four vertexes of the detection region, and right click to complete drawing. Only one region can be configured.

You can use the to clear the existing virtual line and re-draw it.




Figure 10-9 Set Region Entrance Detection



Up to 4 rules can be configured.

Step 8 Click **Apply** to save the settings.

10.6 Region Exiting Detection

Purpose:

Region exiting detection function detects people, vehicle or other objects which exit from a pre-defined virtual region, and some certain actions can be taken when the alarm is triggered.



- Please refer to the *Chapter 9.5 Region Entrance Detection* for operating steps to configure the region exiting detection.
- Up to 4 rules can be configured.

10.7 Unattended Baggage Detection

Purpose:

Unattended baggage detection function detects the objects left over in the pre-defined region such as the baggage, purse, dangerous materials, etc., and a series of actions can be taken when the alarm is triggered.

NOTE

- Please refer to the *Chapter 9.4 Intrusion Detection* for operating steps to configure the unattended baggage detection.
- The Threshold[5s-20s] in the Rule Settings defines the time of the objects left over in the region. If you set the value as 10, alarm is triggered after the object is left and stay in the region for 10s. And the Sensitivity defines the similarity degree of the background image. Usually, when the sensitivity is high, a very small object left in the region can trigger the alarm.
- Up to 4 rules can be configured.

10.8 Object Removal Detection

Purpose:

Object removal detection function detects the objects removed from the pre-defined region, such as the exhibits on display, and a series of actions can be taken when the alarm is triggered.



- Please refer to the *Chapter 9.4 Intrusion Detection* for operating steps to configure the object removal detection.
- The Threshold [5s-20s] in the Rule Settings defines the time of the objects removed from the region. If you set the value as 10, alarm is triggered after the object disappears from the region for 10s. And the Sensitivity defines the similarity degree of the background image. Usually, when the sensitivity is high, a very small object taken from the region can trigger the alarm.
- Up to 4 rules can be configured.

10.9 Audio Exception Detection

Purpose:

Audio exception detection function detects the abnormal sounds in the surveillance scene, such as the sudden increase / decrease of the sound intensity, and some certain actions can be taken when the alarm is triggered.

Step 1 Enter the VCA settings interface.

Menu> Camera> VCA

Step 2 Select the camera to configure the VCA.

You can click the checkbox of **Save VCA Picture** to save the captured pictures of VCA detection.

Step 3 Select the VCA detection type to **Audio Exception Detection**.

Step 4 Click to configure the trigger channel, arming schedule and linkage action for the face detection alarm.

Step 5 Click the Rule Settings button to set the audio exception rules.



Figure 10-10 Set Audio Exception Detection Rules

- 1) Check the checkbox of **Audio Input Exception** to enable the audio loss detection function.
- Check the checkbox of Sudden Increase of Sound Intensity Detection to detect the sound steep rise in the surveillance scene. You can set the detection sensitivity and threshold for sound steep rise.

Sensitivity: Range [1-100], the smaller the value is, the more severe the change should be to trigger the detection.

Sound Intensity Threshold: Range [1-100], it can filter the sound in the environment, the louder the environment sound, the higher the value should be. You can adjust it according to the real environment.

3) Check the checkbox of **Sudden Decrease of Sound Intensity Detection** to detect the sound steep drop in the surveillance scene. You can set the detection sensitivity[1-100] for sound steep drop.

Step 6 Click **Apply** to activate the settings.

10.10 Sudden Scene Change Detection

Purpose:

Scene change detection function detects the change of surveillance environment affected by the external factors; such as the intentional rotation of the camera, and some certain actions can be taken when the alarm is triggered.

NOTE

- Please refer to the *Chapter 9.2 Face Detection* for operating steps to configure the scene change detection.
- The **Sensitivity** in the Rule Settings ranges from 1 to 100, and the higher the value is, the more easily the change of scene can trigger the alarm.

10.11 Defocus Detection

Purpose:

The image blur caused by defocus of the lens can be detected, and some certain actions can be taken when the alarm is triggered.



- Please refer to the *Chapter 9.2 Face Detection* for operating steps to configure the defocus detection.
- The **Sensitivity** in the Rule Settings ranges from 1 to 100, and the higher the value is, the more easily the defocus image can trigger the alarm.

10.12 PIR Alarm

Purpose:

A PIR (Passive Infrared) alarm is triggered when an intruder moves within the detector's field of view. The heat energy dissipated by a person, or any other warm blooded creature such as dogs, cats, etc., can be detected.

Step 1 Enter the VCA settings interface.

Menu> Camera> VCA

Step 2 Select the camera to configure the VCA.

You can click the checkbox of **Save VCA Picture** to save the captured pictures of VCA detection.

Step 3 Select the VCA detection type to PIR Alarm.

- Step 4 Click to configure the trigger channel, arming schedule and linkage action for the PIR alarm.
- Step 5 Click the **Rule Settings** button to set the rules. Please refer to the *Chapter 9.2 Face Detection* for instructions.

Step 6 Click **Apply** to activate the settings.

Chapter 11 VCA Search

With the configured VCA detection, the NVR supports the VCA search for the behavior analysis, face capture, people counting and heat map results.

11.1 Face Search

Purpose:

When there are detected face picture captured and saved in HDD, you can enter the Face Search interface to search the picture and play the picture related video file according to the specified conditions.

Before you start:

Please refer to *Chapter 10.1* Face Detection for configuring the face detection.

Step 1 Enter the Face Search interface.

Menu >VCA Search > Face Search

Step 2 Select the camera (s) for the face search.




Figure 11-1 Face Search

Step 3 Specify the start time and end time for search the captured face pictures or video files.

Step 4 Click **Search** to start searching. The search results of face detection pictures are displayed in list or in chart.



Figure 11-2 Face Search Interface

Step 5 Play the face picture related video file.

You can double click on a face picture to play its related video file in the view window on the top right, or select a picture item and click to play it.

You can also click to stop the playing, or click to play the previous/next file.

Step 6 If you want to export the captured face pictures to local storage device, connect the storage device to the device and click **Export All** to enter the Export interface.

Click **Export** to export all face pictures to the storage device.

Please refer to Chapter 7 Backup for the operation of exporting files.



Figure 11-3 Export Files

11.2 Behavior Search

Purpose:

The behavior analysis detects a series of suspicious behavior based on VCA detection, and certain linkage methods will be enabled if the alarm is triggered.

Step 1 Enter the **Behavior Search** interface.

Menu>VCA Search> Behavior Search

Step 2 Select the camera (s) for the behavior search.

Step 3 Specify the start time and end time for searching the matched pictures.



Figure 11-4 Behavior Search Interface

Step 4 Select the VCA detection type from the dropdown list, including the line crossing detection, intrusion detection, unattended baggage detection, object removal detection, region entrance detection, region exiting detection, parking detection, loitering detection, people gathering detection and fast moving detection.

Step 5 Click Search to start searching. The search results of pictures are displayed in list or in chart.



Figure 11-5 Behavior Search Results

Step 6 Play the behavior analysis picture related video file.

You can double click on a picture from the list to play its related video file in the view window on the top right, or select a picture item and click to play it.

You can also click to stop the playing, or click to play the previous/next file.

Step 7 If you want to export the captured pictures to local storage device, connect the storage device to the device and click **Export All** to enter the Export interface.

Click **Export** to export all pictures to the storage device.

11.3 Plate Search

Purpose:

You can search and view the matched captured vehicle plate picture and related information according to the plate searching conditions including the start time/end time, country and plate No..

Step 1 Enter the Plate Search interface.

Menu>VCA Search> Plate Search

Step 2 Select the camera (s) for the plate search.

Step 3 Specify the start time and end time for searching the matched plate pictures.




Figure 11-6 Plate Search

Step 4 Select the country from the drop-down list for searching the location of the vehicle plate.

Step 5 Input the plate No. in the field for search.

Step 6 Click **Search** to start searching. The search results of detected vehicle plate pictures are displayed in list or in chart.



Please refer to the Step7-Step8 of Section 10.1 Face Search for the operation of the search results.

11.4 People Counting

Purpose:

The Counting is used to calculate the number of people entered or left a certain configured area and form in daily/weekly/monthly/annual reports for analysis.

- Step 1 Enter the Counting interface.
- Step 2 Menu>VCA Search>Counting
- Step 3 Select the camera for the people counting.
- Step 4 Select the report type to Daily Report, Weekly Report, Monthly Report or Annual Report.
- Step 5 Set the statistics time.
- Step 6 Click the **Counting** button to start people counting statistics.




Figure 11-7 People Counting Interface

Step 7 You can click the **Export** button to export the statistics report in excel format.

11.5 Heat Map

Purpose:

Heat map is a graphical representation of data represented by colors. The heat map function is usually used to analyze the visit times and dwell time of customers in a configured area.



The heat map function must be supported by the connected IP camera and the corresponding configuration must be set.

Step 1 Enter the Heat Map interface.

Menu > VCA Search > Heat Map

Step 2 Select the camera for the heat map processing.

Step 3 Select the report type to Daily Report, Weekly Report, Monthly Report or Annual Report.

Step 4 Set the statistics time.




Figure 11-8 Heat Map Interface

Step 5 Click the **Counting** button to export the report data and start heat map statistics, and the results are displayed in graphics marked in different colors.



As shown in the figure above, red color block (255, 0, 0) indicates the most welcome area, and blue color block (0, 0, 255) indicates the less-popular area.

Step 6 You can click the **Export** button to export the statistics report in excel format.

11.6 Advanced Search



The DS-7600/7700/8600/9600-I (/P) series NVR supports the advanced search for fire/ship/temperature/temperature difference detection triggered alarm and the recorded video files and pictures.

Before you start

To get the smart search result, the corresponding fire/ship temperature/temperature difference type must be enabled and configured on the connected thermal network camera (Configuration > Advanced Configuration > Smart Event). Please refer to the user manual of the thermal network camera for details.

Step 1 Enter the Advanced Search interface.

Menu > VCA Search > Advanced Search

Step 2 Select the camera (s) for the advanced search.



Figure 11-9 Advanced Search

Step 3 Specify the start time and end time for searching the thermal imaging detection results.

Step 4 Select the type to fire detection, ship detection, temperature detection and temperature difference detection.

Step 5 Click Search to start searching. The search results are displayed in list or in chart.



Figure 11-10 Search Results

Step 6 You can click the **Export** button to export the statistics report in excel format.

Chapter 12 Network Settings

12.1 Configuring General Settings

Purpose:

Network settings must be properly configured before you operate NVR over network.

Step 1 Enter the Network Settings interface.

Menu >Configuration>Network

Step 2 Select the General tab.




Figure 12-1 Network Settings Interface

Step 3 In the **General Settings** interface, you can configure the following settings: Working Mode, NIC Type, IPv4 Address, IPv4 Gateway, MTU, DNS DHCP and DNS Server.



The valid value range of MTU is 500 - 9676.

If the DHCP server is available, you can click the checkbox of **DHCP** to automatically obtain an IP address and other network settings from that server.

NOTE

- Two self-adaptive 10M/100M/1000M network interfaces for DS-9600NI-I8, DS-9600NI-I16, DS-8600NI-K8, DS-7700NI-I4 and DS-7700NI-K4, and the multi-address and network fault tolerance working modes are configurable.
- One self-adaptive 10M/100M/1000M network interface for DS-7600NI-K2/I2(/P), DS-7700NI-I4/P and DS-7700NI-K4/P.
- One self-adaptive 10M/100M network interface for DS-7600NI-K1 (/P).
- For the DS-7600NI-I(K)/P and DS-7700NI-I(I)/P series NVR, you need to configure the internal NIC address, so that IP addresses are assigned to the cameras connected to the PoE interfaces.

Step 4 After having configured the general settings, click **Apply** button to save the settings.

Working Mode

Two 10M/100M/1000M NIC cards are provided and it allows the device to work in the Multi-address and Net-fault Tolerance modes.

Multi-address Mode: The parameters of the two NIC cards can be configured independently. You can select LAN1 or LAN2 in the NIC type field for parameter settings.

You can select one NIC card as default route. And then the system is connecting with the extranet the data will be forwarded through the default route.

Net-fault Tolerance Mode: The two NIC cards use the same IP address, and you can select the Main NIC to LAN1 or LAN2. By this way, in case of one NIC card failure, the device will automatically enable the other standby NIC card so as to ensure the normal running of the whole system.

12.2 Configuring Advanced Settings

12.2.1 Configuring Hik-Connect

Purpose

Hik-Connect enables the mobile phone application and the service platform page (www.hik-connect.com) to access and manage your connected NVR, providing a convenient remote access to the surveillance system.



The Hik-Connect can be enabled via operation on SADP software, GUI and Web browser. We introduce the operation steps on GUI in this section.

Step 1 Enter the Network Settings interface.

Menu > Configuration > Network

Step 2 Select the **Platform Access** tab to enter the Hik-Connect Settings interface.




Figure 12-2 Hik-Connect Settings

Step 3 Check the **Enable** checkbox to activate the function. The **Service Terms** interface pops up as below.




Figure 12-3 Service Terms

- 1) Create the verification code and enter the code in the Verification Code text field.
- 2) Check the checkbox of The Hik-Connect service will require internet access. Please read Service Terms and Privacy Statement before enabling the service.
- 3) Scan the QR code on the interface to read the Service Terms and the Privacy Statement.
- 4) Click **OK** to save the settings and return to the Hik-Connect interface.

NOTE

- Hik-Connect is disabled by default.
- The verification code is empty when the device leaves factory.
- The verification code must contain 6 to 12 letters or numbers and is case sensitive.
- Every time you enable Hik-Connect, the Service Terms interface pops up and you should check the checkbox before enabling it.
- Step 4 (Optional) Check the checkbox of Custom and input the Server Address.
- Step 5 (Optional) Check the checkbox of **Enable Stream Encryption**. After this feature is enabled, the verification code is required for remote access and live view.



You can use the scanning tool of your phone to quickly get the code by scanning the QR code below.




Figure 12-4 Hik-Connect Settings Interface

Step 6 Click the **Apply** button to save the settings.

After configuration, you can access and manage the NVR by your mobile phone on which the Hik-Connect application is installed or by the website (www.hik-connect.com).



Please refer to the help file on the official website (www.hik-connect.com) and the *Hik-Connect Mobile Client User Manual* for adding the device to Hik-Connect and more operation instructions.

12.2.2 Configuring DDNS

Purpose:

You can set the Dynamic DNS (DDNS) for network access.

Prior registration with your ISP is required before configuring the system to use DDNS.

Step 1 Enter the Network Settings interface.

Menu > Configuration > Network

Step 2 Select the **DDNS** tab to enter the DDNS Settings interface.

Step 3 Check the **DDNS** checkbox to enable this feature.

Step 4 Select **DDNS Type**. Three DDNS types are selectable: DynDNS, PeanutHull, and NO-IP.

•DynDNS:

- 1) Enter **Server Address** for DynDNS (i.e. members.dyndns.org).
- 2) In the **Device Domain Name** text field, enter the domain obtained from the DynDNS website.
- 3) Enter the **User Name** and **Password** registered in the DynDNS website.



Figure 12-5 DynDNS Settings Interface

•PeanutHull: Enter the User Name and Password obtained from the PeanutHull website.



Figure 12-6 PeanutHull Settings Interface

•NO-IP:

Enter the account information in the corresponding fields. Refer to the DynDNS settings.

- 5) Enter Server Address for NO-IP.
- 6) In the **Device Domain Name** text field, enter the domain obtained from the NO-IP website (www.no-ip.com).
- 7) Enter the **User Name** and **Password** registered in the NO-IP website.




Figure 12-7 NO-IP Settings Interface

Step 5 Click the **Apply** button to save and exit the interface.

12.2.3 Configuring NTP Server

Purpose:

A Network Time Protocol (NTP) Server can be configured on your NVR to ensure the accuracy of system date/time.

Step 1 Enter the Network Settings interface.

Menu >Configuration > Network

Step 2 Select the NTP tab to enter the NTP Settings interface, as shown in Figure 12-8.



Figure 12-8 NTP Settings Interface

Step 3 Check the **Enable NTP** checkbox to enable this feature.

Step 4 Configure the following NTP settings:

Interval: Time interval between the two synchronizing actions with NTP server. The unit is minute.

NTP Server: IP address of NTP server.

NTP Port: Port of NTP server.

Step 5 Click the Apply button to save and exit the interface.



The time synchronization interval can be set from1 to 10080min, and the default value is 60min. If the NVR is connected to a public network, you should use a NTP server that has a time synchronization function, such as the server at the National Time Center (IP Address: 210.72.145.44). If the NVR is setup in a more customized network, NTP software can be used to establish a NTP server used for time synchronization.

12.2.4 Configuring SNMP

Purpose:

You can use SNMP protocol to get device status and parameters related information.

Step 1 Enter the Network Settings interface.

Menu > Configuration > Network

Step 2 Select the **SNMP** tab to enter the SNMP Settings interface, as shown in Figure 12-9.



Figure 12-9 SNMP Settings Interface

Step 3 Check the **SNMP** checkbox to enable this feature.

Step 4 The enabling of SNMP may cause security problems. Click **Yes** to continue or **No** to cancel the operation.



Figure 12-10 SNMP Settings Interface

Step 5 When you choose the Yes option in step4, configure the following SNMP settings:

Trap Address: IP Address of SNMP host.

Trap Port: Port of SNMP host.

Step 6 Click the **Apply** button to save and exit the interface.



Before setting the SNMP, please download the SNMP software and manage to receive the device information via SNMP port. By setting the Trap Address, the NVR is allowed to send the alarm event and exception message to the surveillance center.

12.2.5 Configuring More Settings

Step 1 Enter the Network Settings interface.

Menu > Configuration > Network

Step 2 Select the More Settings tab to enter the More Settings interface.



Figure 12-11 More Settings Interface

Step 3 Configure the remote alarm host, server port, HTTP port, multicast, RTSP port.

 Alarm Host IP/Port: With a remote alarm host configured, the device will send the alarm event or exception message to the host when an alarm is triggered. The remote alarm host must have the CMS (Client Management System) software installed.

The **Alarm Host IP** refers to the IP address of the remote PC on which the CMS (Client Management System) software (e.g., iVMS-4200) is installed, and the **Alarm Host Port** must be the same as the alarm monitoring port configured in the software (default port is 7200).

 Multicast IP: The multicast can be configured to realize live view for more than the maximum number of cameras through network. A multicast address spans the Class-D IP range of 224.0.0.0 to 239.255.255.255. It is recommended to use the IP address ranging from 239.252.0.0 to 239.255.255.255.

When adding a device to the CMS (Client Management System) software, the multicast address must be the same as the device's multicast IP.

 RTSP Port: The RTSP (Real Time Streaming Protocol) is a network control protocol designed for use in entertainment and communications systems to control streaming media servers.

Enter the RTSP port in the text field of **RTSP Port**. The default RTSP port is 554, and you can change it according to different requirements.

Server Port and HTTP Port: Enter the Server Port and HTTP Port in the text fields. The
default Server Port is 8000 and the HTTP Port is 80, and you can change them according
to different requirements.



The Server Port should be set to the range of 2000-65535 and it is used for remote client software access. The HTTP port is used for remote IE access.



Figure 12-12 Configure More Settings

Step 4 Click the **Apply** button to save and exit the interface.

12.2.6 Configuring HTTPS Port

Purpose:

HTTPS provides authentication of the web site and associated web server that one is communicating with, which protects against Man-in-the-middle attacks. Perform the following steps to set the port number of https.

Example:

If you set the port number as 443 and the IP address is 192.0.0.64, you may access the device by inputting https://192.0.0.64:443 via the web browser.



The HTTPS port can be only configured through the web browser.

- Step 1 Open web browser, input the IP address of device, and the web server will select the language automatically according to the system language and maximize the web browser.
- Step 2 Input the correct user name and password, and click Login button to log in the device.
- Step 3 Enter the HTTPS settings interface.
- Step 4 Configuration > Remote Configuration > Network Settings > HTTPS
- Step 5 Create the self-signed certificate or authorized certificate.




Figure 12-13 HTTPS Settings

OPTION 1: Create the self-signed certificate

1) Click the **Create** button to create the following dialog box.




Figure 12-14 Create Self-signed Certificate

2) Enter the country, host name/IP, validity and other information.

3) Click **OK** to save the settings.

OPTION 2: Create the authorized certificate

- 1) Click the Create button to create the certificate request.
- 2) Download the certificate request and submit it to the trusted certificate authority for signature.
- 3) After receiving the signed valid certificate, import the certificate to the device.

Step 6 There will be the certificate information after you successfully create and install the certificate.



Figure 12-15 Installed Certificate Property

Step 7 Check the checkbox to enable the HTTPS function.

Step 8 Click the **Save** button to save the settings.

12.2.7 Configuring Email

Purpose:

The system can be configured to send an Email notification to all designated users if an alarm event is detected, etc., an alarm or motion event is detected or the administrator password is changed.

Before configuring the Email settings, the NVR must be connected to a local area network (LAN) that maintains an SMTP mail server. The network must also be connected to either an intranet or the Internet depending on the location of the e-mail accounts to which you want to send notification.

Step 1 Enter the Network Settings interface.

Menu >Configuration> Network

Step 2 Set the IPv4 Address, IPv4 Subnet Mask, IPv4 Gateway and the Preferred DNS Server in the Network Settings menu, as shown in Figure 12-16.



Figure 12-16 Network Settings Interface

Step 3 Click **Apply** to save the settings.

Step 4 Select the Email tab to enter the Email Settings interface.



Figure 12-17 Email Settings Interface

Step 5 Configure the following Email settings:

Enable Server Authentication (optional): Check the checkbox to enable the server authentication feature.

User Name: The user name of sender's account registered on the SMTP server.

Password: The password of sender's account registered on the SMTP server.

SMTP Server: The SMTP Server IP address or host name (e.g., smtp.263xmail.com).

SMTP Port: The SMTP port. The default TCP/IP port used for SMTP is 25.

Enable SSL/TLS (optional): Click the checkbox to enable SSL/TLS if required by the SMTP server.

Sender: The name of sender.

Sender's Address: The Email address of sender.

Select Receivers: Select the receiver. Up to 3 receivers can be configured.

Receiver: The name of user to be notified.

Receiver's Address: The Email address of user to be notified.

Enable Attached Picture: Check the checkbox of **Enable Attached Picture** if you want to send email with attached alarm images. The interval is the time of two adjacent alarm images. You can also set SMTP port and enable SSL here.

Interval: The interval refers to the time between two actions of sending attached pictures.

Step 6 Click **Apply** button to save the Email settings.

Step 7 You can click **Test** button to test whether your Email settings work.

12.2.8 Configuring NAT

Purpose:

Two ways are provided for port mapping to realize the remote access via the cross-segment network, UPnP™ and manual mapping.

UPnPTM

Universal Plug and Play (UPnP[™]) can permit the device seamlessly discover the presence of other network devices on the network and establish functional network services for data sharing, communications, etc. You can use the UPnP[™] function to enable the fast connection of the device to the WAN via a router without port mapping.

Before you start:

If you want to enable the UPnP™ function of the device, you must enable the UPnP™ function of the router to which your device is connected. When the network working mode of the device is set as multi-address, the Default Route of the device should be in the same network segment as that of the LAN IP address of the router.

Step 1 Enter the Network Settings interface.

Menu > Configuration > Network

Step 2 Select the **NAT** tab to enter the port mapping interface.




Figure 12-18 UPnP™ Settings Interface

Step 3 Check checkbox to enable UPnP™.

Step 4 Select the Mapping Type as Manual or Auto in the drop-down list.

OPTION 1: Auto

If you select Auto, the Port Mapping items are read-only, and the external ports are set by the router automatically.

- 1) Select **Auto** in the drop-down list of Mapping Type.
- 2) Click **Apply** button to save the settings.
- 3) You can click **Refresh** button to get the latest status of the port mapping.




Figure 12-19 UPnP™ Settings Finished-Auto

OPTION 2: Manual

If you select Manual as the mapping type, you can edit the external port on your demand by clicking to activate the External Port Settings dialog box.

Steps:

- 1) Select **Manual** in the drop-down list of Mapping Type.
- 2) Click to activate the External Port Settings dialog box. Configure the external port No. for server port, http port, RTSP port and https port respectively.

NOTE

- You can use the default port No., or change it according to actual requirements.
- External Port indicates the port No. for port mapping in the router.
- The value of the RTSP port No. should be 554 or between 1024 and 65535, while the value of the other ports should be between 1 and 65535 and the value must be different from each other. If multiple devices are configured for the UPnP™ settings under the same router, the value of the port No. for each device should be unique.



Figure 12-20 External Port Settings Dialog Box

- 3) Click **Apply** button to save the settings.
- 4) You can click **Refresh** button to get the latest status of the port mapping.




Figure 12-21 UPnP™ Settings Finished-Manual

Step 5 Enter the virtual server setting page of router; fill in the blank of Internal Source Port with the internal port value, the blank of External Source Port with the external port value, and other required contents.



Each item should be corresponding with the device port, including server port, http port, RTSP port and https port.



Figure 12-22 Setting Virtual Server Item



The above virtual server setting interface is for reference only, it may be different due to different router manufactures. Please contact the manufacture of router if you have any problems with setting virtual server.

12.2.9 Configuring Virtual Host

Purpose:

You can directly get access to the IP camera management interface after enabling this function.



The Virtual host function can be only configured through the web browser.

Step 1 Enter the Advanced settings interface, as shown in the Figure 12-23.

Configuration > Network > Advanced Settings > Other




Figure 12-23 Advanced Settings Interface

- Step 2 Check the checkbox of the Enable Virtual Host.
- Step 3 Click the **Save** button to save the setting.
- Step 4 Enter the IP camera management interface of NVR. The Connect column appears on the right-most side of the camera list, as shown in the Figure 12-24.

Configuration > Remote Configuration > Camera Management > IP Camera




Figure 12-24 Connect to IP Camera

Step 5 Click the link and the page of IP camera management appears.

12.3 Checking Network Traffic

Purpose:

You can check the network traffic to obtain real-time information of NVR such as linking status, MTU, sending/receiving rate, etc.

Step 1 Enter the Network Traffic interface.

Menu > Maintenance > Net Detect




Figure 12-25 Network Traffic Interface

Step 2 You can view the sending rate and receiving rate information on the interface. The traffic data is refreshed every 1 second.

12.4 Configuring Network Detection

Purpose:

You can obtain network connecting status of NVR through the network detection function, including network delay, packet loss, etc.

12.4.1 Testing Network Delay and Packet Loss

Step 1 Enter the Network Traffic interface.

Menu >Maintenance>Net Detect

Step 2 Click the **Network Detection** tab to enter the Network Detection menu, as shown in Figure 12-26.



Figure 12-26 Network Detection Interface

- Step 3 Enter the destination address in the text field of **Destination Address**.
- Step 4 Click **Test** button to start testing network delay and packet loss. The testing result pops up on the window. If the testing is failed, the error message box will pop up as well. Refer to Figure 12-27.



Figure 12-27 Testing Result of Network Delay and Packet Loss

12.4.2 Exporting Network Packet

Purpose:

By connecting the NVR to network, the captured network data packet can be exported to USB-flash disk, SATA/eSATA, DVD-R/W and other local backup devices.

Step 1 Enter the Network Traffic interface.

Menu >Maintenance>Net Detect

- Step 2 Click the **Network Detection** tab to enter the Network Detection interface.
- Step 3 Select the backup device from the dropdown list of Device Name, as shown in Figure 12-28.



Click **Refresh** button if the connected local backup device cannot be displayed. When it fails to detect the backup device, please check whether it is compatible with the NVR. You can format the backup device if the format is incorrect.



Figure 12-28 Export Network Packet

Step 4 Click **Export** button to start exporting.

Step 5 After the exporting is complete, click **OK** to finish the packet export, as shown in Figure 12-29.



Figure 12-29 Packet Export Attention



Up to 1M data can be exported each time.

12.4.3 Checking the Network Status

Purpose:

You can also check the network status and quick set the network parameters in this interface.

Steps:

Click the **Status** button on the lower- right corner of the page.




Figure 12-30 Network Status Checking

If the network is normal the following message box pops out.



Figure 12-31 Network Status Checking Result

If the message box pops out with other information instead of this one, you can click **Network** button to show the quick setting interface of the network parameters.

12.4.4 Checking Network Statistics

Purpose:

You can check the network status to obtain the real-time information of NVR.

Step 1 Enter the Network Detection interface.

Menu>Maintenance>Net Detect

Step 2 Choose the Network Stat. tab.




Figure 12-32 Network Stat. Interface

Step 3 Check the bandwidth of IP Camera, bandwidth of Remote Live View, bandwidth of Remote Playback, bandwidth of Net Receive Idle and bandwidth of Net Send Idle.

Step 4 You can click **Refresh** to get the newest status.

Chapter 13 RAID

This chapter is applicable for DS-9600NI-I8 and DS-9600NI-I16 series NVR.

13.1 Configuring Array

Purpose:

RAID (redundant array of independent disks) is a storage technology that combines multiple disk drive components into a logical unit. A RAID setup stores data over multiple hard disk drives to provide enough redundancy so that data can be recovered if one disk fails. Data is distributed across the drives in one of several ways called "RAID levels", depending on what level of redundancy and performance is required.

The NVR supports the disk array that is realized by software. You can enable the RAID function on your demand.



The DS-9600NI-I8 and DS-9600NI-I16 series NVR support the RAID0, RAID1, RAID5, RAID6 and RAID 10 array types.

Before you start:

Please install the HDD(s) properly and it is recommended to use the same enterprise-level HDDs (including model and capacity) for array creation and configuration so as to maintain reliable and stable running of the disks.

Introduction:

The NVR can store the data (such as record, picture, log information) in the HDD only after you have created the array or you have configured network HDD (refer to Chapter14.2 Managing Network HDD). Our device provides two ways for creating array, including one-touch configuration and manual configuration. The following flow chart shows the process of creating array.




Figure 13-1 RAID Working Flow

13.1.2 Enable RAID

Purpose:

Perform the following steps to enable the RAID function, or the disk array cannot be created.



Use the enterprise-level HDDs to create the array.

OPTION 1:

Enable the RAID function in the Wizard when the device startup, please refer to step 7 of Chapter 2.2.

OPTION 2:

Enable the RAID function in the HDD Management Interface.

Step 1 Enter the disk mode configuration interface.

Menu > HDD > Advanced



Figure 13-2 Enable RAID Interface

Step 2 Check the checkbox of Enable RAID.

Step 3 Click the **Apply** button to save the settings.

13.1.3 One-touch Configuration

Purpose:

Through one-touch configuration, you can quickly create the disk array. By default, the array type to be created is RAID 5.

Before you start:

- The RAID function should be enabled, please refer to the Chapter 13.1.1 for details.
- As the default array type is RAID 5, please install at least 3 HDDs in you device.
- If more than 10 HDDs are installed, 2 arrays can be configured.

Step 1 Enter the RAID configuration interface.

Menu > HDD > RAID




Figure 13-3 Physical Disk Interface

Step 2 Check the checkbox of corresponding HDD No. to select it.

Step 3 Click the **One-touch Create** button to enter the One-touch Array Configuration interface.



Figure 13-4 One-touch Array Configuration

Step 4 Edit the array name in the **Array Name** text filed and click **OK** button to start configuring array.



If you install 4 HDDs or above for one-touch configuration, a hot spare disk will be set by default. It is recommended to set hot spare disk for automatically rebuilding the array when the array is abnormal.

Step 5 When the array configuration is completed, click **OK** button in the pop-up message box to finish the settings.

Step 6 You can click **Array** tab to view the information of the successfully created array.



By default, one-touch configuration creates an array and a virtual disk.



Figure 13-5 Array Settings Interface

Step 7 A created array displays as an HDD in the HDD information interface.




Figure 13-6 HDD Information Interface

13.1.4 Manually Creating Array

Purpose:

You can manually create the array of RAID 0, RAID 1, RAID 5, RAID6 and RAID 10.



In this section, we take RAID 5 as an example to describe the manual configuration of array and virtual disk.

Step 1 Enter the Physical Disk Settings interface.

Menu > HDD > RAID > Physical Disk




Figure 13-7 Physical Disk Settings Interface

Step 2 Click Creat button to enter the Create Array interface.




Table 13-1 Create Array Interface

Step 3 Edit the Array Name; set the RAID Level to RAID 0, RAID 1, RAID 5, RAID6 or RAID 10; select the Physical Disk that you want to configure array.

NOTE

- If you choose RAID 0, at least 2 HDDs must be installed.
- If you choose RAID 1, 2 HDDs need to be configured for RAID 1.
- If you choose RAID 5, at least 3 HDDs must be installed.
- If you choose RAID 6, at least 4 HDDs must be installed.
- If you choose RAID 10, the number of HDDs installed should be even in the range of 4 to 16.

Step 4 Click OK button to create array.

NOTE

If the number of HDDs you select is not compatible with the requirement of the RAID level, the error message box will pop up.



Figure 13-8 Error Message Box

Step 5 You can click Array tab to view the successfully created array.



Figure 13-9 Array Settings Interface

13.2 Rebuilding Array

Purpose:

The working status of array includes Functional, Degraded and Offline. By viewing the array status, you can take immediate and proper maintenance for the disks so as to ensure the high security and reliability of the data stored in the disk array.

When there is no disk loss in the array, the working status of array will change to Functional; when the number of lost disks has exceeded the limit, the working status of array will change to Offline; in other conditions, the working status is Degraded.

When the virtual disk is in Degraded status, you can restore it to Functional by array rebuilding.

Before you start:

Please make sure the hot spare disk is configured.

Step 1 Enter the Physical Disk Settings interface to configure the hot spare disk.




Figure 13-10 Physical Disk Settings Interface

Step 2 Select a disk and click disk to set it as the hot spare disk.



Only global hot spare mode is supported.

13.2.2 Automatically Rebuilding Array

Purpose:

When the virtual disk is in Degraded status, the device can start rebuilding the array automatically with the hot spare disk to ensure the high security and reliability of the data.

Enter the Array Settings interface(Menu > HDD > RAID > Array). The status of the array is Degraded. Since the hot spare disk is configured, the system will automatically start rebuilding using it.



Figure 1. 2 Array Settings Interface

If there is no hot spare disk after rebuilding, it is recommended to install a HDD into the device and set is as a hot spare disk to ensure the high security and reliability of the array.

13.2.3 Manually Rebuilding Array

Purpose:

If the hot spare disk has not been configured, you can rebuild the array manually to restore the array when the virtual disk is in Degraded status.

Step 1 Enter the Array Settings interface. The disk 3 is lost.

Menu > HDD > RAID > Array



Figure 13-11 Array Settings Interface

Step 2 Click Array tab to back to the Array Settings interface and click do to configure the array rebuild.



At least one available physical disk should exist for rebuilding the array.




Figure 13-12 Rebuild Array Interface

- Step 3 Select the available physical disk and click OK button to confirm to rebuild the array.
- Step 4 The "Do not unplug the physical disk when it is under rebuilding" message box pops up. Click OK button to start rebuilding.
- Step 5 You can enter the Array Settings interface to view the rebuilding status.
- Step 6 After rebuilding successfully, the array and virtual disk will restore to Functional.

13.3 Deleting Array



Deleting array will cause to delete all the data saved in the disk.

Step 1 Enter the Array Settings interface.

Menu>HDD>RAID>Array



Figure 13-13 Array Settings Interface

Step 2 Select an array and click uto delete the array.



Figure 13-14 Confirm Array Deletion

Step 3 In the pop-up message box, click Yes button to confirm the array deletion.



Deleting array will cause to delete all the data in the array.

13.4 Checking and Editing Firmware

Purpose:

You can view the information of the firmware and set the background task speed on the Firmware interface.

Step 1 Enter the Firmware interface to check the information of the firmware, including the version, maximum physical disk quantity, maximum array quantity, auto-rebuild status, etc.




Figure 13-15 Firmware Interface

Step 2 You can set the Background Task Speed in the drop-down list.

Step 3 Click the Apply button to save the settings.

Chapter 14 HDD Management

14.1 Initializing HDDs

Purpose:

A newly installed hard disk drive (HDD) must be initialized before it can be used with your NVR.



A message box pops up when the NVR starts up if there exits any uninitialized HDD.



Figure 14-1 Message Box of Uninitialized HDD

Click **Yes** button to initialize it immediately or you can perform the following steps to initialize the HDD.

Step 2 Enter the HDD Information interface.

Menu > HDD> General



Figure 14-2 HDD Information Interface

Step 3 Select HDD to be initialized.

Step 4 Click the Init button.



Figure 14-3 Confirm Initialization

Step 5 Select the **OK** button to start initialization.



Figure 14-4 Status changes to Initializing

Step 6 After the HDD has been initialized, the status of the HDD will change from *Uninitialized* to *Normal*.



Figure 14-5 HDD Status Changes to Normal



Initializing the HDD will erase all data on it.

14.2 Managing Network HDD

Purpose:

You can add the allocated NAS or disk of IP SAN to NVR, and use it as network HDD. Up to 8 network disks can be added.

Step 1 Enter the HDD Information interface.

Menu > HDD>General



Figure 14-6 HDD Information Interface

Step 2 Click the Add button to enter the Add NetHDD interface, as shown in Figure 14-7.




Figure 14-7 HDD Information Interface

Step 3 Add the allocated NetHDD.

Step 4 Select the type to NAS or IP SAN.

Step 5 Configure the NAS or IP SAN settings.

- Add NAS disk:
- 1) Enter the NetHDD IP address in the text field.
- 2) Click the Search button to search the available NAS disks.
- 3) Select the NAS disk from the list shown below.
- 4) Or you can just manually enter the directory in the text field of NetHDD Directory.
- 5) Click the **OK** button to add the configured NAS disk.



Figure 14-8 Add NAS Disk

Add IP SAN:

- 1) Enter the NetHDD IP address in the text field.
- 2) Click the Search button to search the available IP SAN disks.
- 3) Select the IP SAN disk from the list shown below.
- 4) Click the **OK** button to add the selected IP SAN disk.



Up to 1 IP SAN disk can be added.




Figure 14-9 Add IP SAN Disk

Step 6 After having successfully added the NAS or IP SAN disk, return to the HDD Information menu. The added NetHDD will be displayed in the list.



If the added NetHDD is uninitialized, please select it and click the **Init** button for initialization.



Figure 14-10 Initialize Added NetHDD

14.3 Managing eSATA

Purpose:

When there is an external eSATA device connected to NVR, you can configure eSATA for the use of Record/Capture or Export, and you can manage the eSATA in the NVR.

Step 1 Enter the Advanced Record Settings interface.

Menu >Record>Advanced

Step 2 Select the eSATA type to Export or Record/Capture from the dropdown list of eSATA.

Export: use the eSATA for backup. Refer to *Backup using eSATA HDDs* in *Chapter Backing up by Normal Video/Picture* Search for operating instructions.

Record/Capture: use the eSATA for record/capture. Refer to the following steps for operating instructions.



Figure 14-11 Set eSATA Mode

Step 3 When the eSATA type is selected to Record/Capture, enter the HDD Information interface.

Menu > HDD>General

Step 4 Edit the property of the selected eSATA, or initialize it is required.



Two storage modes can be configured for the eSATA when it is used for Record/Capture. Please refer to *Chapter Managing HDD Group* and *Chapter Configuring Quota Mode* for details.



Figure 14-12 Initialize Added eSATA

14.4 Managing HDD Group

14.4.1 Setting HDD Groups

Purpose:

Multiple HDDs can be managed in groups. Video from specified channels can be recorded onto a particular HDD group through HDD settings.

Step 1 Enter the Storage Mode interface.

Menu > HDD > Advanced > Storage Mode

Step 2 Set the Mode to Group, as shown in Figure 14-13.



Figure 14-13 Storage Mode Interface

Step 3 Click the **Apply** button and the following Attention box will pop up.



Figure 14-14 Attention for Reboot

Step 4 Click the **Yes** button to reboot the device to activate the changes.

Step 5 After reboot of device, enter the HDD Information interface.

Menu > HDD> General

Step 6 Select HDD from the list and click icon to enter the Local HDD Settings interface, as shown in Figure 14-15.




Figure 14-15 Local HDD Settings Interface

Step 7 Select the Group number for the current HDD.



The default group No. for each HDD is 1.

Step 8 Click the **OK** button to confirm the settings.



Figure 14-16 Confirm HDD Group Settings

Step 9 In the pop-up Attention box, click the **Yes** button to finish the settings.

14.4.2 Setting HDD Property

Purpose:

The HDD property can be set to redundancy, read-only or read/write (R/W). Before setting the HDD property, please set the storage mode to Group (refer to step1-4 of Chapter Setting HDD Groups).

A HDD can be set to read-only to prevent important recorded files from being overwritten when the HDD becomes full in overwrite recording mode.

When the HDD property is set to redundancy, the video can be recorded both onto the redundancy HDD and the R/W HDD simultaneously so as to ensure high security and reliability of video data.

Step 1 Enter the HDD Information interface.

Menu > HDD> General

Step 2 Select HDD from the list and click the icon to enter the Local HDD Settings interface, as shown in Figure 14-17.



Figure 14-17 Set HDD Property

Step 3 Set the HDD property to R/W, Read-only or Redundancy.

Step 4 Click the **OK** button to save the settings and exit the interface.

Step 5 In the HDD Information menu, the HDD property will be displayed in the list.



At least 2 hard disks must be installed on your NVR when you want to set a HDD to Redundancy, and there is one HDD with R/W property.

14.5 Configuring Quota Mode

Purpose:

Each camera can be configured with allocated quota for the storage of recorded files or captured pictures.

Step 1 Enter the Storage Mode interface.

Menu > HDD > Advanced

Step 2 Set the Mode to Quota, as shown in Figure 14-18.



The NVR must be rebooted to enable the changes to take effect.



Figure 14-18 Storage Mode Settings Interface

Step 3 Select a camera for which you want to configure quota.

Step 4 Enter the storage capacity in the text fields of Max. Record Capacity (GB) and Max. Picture Capacity (GB), as shown in Figure 14-19.




Figure 14-19 Configure Record/Picture Quota

Step 5 You can copy the quota settings of the current camera to other cameras if required. Click the **Copy** button to enter the Copy Camera menu, as shown in Figure 14-20.



Figure 14-20 Copy Settings to Other Camera(s)

Step 6 Select the camera (s) to be configured with the same quota settings. You can also click the checkbox of IP Camera to select all cameras.

Step 7 Click the **OK** button to finish the Copy settings and back to the Storage Mode interface.

Step 8 Click the **Apply** button to apply the settings.



If the quota capacity is set to 0, then all cameras will use the total capacity of HDD for record and picture capture.

14.6 Configuring Disk Clone

Purpose:

If the S.M.A.R.T. detection result declares the HDD is abnormal, you can choose to clone all the data on the HDD to an inserted eSATA disk manually. Refer to *Chapter 12.8 HDD Detection* for details of S.M.A.R.T detection.

Before you start:

An eSATA disk should be connected to the device.

Step 1 Enter the HDD Advanced Setting interface:

Menu > HDD > Advanced

Step 2 Click the **Disk Clone** tab to enter the disk clone configuring interface.




Figure 14-21 Disk Clone Configuration Interface

Step 3 Make sure the usage of the eSATA disk is set as Export.

If not, click the **Set** button to set it. Choose Export and click the **OK** button.



Figure 14-22 Setting eSATA Usage



The capacity of destination disk must be the same as that of the clone source disk.

Step 4 Check the checkbox of the HDD to be cloned in the Clone Source list.

Step 5 Click the Clone button and a message box pops up.



Figure 14-23 Message Box for Disk Clone

Step 6 Click the Yes button to continue.

You can check the clone progress in the HDD status.



Figure 14-24 Check Disk Clone Progress

14.7 Checking HDD Status

Purpose:

You may check the status of the installed HDDs on NVR so as to take immediate check and maintenance in case of HDD failure.

Checking HDD Status in HDD Information Interface

Step 1 Enter the HDD Information interface.

Menu > HDD>General

Step 2 Check the status of each HDD which is displayed on the list, as shown in Figure 14-25.




Figure 14-25 View HDD Status (1)



If the status of HDD is *Normal* or *Sleeping*, it works normally. If the status is *Uninitialized* or *Abnormal*, please initialize the HDD before use. And if the HDD initialization is failed, please replace it with a new one.

Checking HDD Status in HDD Information Interface

Step 3 Enter the System Information interface.

Menu > Maintenance > System Info

Step 4 Click the **HDD** tab to view the status of each HDD displayed on the list, as shown in Figure 14-26.




Figure 14-26 View HDD Status (2)

14.8 HDD Detection

Purpose:

The device provides the HDD detection function such as the adopting of the S.M.A.R.T. and the Bad Sector Detection technique. The S.M.A.R.T. (Self-Monitoring, Analysis and Reporting Technology) is a monitoring system for HDD to detect and report on various indicators of reliability in the hopes of anticipating failures.

S.M.A.R.T. Settings

Step 1 Enter the S.M.A.R.T Settings interface.

Menu > Maintenance > HDD Detect

Step 2 Select the HDD to view its S.M.A.R.T information list, as shown in Figure 14-27.




Figure 14-27 S.M.A.R.T Settings Interface

The related information of the S.M.A.R.T. is shown on the interface.

You can choose the self-test types as Short Test, Expanded Test or the Conveyance Test.

Click the start button to start the S.M.A.R.T. HDD self-evaluation.





If you want to use the HDD even when the S.M.A.R.T. checking is failed, you can check the checkbox of the **Continue to use the disk when self-evaluation is failed** item.

Bad Sector Detection

Step 3 Click the Bad Sector Detection tab.

Step 4 Select the HDD No. in the dropdown list you want to configure, and choose All Detection or Key Area Detection as the detection type.

Step 5 Click the **Detect** button to start the detection.




Figure 14-28 Bad Sector Detection

And you can click **Error info** button to see the detailed damage information.

And you can also pause/resume or cancel the detection.

14.9 Configuring HDD Error Alarms

Purpose:

You can configure the HDD error alarms when the HDD status is *Uninitialized* or *Abnormal*.

Step 1 Enter the Exception interface.

Menu > Configuration > Exceptions

Step 2 Select the Exception Type to **HDD Error** from the dropdown list.

Step 3 Click the checkbox(s) below to select the HDD error alarm type (s), as shown in Figure 14-29.



The alarm type can be selected to: Audible Warning, Notify Surveillance Center, Send Email and Trigger Alarm Output. Please refer to *Chapter Setting Alarm Response Actions*.




Figure 14-29 Configure HDD Error Alarm

Step 4 When the Trigger Alarm Output is selected, you can also select the alarm output to be triggered from the list below.

Step 5 Click the **Apply** button to save the settings

Chapter 15 Camera Settings

15.1 Configuring OSD Settings

Purpose:

You can configure the OSD (On-screen Display) settings for the camera, including date /time, camera name, etc.

Step 1 Enter the OSD Configuration interface.

Menu > Camera > OSD

Step 2 Select the camera to configure OSD settings.

Step 3 Edit the Camera Name in the text field.

Step 4 Configure the Display Name, Display Date and Display Week by clicking the checkbox.

Step 5 Select the Date Format, Time Format and Display Mode.




Figure 15-1 OSD Configuration Interface

Step 6 You can use the mouse to click and drag the text frame on the preview window to adjust the OSD position.

Step 7 Click the **Apply** button to apply the settings.

15.2 Configuring Privacy Mask

Purpose:

You are allowed to configure the four-sided privacy mask zones that cannot be viewed by the operator. The privacy mask can prevent certain surveillance areas to be viewed or recorded.

Step 1 Enter the Privacy Mask Settings interface.

Menu > Camera > Privacy Mask

Step 2 Select the camera to set privacy mask.

Step 3 Click the checkbox of **Enable Privacy Mask** to enable this feature.



Figure 15-2 Privacy Mask Settings Interface

Step 4 Use the mouse to draw a zone on the window. The zones will be marked with different frame colors.



Up to 4 privacy masks zones can be configured and the size of each area can be adjusted.

Step 5 The configured privacy mask zones on the window can be cleared by clicking the corresponding Clear Zone1-4 icons on the right side of the window, or click **Clear All** to clear all zones.



Figure 15-3 Set Privacy Mask Area

Step 6 Click the **Apply** button to save the settings.

15.3 Configuring Video Parameters

Purpose:

You can customize the image parameters including the brightness, contrast, saturation, image rotate and mirror for the live view and recording effect.

Step 1 Enter the Image Settings interface.

Menu > Camera > Image



Figure 15-4 Image Settings Interface

- Step 2 Select the camera to set image parameters.
- Step 3 Adjust the slider or click on the up/down arrow to set the value of the brightness, contrast or saturation.
- Step 4 Select the **Enable Rotate** function to Clockwise 270 degrees or OFF. When OFF is selected, the image is restored to original.
- Step 5 Select the **Mirror Mode** to Left-Right, Up-Down, Center or OFF. When OFF is selected, the image is restored to original.



- The Rotate and Mirror functions must be supported by the connected IP camera.
- The image parameters adjustment can affect both the live view and the recording quality.

Step 6 Click the **Apply** button to save the settings.

Chapter 16 NVR Management and Maintenance

16.1 Viewing System Information

Step 1 Enter the System Information interface.

Menu > Maintenance > System Info

Step 2 You can click the **Device Info**, **Camera**, **Record**, **Alarm**, **Network** and **HDD** tabs to view the system information of the device.




Figure 16-1 Device Information Interface



You can add the device to your mobile client software (iVMS-4500) via scanning the QR Code.

16.2 Searching & Exporting Log Files

Purpose:

The operation, alarm, exception and information of the NVR can be stored in log files, which can be viewed and exported at any time.

Step 1 Enter the Log Search interface.

Menu > Maintenance > Log Information



Figure 16-2 Log Search Interface

- Step 2 Set the log search conditions to refine your search, including the Start Time, End Time, Major Type and Minor Type.
- Step 3 Click the **Search** button to start search log files.
- Step 4 The matched log files will be displayed on the list shown below.




Figure 16-3 Log Search Results



Up to 2000 log files can be displayed each time.

Step 5 You can click the button of each log or double click it to view its detailed information, as shown in Figure 16-4. And you can also click the button to view the related video files if available.




Figure 16-4 Log Details

Step 6 If you want to export the log files, click the **Export** button to enter the Export menu, as shown in Figure 16-4 Log Details.

You can also click **Export All** on the Log Search interface (Figure 15.2) to enter the Export interface (Figure 15.5), and all the system logs will be exported to the backup device.



Figure 16-5 Export Log Files

- Step 7 Select the backup device from the dropdown list of **Device Name**.
- Step 8 Select the format of the log files to be exported. Up to 15 formats are selectable.
- Step 9 Click the **Export** to export the log files to the selected backup device.

You can click the **New Folder** button to create new folder in the backup device, or click the **Format** button to format the backup device before log export.



Please connect the backup device to NVR before operating log export.

16.3 Importing/Exporting IP Camera Info

Purpose:

The information of added IP camera can be generated into an excel file and exported to the local device for backup, including the IP address, manage port, password of admin, etc.. And the exported file can be edited on your PC, like adding or deleting the content, and copy the setting to other devices by importing the excel file to it.

Step 1 Enter the camera management interface.

Menu > Camera > IP Camera Import/Export

- Step 2 Click the IP Camera Import/Export tab, the content of detected plugged external device appears.
- Step 3 Click the **Export** button to export configuration files to the selected local backup device.
- Step 4 To import a configuration file, select the file from the selected backup device and click the **Import** button. After the importing process is completed, you must reboot the NVR.

16.4 Importing/Exporting Configuration Files

Purpose:

The configuration files of the NVR can be exported to local device for backup; and the configuration files of one NVR can be imported to multiple NVR devices if they are to be configured with the same parameters.

Step 1 Enter the Import/Export Configuration File interface.

Menu > Maintenance > Import/Export




Figure 16-6 Import/Export Config File

Step 2 Click the **Export** button to export configuration files to the selected local backup device.

Step 3 To import a configuration file, select the file from the selected backup device and click the **Import** button. After the import process is completed, you must reboot the NVR.



After having finished the import of configuration files, the device will reboot automatically.

16.5 Upgrading System

Purpose:

The firmware on your NVR can be upgraded by local backup device or remote FTP server.

16.5.1 Upgrading by Local Backup Device

Step 1 Connect your NVR with a local backup device where the update firmware file is located.

Step 2 Enter the Upgrade interface.

Step 3 Menu > Maintenance > Upgrade

Step 4 Click the Local Upgrade tab to enter the local upgrade menu, as shown in Figure 16-7.




Figure 16-7 Local Upgrade Interface

Step 5 Select the update file from the backup device.

Step 6 Click the **Upgrade** button to start upgrading.

Step 7 After the upgrading is complete, reboot the NVR to activate the new firmware.

16.5.2 Upgrading by FTP

Before you start:

Ensure the network connection of the PC (running FTP server) and the device is valid and correct. Run the FTP server on the PC and copy the firmware into the corresponding directory of your PC.

Step 1 Enter the Upgrade interface.

Menu > Maintenance > Upgrade

Step 2 Click the FTP tab to enter the local upgrade interface, as shown in Figure 16-8.



Figure 16-8 FTP Upgrade Interface

- Step 3 Enter the FTP Server Address in the text field.
- Step 4 Click the **Upgrade** button to start upgrading.
- Step 5 After the upgrading is complete, reboot the NVR to activate the new firmware.

16.6 Restoring Default Settings

Step 1 Enter the Default interface.

Menu > Maintenance > Default




Figure 16-9 Restore Defaults

Step 2 Select the restoring type from the following three options.

Restore Defaults: Restore all parameters, except the network (including IP address, subnet mask, gateway, MTU, NIC working mode, default route, server port, etc.) and user account parameters, to the factory default settings.

Factory Defaults: Restore all parameters to the factory default settings.

Restore to Inactive: Restore the device to the inactive status.

Step 3 Click the **OK** button to restore the default settings.



The device will reboot automatically after restoring to the default settings.

Chapter 17 Others

17.1 Configuring RS-232 Serial Port



The RS-232 serial port is not supported by DS-7600NI series NVR.

Purpose:

The RS-232 port can be used in two ways:

- Parameters Configuration: Connect a PC to the NVR through the PC serial port. Device parameters can be configured by using software such as HyperTerminal. The serial port parameters must be the same as the NVR's when connecting with the PC serial port.
- Transparent Channel: Connect a serial device directly to the NVR. The serial device will be controlled remotely by the PC through the network and the protocol of the serial device.

Step 1 Enter the RS-232 Settings interface.

Menu > Configuration > RS-232



Figure 17-1 RS-232 Settings Interface

Step 2 Configure RS-232 parameters, including baud rate, data bit, stop bit, parity, flow control and usage.

Step 3 Click the **Apply** button to save the settings.

17.2 Configuring General Settings

Purpose:

You can configure the BNC output standard, VGA output resolution, mouse pointer speed through the Menu > Configuration > General interface.

Step 1 Enter the General Settings interface.

Menu > Configuration > General

Step 2 Select the **General** tab.




Figure 17-2 General Settings Interface (DS-9600NI and DS-8600NI)



Figure 17-3 General Settings Interface (DS-7600NI and DS-7700NI)

Step 3 Configure the following settings:

Language: The default language used is English.

Output Standard: Select the output standard to NTSC or PAL, which must be the same with the video input standard.

Resolution: For the DS-9600NI and DS-8600NI series NVR, you can configure the VGA/HDMI resolution and VGA2/HDMI 2 resolution. And up to 4K (3840×2160) resolution is selectable for the VGA/HDMI output.

For the DS-7600NI and DS-7700NI series NVR, you can configure the VGA resolution and HDMI resolution respectively. And up to 4K (3840×2160) resolution is selectable for the HDMI output.

Time Zone: Select the time zone.

Date Format: Select the date format.

System Date: Select the system date.

System Time: Select the system time.

Mouse Pointer Speed: Set the speed of mouse pointer; 4 levels are configurable.

Enable Wizard: Enable/disable the Wizard when the device starts up.

Enable Password: Enable/disable the use of the login password.

Step 4 Click the **Apply** button to save the settings.

17.3 Configuring DST Settings

Step 1 Enter the General Settings interface.

Menu >Configuration>General

Step 2 Choose **DST Settings** tab.



Figure 17-4 DST Settings Interface

You can check the checkbox before the Auto DST Adjustment item.

Or you can manually check the Enable DST checkbox, and then you choose the date of the DST period.

17.4 Configuring More Settings

Step 1 Enter the General Settings interface.

Menu > Configuration > General

Step 2 Click the More Settings tab to enter the More Settings interface.



Figure 17-5 More Settings Interface

Step 3 Configure the following settings:

Device Name: Edit the name of NVR.

Device No.: Edit the serial number of NVR. The Device No. can be set in the range of 1~255, and the default No. is 255. The number is used for the remote and keyboard control.

Auto Logout: Set timeout time for menu inactivity. E.g., when the timeout time is set to 5 *Minutes*, then the system will exit from the current operation menu to live view screen after 5 minutes of menu inactivity.

Enable HDMI/VGA Simultaneous Output (for DS-9600NI and DS-8600NI only): By default, the video outputs from HDMI and VGA interfaces can be operated separately. You can set the simultaneous output for the HDMI and VGA by checking the checkbox of the option.

Menu Output Mode: You can choose the menu display on different video output.

For the DS-9600NI and DS-8600NI series NVR, you can select the menu output mode to **VGA/HDMI**, **VGA2/HDMI2**.

And for the DS-7600NI and DS-7600NI series NVR, you can select the menu output mode to **VGA**, **HDMI** or **Auto**. When the **Auto** option is selected and both HDMI and VGA outputs are connected, the device will detect and set the HDMI as the menu output.

Step 4 Click the **Apply** button to save the settings.

17.5 Managing User Accounts

Purpose:

There is a default account in the NVR: *Administrator*. The *Administrator* user name is *admin* and the password is set when you start the device for the first time. The *Administrator* has the permission to add and delete user and configure user parameters.

17.5.1 Adding a User

Step 1 Enter the User Management interface.

Menu >Configuration>User




Figure 17-6 User Management Interface

Step 2 Click the Add button to enter the Add User interface.




Figure 17-7 Add User Menu

Step 3 Enter the information for new user, including **User Name**, **Admin Password**, **Password**, **Confirm**, **Level** and **User's MAC Address**.

Password: Set the password for the user account.



WARNING

<u>Strong Password recommended</u>—We highly recommend you create a strong password of your own choosing (Using a minimum of 8 characters, including at least three of the following categories: upper case letters, lower case letters, numbers, and special characters.) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

• **Level:** Set the user level to Operator or Guest. Different user levels have different operating permission.

Operator: The *Operator* user level has permission of Two-way Audio in Remote Configuration and all operating permission in Camera Configuration by default.

Guest: The Guest user has no permission of Two-way Audio in Remote Configuration and only has the local/remote playback in the Camera Configuration by default.

 User's MAC Address: The MAC address of the remote PC which logs onto the NVR. If it is configured and enabled, it only allows the remote user with this MAC address to access the NVR.

Step 4 Click the **OK** button to save the settings and go back to the User Management interface. The added new user will be displayed on the list, as shown in Figure 17-8.



Figure 17-8 Added User Listed in User Management Interface

Step 5 Select the user from the list and then click the button to enter the Permission settings interface, as shown in Figure 17-9.



Figure 17-9 User Permission Settings Interface

Step 6 Set the operating permission of Local Configuration, Remote Configuration and Camera Configuration for the user.

Local Configuration

Local Log Search: Searching and viewing logs and system information of NVR.

Local Parameters Settings: Configuring parameters, restoring factory default parameters and importing/exporting configuration files.

Local Camera Management: The adding, deleting and editing of IP cameras.

Local Advanced Operation: Operating HDD management (initializing HDD, setting HDD property), upgrading system firmware, clearing I/O alarm output.

Local Shutdown Reboot: Shutting down or rebooting the NVR.

Remote Configuration

Remote Log Search: Remotely viewing logs that are saved on the NVR.

Remote Parameters Settings: Remotely configuring parameters, restoring factory default parameters and importing/exporting configuration files.

Remote Camera Management: Remote adding, deleting and editing of the IP cameras.

Remote Serial Port Control: Configuring settings for RS-232 and RS-485 ports.

Remote Video Output Control: Sending remote button control signal.

Two-Way Audio: Realizing two-way radio between the remote client and the NVR.

- **Remote Alarm Control**: Remotely arming (notify alarm and exception message to the remote client) and controlling the alarm output.
- **Remote Advanced Operation**: Remotely operating HDD management (initializing HDD, setting HDD property), upgrading system firmware, clearing I/O alarm output.
- Remote Shutdown/Reboot: Remotely shutting down or rebooting the NVR.
- Camera Configuration

Remote Live View: Remotely viewing live video of the selected camera (s).

Local Manual Operation: Locally starting/stopping manual recording and alarm output of the selected camera (s).

Remote Manual Operation: Remotely starting/stopping manual recording and alarm output of the selected camera (s).

Local Playback: Locally playing back recorded files of the selected camera (s).

Remote Playback: Remotely playing back recorded files of the selected camera (s).

Local PTZ Control: Locally controlling PTZ movement of the selected camera (s).

Remote PTZ Control: Remotely controlling PTZ movement of the selected camera (s).

Local Video Export: Locally exporting recorded files of the selected camera (s).

Step 7 Click the **OK** button to save the settings and exit interface.



Only the admin user account has the permission of restoring factory default parameters.

17.5.2 Deleting a User

Step 1 Enter the User Management interface.

Menu >Configuration>User

Step 2 Select the user to be deleted from the list, as shown in Figure 17-10.




Figure 17-10 User List

Step 3 Click the inicon to delete the selected user account.

17.5.3 Editing a User

For the added user accounts, you can edit the parameters.

Step 1 Enter the User Management interface.

Menu >Configuration>User

Step 2 Select the user to be edited from the list, as shown in Figure 17-10.

Step 3 Click the icon to enter the Edit User interface, as shown in Figure 17-12.



Figure 17-11 Edit User (Operator/Guest)




Figure 17-12 Edit User (admin)

Step 4 Edit the password for the user

Operator and Guest

You can edit the user information, including user name, password, permission level and MAC address. Check the checkbox of **Change Password** if you want to change the password, and input the new password in the text field of **Password** and **Confirm**. A strong password is recommended.

Admin

You are only allowed to edit the password and MAC address. Check the checkbox of **Change Password** if you want to change the password, and the input the correct old password, and the new password in the text field of **Password** and **Confirm**.



<u>Strong Password recommended</u>—We highly recommend you create a strong password of your own choosing (Using a minimum of 8 characters, including at least three of the following categories: upper case letters, lower case letters, numbers, and special characters.) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Step 5 Edit the unlock pattern for the admin user account.

- 1) Check the checkbox of **Enable Unlock Pattern** to enable the use of unlock pattern when logging in to the device.
- 2) Use the mouse to draw a pattern among the 9 dots on the screen. Release the mouse when the pattern is done.



Please refer to Chapter 2.3.1 Configuring the Unlock Pattern for detailed instructions.




Figure 17-13 Set Unlock Patter for Admin User

Step 6 Click the of **Export GUID** to enter the reset password interface to export the GUID file for the admin user account.

When the admin password is changed, you can re-export the GUID file to the connected U flash disk for the future password resetting. Please refer to Chapter 2.1.5 Resetting Your Password for details.

Step 7 Click the **OK** button to save the settings and exit the menu.

Step 8 For the **Operator** or **Guest** user account, you can also click the button on the user management interface to edit the permission.

Chapter 18 Appendix

18.1 Specifications

18.1.1 DS-9600NI-I8

| Model | | DS-9608NI-I8 | DS-9616NI-I8 | DS-9632NI-I8 | DS-9664NI-I8 | | |
|-----------------------|-------------------------------------|---|-----------------|------------------|--------------|--|--|
| Video/Audio input | ID . idea in | 8-ch | 16-ch | 32-ch | 64-ch | | |
| | IP video input | Up to 12 MP res | solution | | | | |
| | Two-way audio | 1-ch, RCA (2.0 V | /p-p, 1 k Ω) | | | | |
| | Incoming | 128 Mbps | 256 Mbps, | 320 Mbps | 320 Mbps | | |
| | bandwidth | 120 10100 | or 200 Mbps (w | hen RAID is enab | led) | | |
| Network | Outgoing bandwidth | 256 Mbps, or 20 | 00 Mbps (when R | AID is enabled) | | | |
| | Remote connection | 128 | 128 | | | | |
| | Recording | 12 MP/8 MP/6 MP/5 MP/4 MP/3 MP/1080p/UXGA | | | | | |
| | resolution | /720p/VGA/4CIF/DCIF/2CIF/CIF/QCIF | | | | | |
| | VGA1 /HDMI1 | HDMI1: 4K (3840 × 2160)/60Hz, 4K (3840 × 2160)/30Hz, 2K (2560 × 1440)/60Hz, 1920 × 1080p/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | | |
| Video/Audio output | resolution | VGA1: 2K (2560 × 1440)/60Hz, 1920 × 1080p/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | | |
| | VGA2 /HDMI2 output resolution | 1920 × 1080p/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | | |
| | Audio output | 2-ch, RCA (2.0Vp-p, 1 KΩ) | | | | | |
| Decoding | Decoding format | H.265/H.265+/H | H.264/H.264+/MI | PEG4 | | | |
| | Live view/Playback resolution | 12 MP/8 MP/6 MP/5 MP/4 MP/3 MP/1080p/UXGA/720p/VGA /4CIF/DCIF/2CIF/CIF/QCIF | | | | | |

| | Synchronous playback | 8-ch | 16-ch | | |
|-----------------------|---------------------------------------|--|-----------------------------------|--|--|
| | Capability | 12-ch @ 12 MP (20fps) / 4-ch @ 8 MP (25fps) / 8-ch @ 4MP (30fps) / 16-ch @ 1080p (30fps) | | | |
| Network management | Network protocols | TCP/IP, DHCP, Hik-Connect, DNS, DDNS, NTP, SADP, SMTP, NFS, iSCSI, UPnP™, HTTPS | | | |
| | SATA | 8 SATA interfac | es | | |
| Hard disk | eSATA | 1 eSATA interfa | ce | | |
| | Capacity | Up to 6 TB capa | city for each disk | | |
| | Array type | RAID 0, RAID 1, | RAID 5, RAID 6, RAID 10 | | |
| Disk array | Number of arrays | 4 | | | |
| | Network interface | 2, RJ-45 10/100/1000 Mbps self-adaptive Ethernet interface | | | |
| External interface | Serial interface | RS-232; RS-485; Keyboard | | | |
| interrace | USB interface | Front panel: 2 × | SUSB 2.0; Rear panel: 1 × USB 3.0 | | |
| | Alarm in/out | 16/4 | | | |
| | Power supply | 100 to 240 VAC, 50 to 60 Hz | | | |
| | Max. Power | 200 W | | | |
| | Consumption (without hard disk) | ≤ 30 W | | | |
| General | Working temperature | -10 to +55º C (+14 to +131º F) | | | |
| General | Working humidity | 10 to 90 % | | | |
| | Chassis | 19-inch rack-mo | ounted 2U chassis | | |
| | Dimensions(W × D × H) | 445 × 470 ×90 mm (17.5"× 18.5" × 3.5") | | | |
| | Weight(without hard disk) | ≤ 10 kg (22 lb) | ≤ 10 kg (22 lb) | | |

18.1.2 DS-9600NI-I16

| Model | | DS-9616NI-I16 | DS-9632NI-I16 | DS-9664NI-I16 | | | |
|---------------------------|-------------------------------------|---|---|--------------------|--|--|--|
| | IP video input | 16-ch | 32-ch | 64-ch | | | |
| Video/Aud io input | Incoming | 256 Mbps | 320 Mbps | 320 Mbps | | | |
| | bandwidth | Or 200 Mbps (when | RAID is enabled) | | | | |
| | Outgoing bandwidth | 256 Mbps, or 200 Ml | 256 Mbps, or 200 Mbps (when RAID is enabled) | | | | |
| Video/Aud io output | VGA1 /HDMI1 output resolution | 1024/60Hz, 1280 × 7 HDMI1: 4K (3840 × (2560 × 1440)/60Hz, | VGA1: 2K (2560 × 1440)/60Hz, 1920 × 1080/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz HDMI1: 4K (3840 × 2160)/60Hz, 4K (3840 × 2160)/30Hz, 2K (2560 × 1440)/60Hz, 1920 × 1080/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | |
| | VGA2 /HDMI2 output resolution | VGA2: 1920 × 1080/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz HDMI2: 1920 × 1080/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | | |
| | Audio output | 2-ch, RCA (Linear, 1 KΩ) | | | | | |
| | Decoding format | H.265/H.265+/H.264/H.264+/MPEG4 | | | | | |
| | Recording resolution | 12 MP/8 MP/6 MP/5 MP/4 MP/3 MP/1080p/UXGA /720p/VGA/4CIF/DCIF/2CIF/CIF/QCIF | | | | | |
| Decoding | Synchronous playback | 16-ch | | | | | |
| | Capability | 12-ch @ 12 MP (20fps) / 4-ch @ 8 MP (25fps) / 8-ch @ 4MP (30fps) / 16-ch @ 1080p (30fps) | | | | | |
| Network managem ent | Network protocols | TCP/IP, DHCP, Hik-Connect, DNS, DDNS, NTP, SADP, SMTP, NFS, iSCSI, UPnP™, HTTPS | | | | | |
| | SATA | 16 SATA interfaces | | | | | |
| Hard disk | eSATA | 1 eSATA interface | | | | | |
| | Capacity | Up to 6 TB capacity for each disk | | | | | |
| Disk array | Array type | RAID 0, RAID 1, RAID | 5, RAID 6, RAID 10 | | | | |
| External | Two-way audio | 1-ch, RCA (2.0 Vp-p, | 1 k Ω) | | | | |
| interface | Network | 2, RJ-45 10/100/1000 | O Mbps self-adaptive | Ethernet interface | | | |

| | interface | |
|---------|---------------------------------------|---|
| | Serial interface | RS-232; RS-485; Keyboard |
| | USB interface | Front panel: 2 × USB 2.0; Rear panel: 1 × USB 3.0 |
| | Alarm in/out | 16/8 |
| | Power supply | 100 to 240 VAC, 50 to 60 Hz |
| | Max. Power | 300 W |
| | Consumption (without hard disk) | ≤ 45 W |
| General | Working temperature | -10 to +55° C (+14 to +131° F) |
| | Working humidity | 10 to 90 % |
| | Chassis | 19-inch rack-mounted 3U chassis |
| | Dimensions (W × D × H) | 445 × 496 × 146 mm (17.5 × 19.5 × 5.7") |
| | Weight (without hard disk) | ≤ 12.5 kg (27.6 lb) |

18.1.3 DS-8600NI-I8

| Model | | DS-8608NI-I8 | DS-8616NI-I8 | DS-8632NI-I8 | DS-8664NI-I8 | |
|---------------------------|-------------------------------------|---|-------------------|------------------|--------------|--|
| | ID video input | 8-ch | 16-ch | 32-ch | 64-ch | |
| Video/Au dio input | IP video input | Up to 12 MP res | olution | | | |
| | Two-way audio | 1-ch, RCA (2.0 V | p-p, 1 k Ω) | | | |
| | Incoming | 128 Mbps | 256 Mbps | 320 Mbps | 320 Mbps | |
| | bandwidth | 120 1010005 | or 200 Mbps (w | hen RAID is enab | led) | |
| Network | Outgoing bandwidth | 256 Mbps, or 20 | 0 Mbps (when R/ | AID is enabled) | | |
| | Remote connection | 128 | | | | |
| | Recording | 12 MP/8 MP/6 N | MP/5 MP/4 MP/ | | | |
| resolution VGA1/HDMI1 | 3 MP/1080p/UX | GA/720p/VGA/4 | CIF/DCIF/2CIF/CII | F/QCIF | | |
| | VGA1/HDMI1 output | HDMI1: 4K (3840 × 2160)/60Hz, 4K (3840 × 2160)/30Hz, 2K (2560 × 1440)/60Hz, 1920 × 1080p/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | |
| Video/Au dio output | resolution | VGA1: 2K (2560 × 1440)/60Hz, 1920 × 1080p/60Hz, 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 768/60Hz | | | | |
| | VGA2/HDMI2 output resolution | 1920 × 1080p/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | |
| | Audio output | 2-ch, RCA (2.0Vp | p-p, 1 KΩ) | | | |
| | Decoding format | H.265/H.265+/H | I.264/H.264+/MP | PEG4 | | |
| Docading | Live view/Playback resolution | 12 MP/8 MP/6 MP/5 MP/4 MP/3 MP/1080p/UXGA/720p/VGA /4CIF/DCIF/2CIF/CIF/QCIF | | | A/720p/VGA | |
| Decoding | Synchronous playback | 8-ch 16-ch | | | | |
| | Capability | 12-ch @ 12 MP (20fps) / 4-ch @ 8 MP (25fps) / 8-ch @ 4MP (30fps) / 16-ch @ 1080p (30fps) | | | | |
| Network managem | Network protocols | TCP/IP, DHCP, Hik-Connect, DNS, DDNS, NTP, SADP, SMTP, NFS, iSCSI, UPnP™, HTTPS | | | | |

| ent | | |
|--------------------|---------------------------------------|--|
| | SATA | 8 SATA interfaces |
| Hard disk | eSATA | 1 eSATA interface |
| | Capacity | Up to 6TB capacity for each disk |
| | Network interface | 2, RJ-45 10/100/1000 Mbps self-adaptive Ethernet interface |
| External interface | Serial interface | RS-232; RS-485; Keyboard |
| interrace | USB interface | Front panel: 2 × USB 2.0; Rear panel: 1 × USB 3.0 |
| | Alarm in/out | 16/4 |
| | Power supply | 100 to 240 VAC, 50 to 60 Hz |
| | Max. Power | 200 W |
| | Consumption (without hard disk) | ≤ 30 W |
| | Working temperature | -10 to +55° C (+14 to +131° F) |
| General | Working humidity | 10 to 90 % |
| | Chassis | 19-inch rack-mounted 2U chassis |
| | Dimensions (W × D × H) | 445 × 470 ×90 mm (17.5"× 18.5" × 3.5") |
| | Weight (without hard disk) | ≤ 8 kg (17.6 lb) |

18.1.4 DS-7600NI-I2

| Model | | DS-7608NI-I2 | DS-7616NI-I2 | DS-7632NI-I2 |
|-----------------------|---------------------------------------|---|---|-------------------|
| | ID vide e innut | 8-ch | 16-ch | 32-ch |
| Video/Audio input | IP video input | Up to 12 MP res | olution | |
| | Two-way audio | 1-ch, RCA (2.0 V) | o-p, 1 k Ω) | |
| | Incoming bandwidth | 80 Mbps | 160 Mbps | 256Mbps |
| Network | Outgoing bandwidth | 256 Mbps | | |
| | Remote connection | 32 | 128 | |
| | Recording resolution | 12 MP/8 MP/6 MP/5 MP/4 MP/3 MP/1080p/UZ /720p/VGA/4CIF/DCIF/ 2CIF/CIF/QCIF | | - |
| Video/Audio output | HDMI output resolution | 4K (3840 × 2160)/60Hz, 4K (3840 × 2160)/30Hz, 1920 × 1080p/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | |
| | VGA output resolution | 1920 × 1080p/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | |
| | Audio output | 1-ch, RCA (Linea | r, 1 KΩ) | |
| | Decoding format | H.265/H.265+/H | .264/H.264+/MPEG | 4 |
| Deceding | Live view / Playback resolution | | /IP/5 MP/4 MP/3MP /DCIF/ 2CIF/CIF/QCI | - |
| Decoding | Synchronous playback | 8-ch | 16-ch | 16-ch |
| | Capability | | (20fps) / 4-ch @ 8 M i-ch @ 1080p (30fps | |
| Network management | Network protocols | TCP/IP, DHCP, Hik-Connect, DNS, DDNS, NTP, SADP, SMTP, NFS, iSCSI, UPnP™, HTTPS | | |
| Hard diek | SATA | 2 SATA interface | S | |
| Hard disk | Capacity | Up to 6TB capac | ity for each disk | |
| External interface | Network interface | 1 RJ-45 10/100 interface |)/1000 Mbps self-a | adaptive Ethernet |

Network Video Recorder User Manual

| | USB interface | Front panel: 1 × USB 2.0; Rear panel: 1 × USB 3.0 |
|---------|---------------------------------------|---|
| | Alarm in/out | 4/1 |
| | Power supply | 12 VDC |
| | Power | ≤40 W |
| | Consumption (without hard disk) | ≤15 W |
| General | Working temperature | -10 to +55º C (+14 to +131º F) |
| | Working humidity | 10 to 90 % |
| | Chassis | 385 mm chassis |
| | Dimensions (W × D × H) | 385 × 315× 52 mm (15.2" × 12.4" × 2.0") |
| | Weight(without hard disk) | ≤ 1 kg (2.2 lb) |

18.1.5 DS-7600NI-I2/P

| Model | | DS-7608NI-I2/ 8P | DS-7616NI-I2/ 16P | DS-7632NI-I2/ 16P | | |
|---------------------------|-------------------------------------|--|--|----------------------|--|--|
| | | 8-ch | 16-ch | 32-ch | | |
| Video/ | IP video input | Up to 12 MP resolution | | | | |
| Audio input | Two-way audio | | 1-ch, RCA (2.0 Vp-p, 1 k Ω) | | | |
| | Incoming bandwidth | 80 Mbps | 160 Mbps | 256Mbps | | |
| Network | Outgoing bandwidth | 256 Mbps | | | | |
| | Remote connection | 32 | 128 | | | |
| | Recording resolution | 12 MP/8 MP/6 MP/5 MP/4 MP/3 MP/1080p/UXGA /720p/VGA/4CIF/DCIF/2CIF/CIF/QCIF | | | | |
| Video/Au dio | HDMI output resolution | 4K (3840 × 2160)/60Hz, 4K (3840 × 2160)/30Hz, 2K (2560 × 1440)/60Hz, 1920 × 1080p/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | |
| output | VGA output resolution | 1920 × 1080p/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | |
| | Audio output | 1-ch, RCA (Linear, 1 | ΚΩ) | | | |
| | Decoding format | H.265/H.265+/H.264/H.264+/MPEG4 | | | | |
| Decoding | Live view/Playback resolution | 12 MP/8 MP/6 MP/ /720p/VGA/4CIF/D | '5 MP/4 MP/3 MP/108 CIF/2CIF/CIF/QCIF | 80p/UXGA | | |
| | Synchronous playback | 8-ch | 16-ch | 16-ch | | |
| | Capability | 12-ch @ 12 MP (20fps) / 4-ch @ 8 MP (25fps) / 8-ch @ 4MP (30fps) / 16-ch @ 1080p (30fps) | | | | |
| Network manage ment | Network protocols | TCP/IP, DHCP, Hik-Connect, DNS, DDNS, NTP, SADP, SMTP, NFS, iSCSI, UPnP™, HTTPS | | | | |
| Hard disk | SATA | 2 SATA interfaces | | | | |

| | Capacity | Up to 6TB capacity | for each disk | |
|-----------|---------------------------------------|--|--|--|
| External | Network interface | 1 RJ-45 10/100/1000 Mbps self-adaptive Ethernet interface | | |
| interface | USB interface | Front panel: 1 × US | B 2.0; Rear panel: 1 × USB 3.0 | |
| | Alarm in/out | 4/1 | | |
| POE | Interface | 8, RJ-45 10/100 Mbps self-adaptive Ethernet interface | 16, RJ-45 10/100 Mbps self-adaptive Ethernet interface | |
| Interface | Power | ≤ 120W | ≤ 200W | |
| | Supported standard | IEEE 802.3 af/at | | |
| | Power supply | 100 to 240 VAC, 50 to 60 Hz | | |
| | Power | ≤ 180 W | ≤ 280 W | |
| | Consumption (without hard disk) | ≤15 W (without enabling PoE) | | |
| General | Working temperature | -10 to +55º C (+14 to +131º F) | | |
| General | Working humidity | 10 to 90 % | | |
| | Chassis | 385 mm chassis | | |
| | Dimensions(W × D × H) | 385 × 315× 52 mm | (15.2" × 12.4" × 2.0") | |
| | Weight(witho ut hard disk) | ≤ 3 kg (6.6 lb) | | |

18.1.6 DS-7700NI-I4

| Model | | DS-7708NI-I4 | DS-7716NI-I4 | DS-7732NI-I4 | | | |
|-----------------------|---------------------------------------|---|-----------------------------|------------------|--|--|--|
| | IP video input | 8-ch | 16-ch | 32-ch | | | |
| Video/Audio | ir video iriput | Up to 12 MP resolu | tion | | | | |
| input | Two-way audio | 1-ch, RCA (2.0 Vp-p | 1-ch, RCA (2.0 Vp-p, 1 k Ω) | | | | |
| | Incoming bandwidth | 80 Mbps | 160 Mbps | 256 Mbps | | | |
| Network | Outgoing bandwidth | 256 Mbps | | | | | |
| | Remote connection | 32 | 128 | | | | |
| | | 12 MP/8 MP/6 MP/ /720p/VGA/4CIF/D0 | | 1080p/UXGA | | | |
| Video/Audio output | HDMI output resolution | 4K (3840 × 2160)/60Hz, 4K (3840 × 2160)/30Hz, 1920 × 1080p/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | | |
| | VGA output resolution | 1920 × 1080p/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | | |
| | Audio output | 1-ch, RCA (Linear, 1 KΩ) | | | | | |
| | Decoding format | H.265/H.265+/H.264/H.264+/MPEG4 | | | | | |
| Decoding | Live view / Playback resolution | 12 MP/8 MP/6 MP/5 MP/4 MP/3 MP/1080p/UXGA /720p/VGA/4CIF/DCIF/2CIF /CIF/QCIF | | | | | |
| | Synchronous playback | 8-ch | 16-ch | 16-ch | | | |
| | Capability | 12-ch @ 12 MP (20fps) / 4-ch @ 8 MP (25fps) / 8-ch @ 4MP (30fps) / 16-ch @ 1080p (30fps) | | | | | |
| Network management | Network protocols | TCP/IP, DHCP, Hil SMTP, NFS, iSCSI, U | | DDNS, NTP, SADP, | | | |
| Hond diele | SATA | 4 SATA interfaces | | | | | |
| Hard disk | Capacity | Up to 6TB capacity | for each disk | | | | |

| | Network interface | 2, RJ-45 10/100/1000 Mbps self-adaptive Ethernet interface |
|--------------------|---------------------------------------|--|
| External interface | Serial interface | 1 RS-485 (half-duplex), 1 RS-232 |
| | USB interface | Front panel: 2 × USB 2.0; Rear panel: 1 × USB 3.0 |
| | Alarm in/out | 16/4 |
| | Power supply | 100 to 240 VAC |
| | Power | ≤80 W |
| | Consumption (without hard disk) | ≤20 W |
| | Working temperature | -10 to +55º C (+14 to +131º F) |
| General | Working humidity | 10 to 90 % |
| | Chassis | 19-inch rack-mounted 1.5U chassis |
| | Dimensions (W × D × H) | 445 × 400 ×71 mm (17.5"× 15.7" × 2.8") |
| | Weight (without hard disk) | ≤ 5 kg (11 lb) |

18.1.7 DS-7700NI-I4/P

| Model | | DS-7708NI-I4/8P | DS-7716NI-I4/16P | DS-7732NI-I4/16P | | | | |
|-----------------------|---------------------------------------|---|--|----------------------|--|--|--|--|
| | ID video import | 8-ch | 16-ch | 32-ch | | | | |
| Video/Audio input | IP video input | Up to 12 MP resolut | Up to 12 MP resolution | | | | | |
| | Two-way audio | 1-ch, RCA (2.0 Vp-p, | 1-ch, RCA (2.0 Vp-p, 1 k Ω) | | | | | |
| | Incoming bandwidth | 80 Mbps | 160 Mbps | 256 Mbps | | | | |
| Network | Outgoing bandwidth | 256 Mbps | 256 Mbps | | | | | |
| | Remote connection | 32 | 128 | | | | | |
| | Recording resolution | 12 MP/8 MP/6 MP/ /720p/VGA/4CIF/D0 | 5 MP/4 MP/3 MP/108 CIF/ 2CIF/CIF/QCIF | Op/UXGA | | | | |
| Video/Audio output | HDMI output resolution | 4K (3840 × 2160)/60Hz, 4K (3840 × 2160)/30Hz, 1920 × 1080p/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | | | |
| | VGA output resolution | 1920 × 1080p/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | | | |
| | Audio output | 1-ch, RCA (Linear, 1 | ΚΩ) | | | | | |
| | Decoding format | H.265/H.265+/H.264/H.264+/MPEG4 | | | | | | |
| Decoding | Live view / Playback resolution | 12 MP/8 MP/6 MP/5 MP/4 MP/3 MP/1080p/UXGA /720p/VGA/4CIF/DCIF/ 2CIF/CIF/QCIF | | | | | | |
| | Synchronous playback | 8-ch | 16-ch | 16-ch | | | | |
| | Capability | 12-ch @ 12 MP (20fps) / 4-ch @ 8 MP (25fps) / 8-ch @ 4MP (30fps) / 16-ch @ 1080p (30fps) | | | | | | |
| Network management | Network protocols | TCP/IP, DHCP, Hik-C iSCSI, UPnP™, HTTP: | Connect, DNS, DDNS, N S | TP, SADP, SMTP, NFS, | | | | |
| Hard disk | SATA | 4 SATA interfaces | | | | | | |
| riai u uisk | Capacity | Up to 6TB capacity for each disk | | | | | | |
| External | Network | 1, RJ-45 10/100/1000 Mbps self-adaptive Ethernet interface | | | | | | |

| interface | interface | | | |
|-----------|---------------------------------------|--|--|--|
| | Serial interface | RS-485 (half-duplex), RS-232 | | |
| | USB interface | Front panel: 2 × USB 2.0; Rear panel: 1 × USB 3.0 | | |
| | Alarm in/out | 16/4 | | |
| POE | Interface | 8, RJ-45 10/100 Mbps 16, RJ-45 10/100 Mbps self-adaptive Ethernet interface Ethernet interface | | |
| Interface | Power | ≤200W | | |
| | Supported standard | IEEE 802.3 af/at | | |
| | Power supply | 100 to 240 VAC | | |
| | Power | ≤300 W | | |
| | Consumption (without hard disk) | ≤20 W (without enabling PoE) | | |
| General | Working temperature | -10 to +55° C (+14 to +131° F) | | |
| General | Working humidity | 10 to 90 % | | |
| | Chassis | 19-inch rack-mounted 1.5U chassis | | |
| | Dimensions (W × D × H) | 445 × 400 ×71 mm (17.5"× 15.7" × 2.8") | | |
| | Weight(without hard disk) | ≤ 5 kg (11 lb) | | |

18.1.8 DS-8600NI-K8

| Model | | DS-8608NI-K8 | DS-8616NI-K8 | DS-8632NI-K8 |
|--------------------------|--------------------|--------------|--------------|--------------|
| | IP video input | 8-ch | 16-ch | 32-ch |
| Video/ Audio input | Incoming bandwidth | 80 Mbps | 160 Mbps | 256 Mbps |
| | Outgoing bandwidth | 160 Mbps | | |

| Video/ Audio output | VGA1/HDMI1 output resolution | 1920 × 1080/60H 1280 × 720/60Hz, | 1080/60Hz, 1280 × | , 1280 × 1024/60Hz, | |
|---------------------------|------------------------------------|---|---|---|--|
| | VGA2/HDMI2 output | | VGA1: 2K (2560 × 1440)/60Hz, 1920 × 1080/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | |
| | resolution | VGA2: 1920 × 1 720/60Hz, 1024 × | 1080/60Hz, 1280 × 768/60Hz | 1024/60Hz, 1280 × | |
| | Audio output | 2-ch, RCA (Linear, | 1 Κ Ω) | | |
| | Decoding format | H.265/H.265+/H.2 | 264/H.264+/MPEG4 | | |
| Decading | Recording resolution | 8MP/6MP/5MP/4MP/3MP/1080p/UXGA /720p/VGA/4CIF/DCIF/2CIF/CIF/QCIF | | | |
| Decoding | Synchronous playback | 8-ch | 16-ch | 16-ch | |
| | Capability | 2-ch @ 8 MP (25fps) / 4-ch @ 4MP (30fps) / 8-ch @ 1080p (30fps) | | | |
| Network managem ent | Network protocols | TCP/IP, DHCP, Hik-Connect, DNS, DDNS, NTP, SADP, SMTP, NFS, iSCSI, UPnP™, HTTPS | | | |
| | SATA | 8 SATA interfaces | | | |
| Hard disk | eSATA | 1 eSATA interface | | | |
| | Capacity | Up to 6TB capacity for each disk | | | |
| | Two-way audio | 1-ch, RCA (2.0 Vp- | p, 1 kΩ) | | |
| External | Network interface | 2, RJ-45 10/100/1000 Mbps self-adaptive Ethernet interface | | | |
| interface | Serial interface | RS-232; RS-485; Keyboard | | | |
| | USB interface | Front panel: 2 × U | SB 2.0; Rear panel: 1 > | < USB 3.0 − − − − − − − − − − − − − − − − − − − | |
| | Alarm in/out | 16/4 | | | |
| General | Power supply | 100 to 240 VAC, 50 to 60 Hz | | | |
| Max. Power 200 W | | | | | |

| Consumption (without hard disk) | ≤ 30 W |
|---------------------------------------|--|
| Working temperature | -10 to +55° C (14 to 131° F) |
| Working humidity | 10 to 90 % |
| Chassis | 19-inch rack-mounted 2U chassis |
| Dimensions (W × D × H) | 445 × 470 × 90 mm (17.5" × 18.5" × 3.5") |
| Weight (without hard disk) | ≤ 8 kg (17.6 lb) |

18.1.9 DS-7700NI-K4

| Model | | DS-7708NI-K4 | DS-7 | 7716NI-K4 | DS-77 | 32NI-K4 |
|---------------------------|------------------------------|---|--|--------------|---------------|---------------|
| | IP video input | 8-ch | 16-cl | h | 32-ch | |
| Video/ Audio input | Incoming bandwidth | 80 Mbps 160 Mbps | | 256 M | bps | |
| Прис | Outgoing bandwidth | 160 Mbps | | | | |
| Video/ | HDMI output resolution | 1080/60Hz, 1600 | 4K (3840 × 2160)/30Hz, 2K (2560 × 1440)/60Hz, 1920 : 1080/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 : 720/60Hz, 1024 × 768/60Hz | | | * |
| Audio output | VGA output resolution | 1000 | | | |) × 720/60Hz, |
| | Audio output | 1-ch, RCA (Linear, 1 KΩ) | | | | |
| | Decoding format | H.265/H.265+/H.264+/H.264/MPEG4 | | | | |
| Deceding | Recording resolution | 8MP/6MP/5MP/4MP/3MP/1080p/UXGA/720p/VGA/4CIF/ DCIF/2CIF/CIF/QCIF | | | | |
| Decoding | Synchronou s playback | 8-ch 16-ch | | 16-ch | | 16-ch |
| | Capability | 2-ch @ 8 MP (25fp (30fps) | os) / 4- | -ch @ 4MP (3 | 80fps) / | 8-ch @ 1080p |
| Network manageme nt | Network protocols | TCP/IP, DHCP, Hik-Connect, DNS, DDNS, NTP, SADP, SMTP, NFS, iSCSI, UPnP™, HTTPS | | | , SADP, SMTP, | |
| Hard disk | SATA | 4 SATA interfaces | | | | |
| naru uisk | Capacity | Up to 6TB capacity | for e | ach disk | | |
| | Two-way audio | 1-ch, RCA (2.0 Vp- | p, 1kΩ | 2) | | |
| External interface | Network interface | 2, RJ-45 10/100 interface | · · · · · · · · · · · · · · · · · · · | | | |
| | Serial | RS-485 (half-duple | x), RS | -232, Keyboa | rd (optio | onal) |

| | interface | |
|---------|----------------------------------|---|
| | USB interface | Front panel: 2 × USB 2.0; Rear panel: 1 × USB 3.0 |
| | 16/4 | |
| | Power supply | 100 to 240 VAC |
| | Power | ≤ 80 W |
| | Consumption (without hard disk) | ≤ 20 W |
| General | Working temperature | -10 to +55° C (14 to 131° F) |
| | Working humidity | 10 to 90 % |
| | Chassis | 19-inch rack-mounted 1.5U chassis |
| | Dimensions (W × D × H) | 445 × 400 ×71 mm (17.5"× 15.7" × 2.8") |
| | Weight (without hard disk) | ≤ 5 kg (11. lb) |

18.1.10 DS-7700NI-K4/P

| Model | | DS-7708NI-K4 /8P | DS-7716NI-K 4/16P | DS-7732NI-K4/1 6P | |
|---------------------------|--|---|----------------------|----------------------|--|
| | IP video input | 8-ch | 16-ch | 32-ch | |
| Video/ Audio | Incoming bandwidth | 80 Mbps | 160 Mbps | 256 Mbps | |
| input | Outgoing bandwidth | 160 Mbps | | | |
| Video/ | HDMI output resolution 4K (3840 × 2160)/30Hz, 2K (2560 × 1440)/60Hz 1080/60Hz, 1600 × 1200/60Hz, 1280 × 102 1280 × 720/60Hz, 1024 × 768/60Hz | | | | |
| Audio output | VGA output resolution | | | | |
| | Audio output | 1-ch, RCA (Linear, | 1 ΚΩ) | | |
| | Decoding format | H.265/H.265+/H.264/H.264+/MPEG4 | | | |
| Danding | Recording resolution | 8MP/6MP/5MP/4MP/3MP/1080p/UXGA/720p/VGA/4C IF/DCIF/2CIF/CIF/QCIF | | | |
| Decoding | Synchronous playback | 8-ch | 16-ch | 16-ch | |
| | Capability | 2-ch @ 8 MP (25fps) / 4-ch @ 4MP (30fps) / 8-ch @ 1080p (30fps) | | | |
| Network managem ent | Network protocols | TCP/IP, DHCP, H SMTP, NFS, iSCSI, | | DDNS, NTP, SADP, | |
| Hand diele | SATA | 4 SATA interfaces | | | |
| Hard disk | Capacity | Up to 6TB capacit | y for each disk | | |
| | Two-way audio | 1-ch, RCA (2.0 Vp-p, 1kΩ) | | | |
| External interface | Network interface | 1, RJ-45 10/100/1000 Mbps self-adaptive Ethernet interface | | | |
| | Serial interface | RS-485 (half-duple | ex), RS-232, Keybo | pard | |
| | USB interface | Front panel: 2 × U | SB 2.0; Rear pane | el: 1 × USB 3.0 | |

| | Alarm in/out | 16/4 | | |
|------------------|---------------------------------------|---|---|--|
| POE Interface | Interface | 8, RJ-45 10/100 Mbps self-adaptive Ethernet interface | 16, RJ-45 10/100 Mbps self-adaptive Ethernet interface | |
| interrace | Power | ≤ 200 W | | |
| | Supported standard | IEEE 802.3 af/at | | |
| | Power supply | 100 to 240 VAC | | |
| | Power | ≤ 300 W | | |
| | Consumption (without hard disk) | ≤ 20 W (without enabling PoE) | | |
| | Working temperature | -10 to +55°C (14 to 131°F) | | |
| General | Working humidity | 10 to 90 % | | |
| | Chassis | 19-inch rack-mou | nted 1.5U chassis | |
| | Dimensions (W × D × H) | 445 × 400 ×71 mm (17.5"× 15.7" × 2.8") | | |
| | Weight (without hard disk) | ≤ 5 kg (11. lb) | | |

18.1.11 DS-7600NI-K2

| Model | | DS-7608NI-K2 | DS-7616NI-K2 | DS-7632NI-K2 | | | |
|---------------------------|------------------------|--|-----------------------------------|------------------|--|--|--|
| | IP video input | 8-ch | 16-ch | 32-ch | | | |
| Video/ Audio | Incoming bandwidth | 80 Mbps | 160 Mbps | 256 Mbps | | | |
| input | Outgoing bandwidth | 160 Mbps | 160 Mbps | | | | |
| Video/ | HDMI output resolution | 4K (3840 × 2160)/30Hz, 2K (2560 × 1440)/60Hz, 19 × 1080/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz 1920 × 1080/60Hz, 1280 × 1024/60Hz, 1280 720/60Hz, 1024 × 768/60Hz 1-ch, RCA (Linear, 1 KΩ) | | | | | |
| Audio output | VGA output resolution | | | | | | |
| | Audio output | | | | | | |
| | Decoding format | H.265/H.265+/H.264/H.264+/MPEG4 | | | | | |
| Decedies | Recording resolution | 8MP/6MP/5MP/4MP/3MP/1080p/UXGA/720p/VGA/4 CIF/DCIF/2CIF/CIF/QCIF | | | | | |
| Decoding | Synchronous playback | 8-ch | 16-ch | 16-ch | | | |
| | Capability | 2-ch @ 8 MP (25fps) / 4-ch @ 4MP (30fps) / 8-ch @ 1080p (30fps) | | | | | |
| Network managem ent | Network protocols | TCP/IP, DHCP, Hi SMTP, NFS, iSCSI, | k-Connect, DNS, [UPnP™, HTTPS | DDNS, NTP, SADP, | | | |
| Hard disk | SATA | 2 SATA interfaces | | | | | |
| Hard disk | Capacity | Up to 6TB capacit | y for each disk | | | | |
| | Two-way audio | 1-ch, RCA (2.0 Vp-p, 1kΩ) | | | | | |
| External interface | Network interface | 1 RJ-45 10/100/1000 Mbps self-adaptive Ethernet interface | | | | | |
| | USB interface | Front panel: 1 × USB 2.0; Rear panel: 1 × USB 3.0 | | | | | |
| | Alarm in/out | 4/1 | | | | | |

| | Power supply | 12 VDC |
|---------|---------------------------------------|---|
| | Power | ≤ 40 W |
| | Consumption (without hard disk) | ≤15 W |
| | Working temperature | -10 to +55° C (14 to 131° F) |
| General | Working humidity | 10 to 90 % |
| | Chassis | 385 mm chassis |
| | Dimensions (W × D × H) | 385 × 315× 52 mm (15.2" × 12.4" × 2.0") |
| | Weight (without hard disk) | ≤ 1 kg (2.2 lb) |

18.1.12 DS-7600NI-K2/P

| Model | | DS-7608NI-K2 /8P | DS-7616NI-K 2/16P | DS-7632NI-K2/ 16P | | |
|---------------------------|------------------------|--|----------------------|----------------------|--|--|
| | IP video input | 8-ch | 16-ch | 32-ch | | |
| Video/ Audio | Incoming bandwidth | 80 Mbps | 160 Mbps | 256 Mbps | | |
| input | Outgoing bandwidth | 160 Mbps | | | | |
| Video/ | HDMI output resolution | 4K (3840 × 2160)/30Hz, 2K (2560 × 1440)/60Hz, 1920 × 1080/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | |
| Audio output | VGA output resolution | 1920 × 1080/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | |
| | Audio output | 1-ch, RCA (Linear, 1 KΩ) | | | | |
| | Decoding format | H.265/H.265+/H.264/H.264+/MPEG4 | | | | |
| | Recording resolution | 8MP/6MP/5MP/4MP/3MP/1080p/UXGA/720p/VGA/4 CIF/DCIF/2CIF/CIF/QCIF | | | | |
| Decoding | Synchronous playback | 8-ch | 16-ch | 16-ch | | |
| | Capability | 2-ch @ 8 MP (25 1080p (30fps) | fps) / 4-ch @ 4N | IP (30fps) / 8-ch @ | | |
| Network managem ent | Network protocols | TCP/IP, DHCP, Hi SMTP, NFS, iSCSI, | | DDNS, NTP, SADP, | | |
| tional about | SATA | 2 SATA interfaces | | | | |
| Hard disk | Capacity | Up to 6TB capacit | y for each disk | | | |
| | Two-way audio | 1-ch, RCA (2.0 Vp- | -p, 1kΩ) | | | |
| External | Network interface | 1, RJ-45 10/100, interface | /1000 Mbps self | -adaptive Ethernet | | |
| interface | USB interface | Front panel: 1 × U | ISB 2.0; Rear pane | el: 1 × USB 3.0 | | |
| | Alarm in/out | 4/1 | | | | |

| POE Interface | Interface | 8, RJ-45 10/100 Mbps self-adaptive Ethernet interface | 16, RJ-45 10/100 Mbps self-adaptive Ethernet interface | |
|------------------|---------------------------------------|---|---|--|
| memace | Power | ≤ 120 W | ≤ 200 W | |
| | Supported standard | IEEE 802.3 af/at | | |
| | Power supply | 100 to 240 VAC | | |
| | Power | ≤ 180 W | ≤ 280 W | |
| | Consumption (without hard disk) | ≤ 15 W | | |
| | Working temperature | -10 to +55° C (14† | to 131° F) | |
| General | Working humidity | 10 to 90 % | | |
| | Chassis | 385 mm chassis | | |
| | Dimensions (W × D × H) | 385 × 315× 52 mm (15.2" × 12.4" × 2.0") | | |
| | Weight (without hard disk) | ≤ 3 kg (6.6 lb) | | |

18.1.13 DS-7600NI-K1

| Model | | DS-7604NI-K1 | DS-7608NI-K1 | DS-7616NI-K1 | | | |
|---------------------------|----------------------|---|--|------------------|--|--|--|
| | IP video input | 4-ch | 8-ch | 16-ch | | | |
| Video/ Audio | Incoming bandwidth | 40 Mbps | 60 Mbps | 80 Mbps | | | |
| input | Outgoing bandwidth | 80 Mbps | 80 Mbps | | | | |
| Video/ | HDMI/VGA output | ` | 4K (3840 × 2160)/30Hz, 1920 × 1080/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 | | | | |
| Audio output | resolution | VGA: 1920 × 1080/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz | | | | | |
| | Audio output | 1-ch, RCA (Linear, 1 | 1 ΚΩ) | | | | |
| | Decoding format | H.265/H.264/H.264+ | | | | | |
| Decoding | Recording resolution | 8MP/6MP/5MP/4MP/3MP/1080p/UXGA/720p/VGA/4C IF/DCIF/2CIF/CIF/QCIF | | | | | |
| | Synchronous playback | 4-ch | 8-ch | 16-ch | | | |
| | Capability | 2-ch @ 4 MP (30fp | s) | | | | |
| Network manageme nt | Network protocols | TCP/IP, DHCP, Hill SMTP, NFS, iSCSI, L | | DDNS, NTP, SADP, | | | |
| Hond diale | SATA | 1 SATA interface | | | | | |
| Hard disk | Capacity | Up to 6TB capacity | for each disk | | | | |
| | Two-way audio | 1-ch, RCA (2.0 Vp-ր | ο, 1kΩ) | | | | |
| External interface | Network interface | 1, RJ-45 10 M/ interface | 100 Mbps self-a | daptive Ethernet | | | |
| | USB interface | 2 × USB 2.0 | | | | | |

| | Power supply | 12 VDC |
|---------|---------------------------------------|---|
| | Consumption (without hard disk) | ≤ 10 W |
| | Working temperature | -10 to +55° C (14 to 131° F) |
| General | Working humidity | 10 to 90 % |
| | Chassis | 260 mm chassis |
| | Dimensions (W × D × H) | 260 × 225 × 48 mm (10.2" × 8.9" × 1.9") |
| | Weight (without hard disk) | ≤ 1 kg (2.2 lb) |

18.1.14 DS-7604NI-K1/4P

| Model | | DS-7604NI-K1/4P |
|---------------------------|-----------------------|--|
| | IP video input | 4-ch |
| Video/ Audio | Incoming bandwidth | 40 Mbps |
| input | Outgoing bandwidth | 80 Mbps |
| Video/ | HDMI/VGA output | HDMI: 4K (3840 × 2160)/30Hz, 1920 × 1080/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz |
| Audio output | resolution | VGA: 1920 × 1080/60Hz, 1600 × 1200/60Hz, 1280 × 1024/60Hz, 1280 × 720/60Hz, 1024 × 768/60Hz |
| | Audio output | 1-ch, RCA (Linear, 1 KΩ) |
| | Decoding format | H.265/H.264/H.264+ |
| Decoding | Recording resolution | 8MP/6MP/5MP/4MP/3MP/1080p/UXGA/720p/VGA/ 4CIF/DCIF/2CIF/CIF/QCIF |
| | Synchronous playback | 4-ch |
| | Capability | 2-ch @ 4 MP (30fps) |
| Hand disk | SATA | 1 SATA interface for 1HDD |
| Hard disk | Capacity | Up to 6TB capacity for each disk |
| Network managem ent | Network protocols | TCP/IP, DHCP, Hik-Connect, DNS, DDNS, NTP, SADP, SMTP, NFS, iSCSI, UPnP™, HTTPS |
| | Two-way audio | 1-ch, RCA (2.0 Vp-p, 1kΩ) |
| External interface | Network interface | 1, RJ-45 100 Mbps full-duplex Ethernet interface |
| | USB interface | Front panel: 1 × USB 2.0; Rear panel: 1 × USB 2.0 |
| POE | Interface | 4, RJ-45 100 Mbps full-duplex Ethernet interface |

| Interface | Power | ≤ 40 W |
|-----------|---------------------------------------|---|
| | Supported standard | IEEE 802.3 af/at |
| | Power supply | 48 VDC |
| | Power | ≤ 65 W |
| | Consumption (without hard disk) | ≤ 10 W (not enabling PoE) |
| | Working temperature | -10 to +55° C (14 to 131° F) |
| General | Working humidity | 10 to 90 % |
| | Chassis | 1U chassis |
| | Dimensions (W × D × H) | 315 × 240 × 48 mm (12.4" × 9.4" × 1.9") |
| | Weight (without hard disk) | ≤ 1 kg (2.2 lb) |

18.2 Glossary

- **Dual Stream:** Dual stream is a technology used to record high resolution video locally while transmitting a lower resolution stream over the network. The two streams are generated by the NVR, with the main stream having a maximum resolution of 4CIF and the sub-stream having a maximum resolution of CIF.
- **HDD:** Acronym for Hard Disk Drive. A storage medium which stores digitally encoded data on platters with magnetic surfaces.
- **DHCP:** Dynamic Host Configuration Protocol (DHCP) is a network application protocol used by devices (DHCP clients) to obtain configuration information for operation in an Internet Protocol network.
- **HTTP:** Acronym for Hypertext Transfer Protocol. A protocol to transfer hypertext request and information between servers and browsers over a network
- DDNS: Dynamic DNS is a method, protocol, or network service that provides the capability
 for a networked device, such as a router or computer system using the Internet Protocol
 Suite, to notify a domain name server to change, in real time (ad-hoc) the active DNS
 configuration of its configured hostnames, addresses or other information stored in DNS.
- **Hybrid NVR:** A hybrid NVR is a combination of a NVR and NVR.
- **NTP:** Acronym for Network Time Protocol. A protocol designed to synchronize the clocks of computers over a network.
- NTSC: Acronym for National Television System Committee. NTSC is an analog television standard used in such countries as the United States and Japan. Each frame of an NTSC signal contains 525 scan lines at 60Hz.
- **NVR:** Acronym for Network Video Recorder. An NVR can be a PC-based or embedded system used for centralized management and storage for IP cameras, IP Domes and other NVRs.
- PAL: Acronym for Phase Alternating Line. PAL is also another video standard used in broadcast televisions systems in large parts of the world. PAL signal contains 625 scan lines at 50Hz.
- **PTZ:** Acronym for Pan, Tilt, Zoom. PTZ cameras are motor driven systems that allow the camera to pan left and right, tilt up and down and zoom in and out.
- **USB:** Acronym for Universal Serial Bus. USB is a plug-and-play serial bus standard to interface devices to a host computer.

18.3 Troubleshooting

No image displayed on the monitor after starting up normally.

Possible Reasons:

- No VGA or HDMI connections.
- Connection cable is damaged.
- Input mode of the monitor is incorrect.
- Step 1 Verify the device is connected with the monitor via HDMI or VGA cable.
- Step 2 If not, please connect the device with the monitor and reboot.
- Step 3 Verify the connection cable is good.
- Step 4 If there is still no image display on the monitor after rebooting, please check if the connection cable is good, and change a cable to connect again.
- Step 5 Verify Input mode of the monitor is correct.
- Step 6 Please check the input mode of the monitor matches with the output mode of the device (e.g. if the output mode of NVR is HDMI output, then the input mode of monitor must be the HDMI input). And if not, please modify the input mode of monitor.
- Step 7 Check if the fault is solved by the step 1 to step 3.
- Step 8 If it is solved, finish the process.
 - If not, please contact the engineer from Hikvision to do the further process.
- There is an audible warning sound "Di-Di-Di-DiDi" after a new bought NVR starts up.

Possible Reasons:

- No HDD is installed in the device.
- The installed HDD has not been initialized.
- The installed HDD is not compatible with the NVR or is broken-down.

Step 9 Verify at least one HDD is installed in the NVR.

- If not, please install the compatible HDD.



Please refer to the "Quick Operation Guide" for the HDD installation steps.

 If you don't want to install a HDD, select "Menu>Configuration > Exceptions", and uncheck the Audible Warning checkbox of "HDD Error".

Step 10 Verify the HDD is initialized.

- 1) Select "Menu>HDD>General".
- 2) If the status of the HDD is "Uninitialized", please check the checkbox of corresponding HDD and click the "Init" button.

Step 11 Verify the HDD is detected or is in good condition.

- 3) Select "Menu>HDD>General".
- 4) If the HDD is not detected or the status is "Abnormal", please replace the dedicated HDD according to the requirement.

Step 12 Check if the fault is solved by the step 1 to step 3.

If it is solved, finish the process.

If not, please contact the engineer from Hikvision to do the further process.

• The status of the added IP camera displays as "Disconnected" when it is connected through Private Protocol. Select "Menu>Camera>Camera>IP Camera" to get the camera status.

Possible Reasons:

- Network failure, and the NVR and IP camera lost connections.
- The configured parameters are incorrect when adding the IP camera.
- Insufficient bandwidth.

Step 1 Verify the network is connected.

- 1) Connect the NVR and PC with the RS-232 cable.
- 2) Open the Super Terminal software, and execute the ping command. Input "ping IP" (e.g. ping 172.6.22.131).



Simultaneously press Ctrl and C to exit the ping command.

If there exists return information and the time value is little, the network is normal.

Step 2 Verify the configuration parameters are correct.

- 1) Select "Menu>Camera>Camera>IP Camera".
- 2) Verify the following parameters are the same with those of the connected IP devices, including IP address, protocol, management port, user name and password.

Step 3 Verify the whether the bandwidth is enough.

- 1) Select "Menu > Maintenance > Net Detect > Network Stat.".
- 2) Check the usage of the access bandwidth, and see if the total bandwidth has reached its limit.

Step 4 Check if the fault is solved by the step 1 to step 3.

If it is solved, finish the process.

If not, please contact the engineer from Hikvision to do the further process.

 The IP camera frequently goes online and offline and the status of it displays as "Disconnected".

Possible Reasons:

- The IP camera and the NVR versions are not compatible.
- Unstable power supply of IP camera.
- Unstable network between IP camera and NVR.
- Limited flow by the switch connected with IP camera and NVR.

Step 1 Verify the IP camera and the NVR versions are compatible.

- 1) Enter the IP camera Management interface "Menu > Camera > Camera > IP Camera", and view the firmware version of connected IP camera.
- Enter the System Info interface "Menu>Maintenance>System Info>Device Info", and view the firmware version of NVR.

Step 2 Verify power supply of IP camera is stable.

- 1) Verify the power indicator is normal.
- 2) When the IP camera is offline, please try the ping command on PC to check if the PC connects with the IP camera.

Step 3 Verify the network between IP camera and NVR is stable.

- 3) When the IP camera is offline, connect PC and NVR with the RS-232 cable.
- 4) Open the Super Terminal, use the ping command and keep sending large data packages to the connected IP camera, and check if there exists packet loss.



Simultaneously press **Ctrl** and **C** to exit the ping command.

Example: Input ping 172.6.22.131 -l 1472 -f.

Step 1 Verify the switch is not flow control.

Check the brand, model of the switch connecting IP camera and NVR, and contact with the manufacturer of the switch to check if it has the function of flow control. If so, please turn it down.

Step 2 Check if the fault is solved by the step 1 to step 4.

If it is solved, finish the process.

If not, please contact the engineer from Hikvision to do the further process.

No monitor connected with the NVR locally and when you manage the IP camera to connect with the device by web browser remotely, of which the status displays as Connected. And then you connect the device with the monitor via VGA or HDMI interface and reboot the device, there is black screen with the mouse cursor.

Connect the NVR with the monitor before startup via VGA or HDMI interface, and manage the IP camera to connect with the device locally or remotely, the status of IP camera displays as Connect. And then connect the device with the CVBS, and there is black screen either.

Possible Reasons:

After connecting the IP camera to the NVR, the image is output via the main spot interface by default.

Step 1 Enable the output channel.

Step 2 Select "Menu > Configuration > Live View > View", and select video output interface in the drop-down list and configure the window you want to view.



- The view settings can only be configured by the local operation of NVR.
- Different camera orders and window-division modes can be set for different output interfaces separately, and digits like "D1" and "D2" stands for the channel number, and "X" means the selected window has no image output.

Step 3 Check if the fault is solved by the above steps.

If it is solved, finish the process.

If not, please contact the engineer from Hikvision to do the further process.

Live view stuck when video output locally.

Possible Reasons:

- Poor network between NVR and IP camera, and there exists packet loss during the transmission.
- The frame rate has not reached the real-time frame rate.

Step 1 Verify the network between NVR and IP camera is connected.

- When image is stuck, connect the RS-232 ports on PC and the rear panel of NVR with the RS-232 cable.
- Open the Super Terminal, and execute the command of "ping 192.168.0.0 -| 1472 -f" (the IP address may change according to the real condition), and check if there exists packet loss.



Simultaneously press **Ctrl** and **C** to exit the ping command.

Step 2 Verify the frame rate is real-time frame rate.

Select "Menu > Record > Parameters > Record", and set the Frame rate to Full Frame.

Step 3 Check if the fault is solved by the above steps.

If it is solved, finish the process.

If not, please contact the engineer from Hikvision to do the further process.

• Live view stuck when video output remotely via the Internet Explorer or platform software.

Possible Reasons:

- Poor network between NVR and IP camera, and there exists packet loss during the transmission.
- Poor network between NVR and PC, and there exists packet loss during the transmission.
- The performances of hardware are not good enough, including CPU, memory, etc..

Step 4 Verify the network between NVR and IP camera is connected.

- 1) When image is stuck, connect the RS-232 ports on PC and the rear panel of NVR with the RS-232 cable.
- 2) Open the Super Terminal, and execute the command of "ping 192.168.0.0 I 1472 f" (the IP address may change according to the real condition), and check if there exists packet loss.



Simultaneously press **Ctrl** and **C** to exit the ping command.

Step 5 Verify the network between NVR and PC is connected.

- 1) Open the cmd window in the Start menu, or you can press "windows+R" shortcut key to open it.
- 2) Use the ping command to send large packet to the NVR, execute the command of "ping 192.168.0.0 –l 1472 –f" (the IP address may change according to the real condition), and check if there exists packet loss.



Simultaneously press Ctrl and C to exit the ping command.

Step 6 Verify the hardware of the PC is good enough.

Simultaneously press **Ctrl**, **Alt** and **Delete** to enter the windows task management interface, as shown in the following figure.




Figure 18-1 Windows task management interface

- Select the "Performance" tab; check the status of the CPU and Memory.
- If the resource is not enough, please end some unnecessary processes.

Step 7 Check if the fault is solved by the above steps.

If it is solved, finish the process.

If not, please contact the engineer from Hikvision to do the further process.

 When using the NVR to get the live view audio, there is no sound or there is too much noise, or the volume is too low.

Possible Reasons:

- Cable between the pickup and IP camera is not connected well; impedance mismatches or incompatible.
- The stream type is not set as "Video & Audio".
- The encoding standard is not supported with NVR.
- Step 1 Verify the cable between the pickup and IP camera is connected well; impedance matches and compatible.
 - Log in the IP camera directly, and turn the audio on, check if the sound is normal. If not, please contact the manufacturer of the IP camera.
- Step 2 Verify the setting parameters are correct.
 - Select "Menu > Record > Parameters > Record", and set the Stream Type as "Audio & Video".
- Step 3 Verify the audio encoding standard of the IP camera is supported by the NVR.

NVR supports G722.1 and G711 standards, and if the encoding parameter of the input audio is not one of the previous two standards, you can log in the IP camera to configure it to the supported standard.

Step 4 Check if the fault is solved by the above steps.

If it is solved, finish the process.

If not, please contact the engineer from Hikvision to do the further process.

The image gets stuck when NVR is playing back by single or multi-channel.

Possible Reasons:

- Poor network between NVR and IP camera, and there exists packet loss during the transmission.
- The frame rate is not the real-time frame rate.
- The NVR supports up to 16-channel synchronize playback at the resolution of 4CIF, if you
 want a 16-channel synchronize playback at the resolution of 720p, the frame extracting may
 occur, which leads to a slight stuck.

Step 5 Verify the network between NVR and IP camera is connected.

- 1) When image is stuck, connect the RS-232 ports on PC and the rear panel of NVR with the RS-232 cable.
- 2) Open the Super Terminal, and execute the command of "ping 192.168.0.0 –I 1472 –f" (the IP address may change according to the real condition), and check if there exists packet loss.



Simultaneously press the **Ctrl** and **C** to exit the ping command.

Step 6 Verify the frame rate is real-time frame rate.

Select "Menu > Record > Parameters > Record", and set the Frame Rate to "Full Frame".

Step 7 Verify the hardware can afford the playback.

Reduce the channel number of playback.

Select "Menu > Record > Encoding > Record", and set the resolution and bitrate to a lower level.

Step 8 Reduce the number of local playback channel.

Select "Menu > Playback", and uncheck the checkbox of unnecessary channels.

Step 9 Check if the fault is solved by the above steps.

If it is solved, finish the process.

If not, please contact the engineer from Hikvision to do the further process.

• No record file found in the NVR local HDD, and prompt "No record file found".

Possible Reasons:

- The time setting of system is incorrect.
- The search condition is incorrect.
- The HDD is error or not detected.
- Step 1 Verify the system time setting is correct.

Select "Menu > Configuration > General > General", and verify the "Device Time" is correct.

Step 2 Verify the search condition is correct.

Select "Playback", and verify the channel and time are correct.

Step 3 Verify the HDD status is normal.

Select "Menu > HDD > General" to view the HDD status, and verify the HDD is detected and can be read and written normally.

Step 4 Check if the fault is solved by the above steps.

If it is solved, finish the process.

If not, please contact the engineer from Hikvision to do the further process.

18.4 Summary of Changes

Version 3.4.92

Added:

 Easy network access by Hik-Connect. (Chapter 2.2 Using the Wizard for Basic Configuration, Chapter 12.2.1 Configuring Hik-Connect)

Deleted:

 Delete two DDNS types: IP sever and HiDDNS. (Chapter 2.2 Using the Wizard for Basic Configuration, Chapter 12.2.2 Configuring DDNS)

Version 3.4.91

Added:

- Support long distance (max.: 250-300 m) network transmission via PoE for /P models. (Chapter 2.3.5 Configuring PoE Interface)
- Add prompt of using enterprise-level HDD to create array on GUI. (Chapter 13.1.2 Enable RAID)

Version 3.4.90

Added:

- Reset the admin password by exporting/importing the GUID file. (Chapter 2.1.2, Chapter 2.1.4, Chapter 2.1.5, Chapter 17.5.3)
- DS-7600/7700/8600/9600-I (/P) series NVR support 3D positioning in live view. (Chapter 3.1)
- Configurable main stream and sub-stream for the live view. (Chapter 3.1, Chapter 3.3)
- All-day continuous recording is configured by factory default. (Chapter 5.2)

Updated:

- Optimize the playback interface and add the configurable motion detection area for smart playback. (Chapter 6 Playback)
- Up to 2048 LRP lists supported in vehicle detection.

Version 3.4.80

Added:

 Add the new models of DS-8600NI-I8. (Chapter 1.1 Front Panel, Chapter 1.5 Rear Panel and Chapter 18.1 Specifications)

- DS-7600/7700/8600/9600-I (/P) series NVR is accessible by the thermal network camera, and supports the advanced search for fire/ship/temperature/temperature difference detection triggered alarm and the recorded video files and pictures (Chapter 11.6 Advanced Search)
- DS-7600/7700/8600/9600-I (/P) series NVR supports the playback by main stream or sub stream.
 (Chapter 6 Playback)
- Remind user to remember the password after the device is activated. (Chapter 2.3 Activating Your Device)
- One-key alarm disarming for the local alarm input 1. (Chapter 8.2 Setting Sensor Alarms)

Updated:

- Optimize the playback by normal/smart interface. (Chapter 6 Playback)
- Admin Password changed to Password when adding the IP camera. (Chapter 2.6 Adding and Connecting the IP Cameras)

Deleted:

 Delete four VCA detection types: people gathering, fast movement, parking and loitering (Chapter 10 VCA Alarm)

Version 3.4.70

Added:

 Add the POS function supported by I series NVR. (Chapter 5 Recording and Capture Settings, Chapter 6 Playback, Chapter 6 Backup, Chapter 9 POS Configuration)

Version 3.4.6

Updated:

- Update the description of IR remote control operation. (Chapter 1.2 IR Remote Control Operations)
- Change the EZVIZ Cloud P2P to HIK Cloud P2P. (Chapter 2.4 Using Wizard for Basic Configuration, Chapter 11.2.1 Configuring HIK Cloud P2P)

Version 3.4.2

Added:

- Add the new models of DS-7600NI-K1, and DS-7600NI-K1/4P. (Chapter 1.1 Front Panel and Chapter 1.5 Rear Panel)
- Support the display of IP camera's password on the IP camera management interface. (Chapter 2.4 Adding and Connecting the IP Cameras; Chapter 16.5.2 Editing a User)

- Add the configuration and use of unlock pattern for fast login. (Chapter 2.3 Using the Unlock Pattern for Login)
- Add the fisheye expansion view for the connected fisheye camera in the live view and playback.
 (Chapter 3.2.5 Fisheye Expansion View)
- Add the scaling display (30min/1h/2h/6h/24h) of time bar in the playback mode. (Chapter 6 Playback)
- Add the thumbnails view and fast view during playback. (Chapter Key Features, Chapter 6.2.2 Thumbnails View, Chapter 6.2.3 Fast View)

Updated:

- Optimize the playback interface. (Chapter 6 Playback)
- Update the digital zoom operation in image. (Chapter 3.2.3 Quick Setting Toolbar in Live View Mode, Chapter 6.2.2 Digital Zoom)

Version 3.3.9

Updated:

 Support H.265 video encoding format. (Product Key Features, Chapter 5.1 Configuring Parameters)

Deleted:

Delete the PPPoE settings. (Delete Chapter 11.2.1 Configuring PPPoE Settings)

Version 3.3.7

Added:

- Add the new models of DS-8600NI-K8, DS-7700NI-K4(/P) and DS-7600NI-K2(/P).
- Add the front panel and rear panel of the new models. (Chapter 1.1 Front Panel and Chapter 1.5 Rear Panel)
- Add the specifications of the new models (Chapter 17.1 Specifications)

Version 3.3.6

Added:

 Add front panel and rear panel of DS-9600NI-I16. (Chapter 1.1 Front Panel and Chapter 1.5 Rear Panel)

Updated:

 DS-9600NI-I16 supports RAID6, capture, picture playback, eSATA HDD and eSATA backup, two self-adaptive 10M/100M/1000M network interfaces. (Product Main Features, 2.3 Using Wizard for Basic Configuration, Chapter 5 Recording and Capture Settings, Chapter 6.1.9 Playing Back Pictures, Chapter 7 Backup, Chapter 11 Network Settings, Chapter 12 RAID, Chapter 17 Specifications)

Version 3.3.4

Added:

- Add the new models of DS-7600NI-I2 (/P) and DS-7700NI-I4 (/P).
- Add the support of Cloud P2P (Step 4 in Chapter 2.3 Using the Wizard for Basic Configuration, Chapter 11.2.2 Configuring EZVIZ Cloud P2P)

18.5 List of Compatible IP Cameras

18.5.1 List of Hikvision IP Cameras



For the list, our company holds right to interpret.

| Туре | Model | Version | Max. Resolution | Sub- stream | Audio |
|---------------|-------------------------------|---------------------|--------------------|----------------|-------|
| | DS-2CD7133F-E | V5.2.0 build 140721 | 640*480 | ٧ | × |
| | DS-2CD793NFWD-EI | V5.2.0 build 140721 | 704*576 | ٧ | ٧ |
| SD | | V2.0 build 090522 | | | |
| Network | DS-2CD802NF | V2.0 build 090715 | 704*576 | ٧ | ٧ |
| Camera | | V2.0 build 110301 | | | |
| | DS-2CD833F-E | V5.2.0 build 140721 | 640*480 | ٧ | ٧ |
| | DS-2CD893PF-E | V5.2.0 build 140721 | 704*576 | ٧ | ٧ |
| | DS-2CD2012-I | V5.3.0 build150327 | 1280*960 | ٧ | × |
| | DS-2CD2132-I | V5.3.0 build150327 | 2048*1536 | ٧ | × |
| | DS-2CD2410FD-I(W) | V5.3.0 build150327 | 1920*1080 | ٧ | ٧ |
| | DS-2CD2612F-I | V5.3.0 build150327 | 1280*960 | ٧ | × |
| | DS-2CD2612F-IS | V5.3.0 build150327 | 1280*960 | ٧ | ٧ |
| | DS-2CD2632F-I | V5.3.0 build150327 | 2048*1536 | ٧ | × |
| | DS-2CD2632F-IS | V5.3.0 build150327 | 2048*1536 | ٧ | ٧ |
| | DS-2CD2710F-I | V5.3.0 build150327 | 1920*1080 | ٧ | × |
| | DS-2CD2720F-I | V5.3.0 build150327 | 1920*1080 | ٧ | × |
| | DS-2CD4010F | V5.3.0 build150327 | 1920*1080 | ٧ | ٧ |
| | DS-2CD4012F | V5.3.0 build150327 | 1280*1024 | ٧ | ٧ |
| HD Network | DS-2CD4026FWD | V5.3.0 build150327 | 1920*1080 | ٧ | ٧ |
| Camera | DS-2CD4026FWD-SDI | V5.3.0 build150327 | 1920*1080 | ٧ | ٧ |
| | DS-2CD4032FWD | V5.3.0 build150327 | 2048*1536 | ٧ | ٧ |
| | DS-2CD4065F | V5.3.0 build150327 | 3072*2048 | ٧ | ٧ |
| | DS-2CD4124F-I(2.8-12mm) | V5.3.0 build150327 | 1920*1080 | ٧ | ٧ |
| | DS-2CD4132FWD-I(2.8-12m m) | V5.3.0 build150327 | 2048*1536 | ٧ | ٧ |
| | DS-2CD4212F-I(2.8-12mm) | V5.3.0 build150327 | 1280*1024 | ٧ | × |
| | DS-2CD4212F-IS(2.8-12mm) | V5.3.0 build150327 | 1280*1024 | ٧ | ٧ |
| | DS-2CD4212FWD-I | V5.3.0 build150327 | 1280*960 | ٧ | × |
| | DS-2CD4212FWD-IS | V5.3.0 build150327 | 1280*960 | ٧ | ٧ |
| | DS-2CD4224F-I | V5.3.0 build150327 | 1920*1080 | ٧ | × |
| | DS-2CD4232FWD-I | V5.3.0 build150327 | 2048*1536 | ٧ | × |

| Туре | Model | Version | Max. Resolution | Sub- stream | Audio |
|------|--------------------------------|---------------------|--------------------|----------------|-------|
| | DS-2CD4232FWD-IS(2.8-12m m) | V5.3.0 build150327 | 2048*1536 | ٧ | ٧ |
| | DS-2CD4312F-I | V5.3.0 build150327 | 1280*1024 | ٧ | × |
| | DS-2CD4312FWD-I | V5.3.0 build150327 | 1280*960 | ٧ | × |
| | DS-2CD4324F-I | V5.3.0 build150327 | 1920*1080 | ٧ | × |
| | DS-2CD4332FHWD-IS | V5.3.0 build150327 | 2048*1536 | ٧ | ٧ |
| | DS-2CD4332FHWD-I | V5.3.0 build150327 | 2048*1536 | ٧ | × |
| | DS-2CD4332FWD-I | V5.3.0 build150327 | 2048*1536 | ٧ | × |
| | DS-2CD6213F | V5.2.6 build 141218 | 1280*960 | ٧ | × |
| | DS-2CD6223F | V5.2.6 build 141218 | 1920*1080 | ٧ | × |
| | DS-2CD6233F | V5.2.6 build 141218 | 2048*1536 | ٧ | × |
| | DS-2CD7153-E | V5.2.0 build 140721 | 1600*1200 | ٧ | × |
| | DS-2CD7164-E | V5.2.0 build 140721 | 1280*720 | ٧ | × |
| | DS_2CD754F-EI | V5.2.0 build 140721 | 2048*1536 | ٧ | ٧ |
| | DS-2CD754FWD-E | V5.2.0 build 140721 | 1920*1080 | ٧ | ٧ |
| | DS-2CD754FWD-EIZ | V5.2.0 build 140721 | 2048*1536 | ٧ | ٧ |
| | DS_2CD783F-EI | V5.2.0 build 140721 | 2560*1920 | ٧ | ٧ |
| | DS-2CD8153F-E | V5.2.0 build 140721 | 1600*1200 | ٧ | ٧ |
| | DS-2CD8464F-EI | V5.2.0 build 140721 | 1280*960 | ٧ | ٧ |
| | | V2.0 build 110614 | | | |
| | DS-2CD852MF-E | V2.0 build 110426 | 1600*1200 | ٧ | ٧ |
| | | V2.0 build 100521 | | | |
| | DS-2CD855F-E | V5.2.0 build 140721 | 1920*1080 | ٧ | ٧ |
| | | V2.0 build 110614 | | | |
| | DS-2CD862MF-E | V2.0 build 110426 | 1280*960 | ٧ | ٧ |
| | | V2.0 build 100521 | | | |
| | DS-2CD863PF/NF-E | V5.2.0 build 140721 | 1280*960 | ٧ | ٧ |
| | DS-2CD864FWD-E | V5.2.0 build 140721 | 1280*720 | ٧ | ٧ |
| | DS-2CD876MF/BF-E | V4.0.3 build120913 | 1600*1200 | ٧ | ٧ |
| | DS-2CD877BF | V4.0.3 build120913 | 1920*1080 | ٧ | ٧ |
| | DS-2CD886MF-E | V4.0.3 build 120913 | 2560*1920 | ٧ | ٧ |

| Туре | Model | Version | Max. Resolution | Sub- stream | Audio |
|---------|----------------|---------------------|--------------------|----------------|-------|
| | DS-2CD966(B) | V3.1 build 120423 | 1360*1024 | × | × |
| | DS-2CD966-V(B) | V3.1 build 120423 | 1360*1024 | × | × |
| | DS-2CD976(C) | V3.1 build 120423 | 1600*1200 | × | × |
| | DS-2CD976-V(C) | V3.1 build 120423 | 1600*1200 | × | × |
| | DS-2CD977(C) | V3.1 build 120423 | 1920*1080 | × | × |
| | DS-2CD986A(C) | V3.1 build 120423 | 2448*2048 | × | × |
| | DS-2CD986C (B) | V2.3.6 build 120401 | 2560*1920 | × | × |
| | DS-2CD9122 | V3.7.1 build140417 | 1920*1080 | ٧ | × |
| | DS-2CD9152 | V3.7.1 build140417 | 2560*1920 | ٧ | × |
| | iDS-2CD9152 | V3.7.1 build140417 | 2560*1920 | ٧ | × |
| | DS-2CD9122-H | V3.7.1 build140417 | 1920*1080 | ٧ | × |
| | DS-2CD9182-H | V3.8.1 build140815 | 3296*2472 | ٧ | × |
| | DS-2CD9121 | V3.7.1 build140417 | 1600*1200 | ٧ | × |
| | iDS-2CD9121 | V3.7.1 build140417 | 1600*1200 | ٧ | × |
| | DS-2CD9131 | V4.0.0 build150213 | 2048*1536 | ٧ | × |
| | iDS-2CD9131 | V4.0.0 build150213 | 2048*1536 | ٧ | × |
| | DS-2CD9121A | V3.8.2 build141121 | 1600*1200 | ٧ | × |
| HD | iDS-2CD9121A | V3.8.2 build141121 | 1600*1200 | ٧ | × |
| Network | DS-2CD9111(B) | V3.7.1 build140417 | 1360*1024 | ٧ | × |
| Camera | DS-2CD9151A | V3.8.2 build141121 | 2448*2048 | ٧ | × |
| | DS-2CD9152-H | V3.8.2 build141121 | 2592*2048 | ٧ | × |
| | iDS-2CD9282 | V3.8.2 build141121 | 3296*2472 | ٧ | × |
| | DS-2CD9131-K | V4.0.0 build150213 | 2048*1536 | ٧ | ٧ |
| | DS-2CD9152-HK | V3.8.2 build141121 | 2592*2048 | ٧ | ٧ |
| | iDS-2CD9131-E | V3.8.2 build141121 | 2048*1536 | ٧ | × |
| | iDS-2CD9151A-E | V3.8.2 build141121 | 2448*2048 | ٧ | × |
| | iDS-2CD9151A | V3.8.2 build141121 | 2448*2048 | ٧ | × |
| | iDS-2CD9152-EH | V3.8.2 build141121 | 2592*2048 | ٧ | × |
| | iDS-2CD9152-H | V3.8.2 build141121 | 2592*2048 | ٧ | × |
| | DS-2CD9120-H | V3.7.1 build140417 | 1600*1200 | ٧ | × |

| Туре | Model | Version | Max. Resolution | Sub- stream | Audio |
|---------------|-------------------|--------------------|--------------------|----------------|-------|
| | iDS-2CD9361 | V4.0.0 build150213 | 2752*2208 | ٧ | × |
| | iDS-2CD9022 | V4.0.0 build150213 | 1920*1080 | ٧ | ٧ |
| | iDS-2CD9025 | V3.8.2 build141114 | 1920*1080 | ٧ | × |
| | iDS-2CD9022-SZ | V4.0.0 build150213 | 1920*1080 | ٧ | × |
| | DS-2CD9125-KS | V3.8.1 build150113 | 1920*1080 | ٧ | × |
| | DS-6501HCI | V1.0.1 build130607 | 352*288 | ٧ | ٧ |
| | DS-6501HCI-SATA | V1.0.1 build130607 | 352*288 | ٧ | ٧ |
| | DS-6501HFI | V1.0.1 build130607 | 704*576 | ٧ | ٧ |
| | DS-6501HFI- SATA | V1.0.1 build130607 | 704*576 | ٧ | ٧ |
| | DS-6502HCI | V1.0.1 build130607 | 352*288 | ٧ | ٧ |
| | DS-6502HCI- SATA | V1.0.1 build130607 | 352*288 | ٧ | ٧ |
| | DS-6502HFI | V1.0.1 build130607 | 704*576 | ٧ | ٧ |
| | DS-6502HFI- SATA | V1.0.1 build130607 | 704*576 | ٧ | ٧ |
| | DS-6504HCI | V1.0.1 build130607 | 352*288 | ٧ | ٧ |
| | DS-6504HCI- SATA | V1.0.1 build130607 | 352*288 | ٧ | ٧ |
| | DS-6504HFI | V1.0.1 build130607 | 704*576 | ٧ | ٧ |
| | DS-6504HFI- SATA | V1.0.1 build130607 | 704*576 | ٧ | ٧ |
| SD Encoder | DS-6508HCI | V1.0.1 build130607 | 352*288 | ٧ | ٧ |
| 2.100 Ge. | DS-6508HCI- SATA | V1.0.1 build130607 | 352*288 | ٧ | ٧ |
| | DS-6508HFI | V1.0.1 build130607 | 704*576 | ٧ | ٧ |
| | DS-6508HFI- SATA | V1.0.1 build130607 | 704*576 | ٧ | ٧ |
| | DS-6516HCI | V1.0.1 build130607 | 352*288 | ٧ | ٧ |
| | DS-6516HCI- SATA | V1.0.1 build130607 | 352*288 | ٧ | ٧ |
| | DS-6516HFI | V1.0.1 build130607 | 704*576 | ٧ | ٧ |
| | DS-6516HFI- SATA | V1.0.1 build130607 | 704*576 | ٧ | ٧ |
| | DS-6601HCI | V1.2.1 build131202 | 352*288 | ٧ | ٧ |
| | DS-6602HCI | V1.2.1 build131202 | 352*288 | ٧ | ٧ |
| | DS-6604HCI | V1.2.1 build131202 | 352*288 | ٧ | ٧ |
| | DS-6601HFI(-SATA) | V1.2.1 build131202 | 704*576 | ٧ | ٧ |
| | DS-6602HFI(SATA) | V1.2.1 build131202 | 704*576 | ٧ | ٧ |

| Туре | Model | Version | Max. Resolution | Sub- stream | Audio |
|--------------------------|--|--------------------|--------------------|----------------|-------|
| | DS-6604HFI(-SATA) | V1.2.1 build131202 | 704*576 | ٧ | ٧ |
| | DS-6701HWI | V1.2.3 build141202 | 960*576 | ٧ | ٧ |
| | DS-6701HWI-SATA | V1.2.3 build141202 | 960*576 | ٧ | ٧ |
| | DS-6704HWI | V1.2.3 build141202 | 960*576 | ٧ | ٧ |
| | DS-6704HWI-SATA | V1.2.3 build141202 | 960*576 | ٧ | ٧ |
| | DS-6708HWI | V1.2.3 build141202 | 960*576 | ٧ | ٧ |
| | DS-6708HWI-SATA | V1.2.3 build141202 | 960*576 | ٧ | ٧ |
| | DS-6716HWI | V1.2.3 build141202 | 960*576 | ٧ | ٧ |
| | DS-6716HWI-SATA | V1.2.3 build141202 | 960*576 | ٧ | ٧ |
| HD | DS-6601HFHI | V1.1.0 build150123 | 1920*1080 | ٧ | ٧ |
| Encoder | DS-6601HFHI/L | V1.1.0 build150123 | 1920*1080 | ٧ | ٧ |
| | DS-2DF7274-A/D/AF | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | iDS-2DF7274-A/D/AF | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | DS-2DM7274-A | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | DS-2DF5274-A/D/A3/D3/AF/ A3F | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | iDS-2DF5274-A/D/A3/D3/AF /A3F | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | DS-2DM5274-A/A3 | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | DS-2DF7276-A/D/AF | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| Material | iDS-2DF7276-A/D/AF | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| Network Speed Dome | DS-2DF5276-A/D/A3/D3/AF/ A3F | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | iDS-2DF5276-A/D/A3/D3/AF /A3F | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | DS-2DF7274-AH/DH/AFH | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | iDS-2DF7274-AH/DH/AFH | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | DS-2DF5274-AH/DH/A3H/D3 H/AFH/A3FH | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | iDS-2DF5274-AH/DH/A3H/D 3H/AFH/A3FH | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | DS-2DF7276-AH/DH/AFH | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | iDS-2DF7276-AH/DH/AFH | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |

| Туре | Model | Version | Max. Resolution | Sub- stream | Audio |
|------|--|--------------------|--------------------|----------------|-------|
| | DS-2DF5276-AH/DH/A3H/D3 H/AFH/A3FH | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | iDS-2DF5276-AH/DH/A3H/D 3H/AFH/A3FH | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | DS_2DF7130I5-AW | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | DS-2DF7285-AH | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2DF5285-AH | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2DF7294-A/D/AF | V5.2.8 build150124 | 2048*1536 | ٧ | ٧ |
| | iDS-2DF7294-A/D/AF | V5.2.8 build150124 | 2048*1536 | ٧ | ٧ |
| | DS-2DF5294-A/D/A3/D3/AF/ A3F | V5.2.8 build150124 | 2048*1536 | ٧ | ٧ |
| | iDS-2DF5294-A/D/A3/D3/AF /A3F | V5.2.8 build150124 | 2048*1536 | ٧ | ٧ |
| | DS-2DF7296-A/D/AF | V5.2.8 build150124 | 2048*1536 | ٧ | ٧ |
| | iDS-2DF7296-A/D/AF | V5.2.8 build150124 | 2048*1536 | ٧ | ٧ |
| | DS-2DF5296-A/D/A3/D3/AF/ A3F | V5.2.8 build150124 | 2048*1536 | ٧ | ٧ |
| | iDS-2DF5296-A/D/A3/D3/AF /A3F | V5.2.8 build150124 | 2048*1536 | ٧ | ٧ |
| | DS-2DF6223-A | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | iDS-2DF6223-A | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2DF8223i-A | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | iDS-2DF8223i-A | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2DF7284-A/D/AF | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | iDS-2DF7284-A/D/AF | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2DF7286-A/D/AF | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | iDS-2DF7286-A/D/AF | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2DF5284-A/D/A3/D3/AF/ A3F | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | iDS-2DF5284-A/D/A3/D3/AF /A3F | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2DF5286-A/D/A3/D3/AF/ A3F | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |

| Туре | Model | Version | Max. Resolution | Sub- stream | Audio |
|------|----------------------------------|---------------------|--------------------|----------------|-------|
| | iDS-2DF5286-A/D/A3/D3/AF /A3F | V5.2.8 build150124 | 1920*1080 | V | ٧ |
| | DS_2DF7230I5-AW | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2AF7220-A/D | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2AF7230-A/D | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2AF5220-A/D | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2AF5230-A/D | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | iDS-2DF5220S-D4/JY | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2DF7268-A | V5.2.8 build150124 | 704*576 | ٧ | ٧ |
| | DS-2DF5268-A | V5.2.8 build150124 | 704*576 | ٧ | ٧ |
| | DS-2DF7264-A | V5.2.8 build150124 | 704*576 | ٧ | ٧ |
| | DS-2DF5264-A | V5.2.8 build150124 | 704*576 | ٧ | ٧ |
| | DS-2DE5172-A/A3 | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DE5174-A/AE/AE3/A3/D /D3 | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DE5176-A/AE | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DE7172-A | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DE7174-A/AE/D | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DE7176-A/AE | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DE7120i-A/AE | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DM7130i-A | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DM4120-A | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DE5120I-A | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DM5120-A | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DM5130-A | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DE2103-DE3/W | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DE2103I-DE3/W | V5.2.10 build150128 | 1280*960 | ٧ | ٧ |
| | DS-2DE7184-A/AE/D | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DE5182-A/A3 | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DE5184-A/AE/AE3/A3/D /D3 | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |

| Туре | Model | Version | Max. Resolution | Sub- stream | Audio |
|------|-------------------|---------------------|--------------------|----------------|-------|
| | DS-2DE5186-A/AE | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DE7182-A | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DE4582-A | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DE4220-A | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DE4182-A | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DM7230i-A | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DM7220i-A | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DE7186-A/AE | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DE5220I-A | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DM5220-A | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DM5230-A | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DE2202-DE3/W | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DE2202I-DE3/W | V5.2.10 build150128 | 1920*1080 | ٧ | ٧ |
| | DS-2DE4572-A | V5.2.10 build150128 | 1280*720 | ٧ | ٧ |
| | DS-2DE4172-A | V5.2.10 build150128 | 1280*720 | ٧ | ٧ |
| | DS-2DE7194-A/A3 | V5.2.10 build150128 | 2048*1536 | ٧ | ٧ |
| | DS-2DE5194-A/A3 | V5.2.10 build150128 | 2048*1536 | ٧ | ٧ |
| | DS-2DF1-518 | V3.2.0 build131223 | 704*576 | ٧ | ٧ |
| | DS-2DM1-718 | V3.2.0 build131223 | 704*576 | ٧ | ٧ |
| | DS-2DM1-518 | V3.2.0 build131223 | 704*576 | ٧ | ٧ |
| | DS-2DF1-718 | V3.2.0 build131223 | 704*576 | ٧ | ٧ |
| | DS-2DF1-514 | V3.2.0 build131223 | 704*576 | ٧ | ٧ |
| | DS-2DF1-714 | V3.2.0 build131223 | 704*576 | ٧ | ٧ |
| | DS-2DY9174-A | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | DS-2DY9176-A | V5.2.8 build150124 | 1280*960 | ٧ | ٧ |
| | DS-2DY9194-A | V5.2.8 build150124 | 2048*1536 | ٧ | ٧ |
| | DS-2DY9196-A | V5.2.8 build150124 | 2048*1536 | ٧ | ٧ |
| | DS-2DY9184-A | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2DY9186-A | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |
| | DS-2DY9185-A | V5.2.8 build150124 | 1920*1080 | ٧ | ٧ |

| Туре | Model | Version | Max. Resolution | Sub- stream | Audio |
|------------------|----------------|--------------------|--------------------|----------------|-------|
| | DS-2DY9187-A | V5.2.8 build150124 | 1920*1080 | ٧ | V |
| | DS-2DF8223IV-A | V5.3.0 build150304 | 1920*1080 | ٧ | ٧ |
| | DS-2DF8623IV-A | V5.3.0 build150304 | 3072*1728 | ٧ | ٧ |
| | DS-2DF6623V-A | V5.3.0 build150304 | 3072*1728 | ٧ | ٧ |
| | DS-2DF8823IV-A | V5.3.0 build150304 | 4096*2160 | ٧ | ٧ |
| | DS-2ZCN2006 | V5.2.7 build141107 | 1280*960 | ٧ | ٧ |
| | DS-2ZCN2006(B) | V5.2.7 build141107 | 1280*960 | ٧ | ٧ |
| | DS-2ZCN3006 | V5.2.7 build141107 | 1280*960 | ٧ | ٧ |
| | DS-2ZCN3006(B) | V5.2.7 build141107 | 1280*960 | ٧ | ٧ |
| | DS-2ZMN2006 | V5.2.7 build141107 | 1280*960 | ٧ | ٧ |
| | DS-2ZMN2006(B) | V5.2.7 build141107 | 1280*960 | ٧ | ٧ |
| | DS-2ZMN3006 | V5.2.7 build141107 | 1280*960 | ٧ | ٧ |
| | DS-2ZMN3006(B) | V5.2.7 build141107 | 1280*960 | ٧ | ٧ |
| | DS-2ZCN2007 | V5.2.7 build141107 | 1920*1080 | ٧ | ٧ |
| | DS-2ZCN3007 | V5.2.7 build141107 | 1920*1080 | ٧ | ٧ |
| | DS-2ZCN3007(B) | V5.2.7 build141107 | 1920*1080 | ٧ | ٧ |
| Network Zoom | DS-2ZMN2007 | V5.2.7 build141107 | 1920*1080 | ٧ | ٧ |
| Camera Module | DS-2ZMN3007 | V5.2.7 build141107 | 1920*1080 | ٧ | ٧ |
| iviodule | DS-2ZMN3007(B) | V5.2.7 build141107 | 1920*1080 | ٧ | ٧ |
| | DS-2ZMN0407 | V5.2.7 build141107 | 1920*1080 | ٧ | ٧ |
| | DS-2ZMN3207 | V5.2.7 build141107 | 1920*1080 | ٧ | ٧ |
| | DS-2ZMN2008 | V5.2.7 build141107 | 2048*1536 | ٧ | ٧ |
| | DS-2ZCN2008 | V5.2.7 build141107 | 2048*1536 | ٧ | ٧ |
| | DS-2ZMN3007(S) | V5.2.2 build141113 | 1920*1080 | ٧ | ٧ |
| | DS-2ZCN3007(S) | V5.2.2 build141113 | 1920*1080 | ٧ | ٧ |
| | DS-2ZMN2307 | V5.2.2 build141113 | 1920*1080 | ٧ | ٧ |
| | DS-2CN2307 | V5.2.2 build141113 | 1920*1080 | ٧ | ٧ |
| | DS-2ZMN2309 | V5.2.2 build141113 | 3072*2048 | ٧ | ٧ |
| | DS-2ZCN2309 | V5.2.2 build141113 | 3072*2048 | ٧ | ٧ |

18.5.2 List of Third-party IP Cameras



ONVIF compatibility refers to the camera can be supported both when it uses the ONVIF protocol and its private protocols. **Only ONVIF is supported** refers to the camera can only be supported when it uses the ONVIF protocol. **Only AXIS is supported** refers to the function can only be supported when it uses the AXIS protocol.

| IP Camera Manufacturer or Protocol | Model | Version | Max. Resolution | Sub- stream | Audio |
|--|--|---------------------|------------------------|----------------|-------|
| | ACM3401-09L-X-002 27 | A1D-220-V3.13.16-AC | 1208*1024 | × | × |
| ACTi | TCM4301-10D-X-00 083 | A1D-310-V4.12.09-AC | 1208*1024 | × | ٧ |
| | TCM5311-11D-X-00 023 | A1D-310-V4.12.09-AC | 1208*960 | × | ٧ |
| | AV1305 M | 65175 | 1208*1024 | ٧ | × |
| A | AV2815 | 65220 | 1920*1080 | ٧ | × |
| Arecont | AV3105M | 65175 | 1920*1080 | ٧ | × |
| | AV8185DN | 65172 | 1600*1200 | × | × |
| | M1114 | 5.09.1 | 1024*640 | ٧ | × |
| | M3011(ONVIF compatibility) | 5.21 | 640*480 (704*576) | √ (×) | × |
| | M3014(ONVIF compatibility) | 5.21.1 | 1280*800 | ٧ | × |
| | P1346 | 5.40.9.2 | 2048*1536 | ٧ | ٧ |
| Axis | P3301(ONVIF compatibility) | 5.11.2 | 640*480 (768*576) | V | √ (×) |
| | P3304(ONVIF compatibility) | 5.20 | 1280*800 (1440*900) | ٧ | √ (×) |
| | P3343(ONVIF compatibility) | 5.20.1 | 800*600 | ٧ | √ (×) |
| | P3344(ONVIF compatibility) | 5.20.1 | 1280*800 (1440*900) | V | √ (×) |
| | P5532 | 5.15 | 720*576 | ٧ | × |
| | Q7404 | 5.02 | 720*576 | ٧ | ٧ |
| | AutoDome Jr 800 HD (ONVIF compatibility) | 39500450 | 1920*1080 | × | v (×) |
| Bosch | Dinion NBN-921-P (ONVIF compatibility) | 10500453 | 1280*720 | × | v (×) |

| | NBC 265 P (ONVIF compatibility) | 07500452 | 1280*720 | × | v (×) |
|-----------|---|--------------------------------------|-------------------------|-------|-------|
| Brickcom | CB-500Ap(Brickcom- 50xA) (ONVIF compatibility) | v3.2.1.3 | 1920*1080 | × | v (×) |
| | VB-H410(ONVIF compatibility) | Ver.+1.0.0 | 1920*1080 (1280*960) | × | ٧ |
| | VB-S9000F | Ver. 1.0.0 | 1920*1080 | × | × |
| Canon | VB-S300D | Ver. 1.0.0 | 1920*1080 | × | × |
| | VB-H6100D | Ver. 1.0.0 | 1920*1080 | × | × |
| | VB-H7100F | Ver. 1.0.0 | 1920*1080 | × | ٧ |
| | VB-S8000 | Ver. 1.0.0 | 1920*1080 | × | × |
| Panasonic | SP306H (ONVIF compatibility) | Application:1.34 Image data:1.06 | 1280*960 | v (×) | ٧ |
| | SF336H | Application:1.06 Image data: 1.06 | 1280*960 | ٧ | ٧ |
| | D5118 (ONVIF compatibility) | 1.8.2-20120327-2.93 10-A1.7852 | 1280*960 | ٧ | × |
| Pelco | IX30DN-ACFZHB3 (ONVIF compatibility) | 1.8.2-20120327-2.90 80-A1.7852 | 2048*1536 | ٧ | × |
| | IXE20DN-AAXVUU2 (ONVIF compatibility) | 1.8.2-20120327-2.90 81-A1.7852 | 1920*1080 | ٧ | × |
| | 2300P(with lens) | 2.03-02 (110318-00) | 1920*1080 | × | × |
| Sanyo | 2500P(with lens) | 2.02-02 (110208-00) | 1920*1080 | × | ٧ |
| | 4600P | 2.03-02 (110315-00) | 1920*1080 | × | ٧ |
| | SNC-CH220 | 1.50.00 | 1920*1080 | × | × |
| SONY | SNCDH220T (ONVIF only) | 1.50.00 | 2048*1536 | × | × |
| | SNC-EP580 (ONVIF compatibility) | 1.53.00 | 1920*1080 | ٧ | ٧ |

Network Video Recorder User Manual

| | SNC-RH124 (ONVIF compatibility) | 1.79.00 | 1280*720 | V | V |
|---------|---------------------------------------|---------------|-----------|-------|-------|
| SUMSUNG | SND-5080 (ONVIF compatibility) | 3.10_130416 | 1280*1024 | V | ٧ |
| | IP7133 | 0203a | 640*480 | × | × |
| | FD8134 (ONVIF compatibility) | 0107a | 1280*800 | × | × |
| Vivotek | IP8161 (ONVIF compatibility) | 0104a | 1600*1200 | × | √ (×) |
| | IP8331 (ONVIF compatibility) | 0102a | 640*480 | × | × |
| | IP8332 (ONVIF compatibility) | 0105b | 1280*800 | × | × |
| | D5110 (ONVIF compatibility) | MG.1.6.03P8 | 1280*1024 | √ (×) | × |
| | F3106 (ONVIF compatibility) | M2.1.6.03P8 | 1280*1024 | √ (×) | ٧ |
| Zavio | F3110 (ONVIF compatibility) | M2.1.6.01 | 1280*720 | v (×) | ٧ |
| | F3206 (ONVIF compatibility) | MG.1.6.02c045 | 1920*1080 | v (×) | ٧ |
| | F531E (ONVIF compatibility) | LM.1.6.18P10 | 640*480 | v (×) | ٧ |

18.5.3 List of IP Cameras Connected to PoE by Long Network Cable (100 - 300 m)

| Index | Model |
|-------|--------------------|
| 1 | DS-2CD4665F-IZHS |
| 2 | DS-2CD4026FWD-AP |
| 3 | DS-2CD4A35FWD-IZHS |
| 4 | DS-2CD2642FWD-IZS |
| 5 | DS-2CD2F42FWD-IWS |
| 6 | DS-2CD2942F-IWS |
| 7 | DS-2CD2510F |
| 8 | DS-2CD2342WD-I |
| 9 | DS-2CD2322WD-I |
| 10 | DS-2CD2352-I |
| 11 | DS-2CD2642FWD-IZS |
| 12 | DS-2CD2642FWD-I |
| 13 | DS-2CD2642FWD-IS |
| 14 | DS-2CD2642FWD-IZ |
| 15 | DS-2CD2742FWD-IZS |
| 16 | DS-2CD2742FWD-I |
| 17 | DS-2CD2742FWD-IS |
| 18 | DS-2CD2742FWD-IZ |
| 19 | DS-2CD2T42WD-I8 |
| 20 | DS-2CD2T42WD-I5 |

030492170208

